

## FOREWORD

- Thank you very much for purchasing our tractor which will give you many years of reliable service.
- The introduction in this manual sets out the correct manner of operating, maintaining and checking the tractor to ensure long-term durability.
- Please ensure correct operation of the tractor as incorrect can cause substantial mechanical damage as well as cause accidents with the associated injuries.
- Please note that in some cases differences can exist between this manual and your tractor due to the manufacture's policy of constant product improvement.
- In the event that you encounter a problem not covered by this manual, please contact your nearest dealer who will assist you in resolving your problem.



### **CALIFORNIA PROPOSITION 65 WARNING**

The engine exhaust from this product contains chemicals known to the state of California to cause cancer, birth defects or other reproductive harm.

## WARNING SIGNS

### WARNING SIGNS IN THIS MANUAL

The following warning signs in this manual draw additional attention to items of importance for the safe and correct operation of the tractor.

SIGNS	MEANING OF THE SIGN
 <b>DANGER</b>	This indicates that a condition may result in harm, serious injury or death to you or other persons if the warning is not heeded. Follow the advice provided with the warning signs.
 <b>WARNING</b>	Hazard or unsafe practice that can lead to severe injury or death.
 <b>CAUTION</b>	Hazard or unsafe practice that can lead in injury or death.
 <b>IMPORTANT</b>	Instructions for the correct operation of the machine which, if followed, will ensure that it performs at its best.

All information, illustrations and specifications in this manual are based on latest information available at the time of publication. The right is reserved to make change at any time without a notice.

**GENERAL INFORMATION**

**A**

**SAFETY PRECAUTIONS**

**B**

**TRACTOR INSTRUMENTS**

**C**

**OPERATION**

**D**

**MAINTENANCE**

**E**

**TROUBLESHOOTING**

**F**

**STANDARD FOR FARMWORK**

**G**

**APPENDIX**

**H**

**INDEX**

**I**

# TABLE OF CONTENTS

## GENERAL INFORMATION **A**

1. EXTERIOR VIEW . . . . . A – 2
2. TRACTOR IDENTIFICATION . . . . . A – 5
3. ABOUT THIS MANUAL . . . . . A – 6
4. INTRODUCTION & DESCRIPTION . . . . . A – 7
5. OWNER ASSISTANCE . . . . . A – 9
6. ROPS (ROLL OVER PROTECTIVE STRUCTURES) . . . . . A – 10
7. SEAT ADJUSTMENT . . . . . A – 12

## TRACTOR INSTRUMENTS **C**

1. SWITCHES AND INSTRUMENT PANEL . . . . . C – 2
2. CONTROLS . . . . . C – 18
3. THREE POINT LINKAGE . . . . . C – 35
4. CABIN . . . . . C – 39

## MAINTENANCE **E**

1. OPENING COVERS . . . . . E – 2
2. INSPECTION ITEMS . . . . . E – 3
3. SERVICING EACH PART . . . . . E – 4
4. MAINTENANCE AND ADJUSTMENT SCHEDULE . . . . . E – 30
5. INSPECTING ELECTRO HYDRAULIC SYSTEM . . . . . E – 33

## SAFETY PRECAUTIONS **B**

1. SAFETY INSTRUCTIONS . . . . . B – 2
2. SAFE OPERATION OF TRACTOR . . . . . B – 15
3. DOs & DON'Ts . . . . . B – 22
4. SAFETY DECALS . . . . . B – 24
5. UNIVERSAL SYMBOLS . . . . . B – 29

## OPERATION **D**

1. START & STOP OF ENGINE . . . . . D – 2
2. OPERATING TRACTOR . . . . . D – 4
3. OPERATION OF PTO . . . . . D – 7
4. IMPLEMENTS . . . . . D – 9
5. TOWING THE TRACTOR . . . . . D – 10
6. CHECKS DURING DRIVING . . . . . D – 12
7. WORK PROCEDURES . . . . . D – 14
8. OPERATION TIPS . . . . . D – 20

## TROUBLESHOOTING **F**

1. ENGINE TROUBLESHOOTING . . . . . F – 2
2. BRAKE, CLUTCH TROUBLESHOOTING . . . . . F – 5
3. STEERING WHEEL & HYDRAULIC SYSTEM TROUBLESHOOTING . . . . . F – 6
4. ELECTRIC INSTRUMENTS TROUBLESHOOTING . . . . . F – 7

## **STANDARD FOR FARMWORK** **G**

1. STANDARD FOR FARMWORK . . . . . G - 2

## **INDEX** **I**

1. INDEX . . . . . I - 2

## **APPENDIX** **H**


1. SPECIFICATION . . . . . H - 2

2. STANDARD PARTS . . . . . H - 4

3. MAJOR CONSUMABLES . . . . . H - 5

4. ENGINE EMISSION WARRANTY . . . . . H - 7





## **GENERAL INFORMATION**

1. EXTERIOR VIEW · · · · · A – 2
2. TRACTOR IDENTIFICATION · · · · · A – 5
3. ABOUT THIS MANUAL · · · · · A – 6
4. INTRODUCTION & DESCRIPTION · · · · · A – 7
5. OWNER ASSISTANCE · · · · · A – 9
6. ROPS (Roll Over Protective Structures) · · · · A – 10
7. SEAT ADJUSTMENT · · · · · A – 12



## 1. EXTERIOR VIEW

### ► RIGHT SIDE OF THE TRACTOR




► LEFT SIDE OF THE TRACTOR

A






## ► BACK SIDE OF THE TRACTOR



## 2. TRACTOR IDENTIFICATION

### ▶ TYPE OR NUMBER OF ENGINE & CHASSIS



The chassis number is stamped as shown in the drawing above.

### ▶ WARRANTY OF THE PRODUCT

The manufacturer warrants this product and full details of the warranty are provided on a separate warranty schedule.

### ▶ SERVICE & PARTS

#### • SERVICE

Service is available from any TYM dealer in the country.

#### • PARTS

To obtain spare parts please contact your nearest dealer and give him the details listed below.

- Tractor model
- Tractor serial number
- Tractor engine number
- Part number and description
- Quantity required



### 3. ABOUT THIS MANUAL

This manual has been prepared to assist you in following/adopting the correct procedure for running-in operation and maintenance of your new TYM CO., LTD tractor.

Your tractor has been designed and built to give maximum performance, with good fuel economy and ease of operation under a wide variety of operating conditions.

Prior to delivery, the tractor was carefully inspected, both at the factory and by your TYM Dealer/Distributor, to ensure that it reaches you in optimum conditions.

To maintain this condition and ensure trouble free performance, it is important that the routine services, as specified in this manual, are carried out at the recommended intervals.

Read this manual carefully and keep it in a convenient place for future reference.

If at any time you require advice concerning your tractor, do not hesitate to contact your authorized TYM dealer / distributor.

He has trained personnel, genuine parts and necessary equipment to undertake all your service requirements.

Manufacturer's policy is one of continuous improvement, and the right to change prices, specifications or equipment at any time without notice is reserved.

All data given in this book is subject to production variations.

Dimensions & weight are approximate only and the illustrations do not necessarily show tractors in standard condition.

For exact information about any particular tractor, please consult your TYM dealer / distributor.

## 4. INTRODUCTION & DESCRIPTION

### ► INTRODUCTION OF A TRACTOR

The word, 'tractor' has been derived from 'traction' which means pulling. A tractor is required to pull or haul an equipment, implement or trolley which are coupled to the tractor body through suitable linkage.

A tractor can also be used as a prime mover as it has a power outlet source which is also called Power Take or PTO shaft.

In this book the operating, maintenance and storage instructions for all models of TYM diesel tractors has been compiled. This material has been prepared in detail to help you in the better understanding of maintenance and efficient operation of the machine.

If you need any information not given in this manual, or require the services of a trained mechanic, please get in touch with the TYM dealer / distributor in your locality.

Dealer / distributors are kept informed of the latest methods of servicing tractors.

They stock genuine spare parts and are backed by the company's full support.


Through this manual, the use of the terms LEFT, RIGHT, FRONT and REAR must be understood, to avoid any confusion when following the introductions.

The LEFT and RIGHT means left and right sides of the tractor when facing forward in the driver's seat, reference to the FRONT indicates the radiator end of the tractor, while the REAR, indicates the drawbar end.

When spare parts are required, always specify the tractor and engine serial number when ordering these parts. This will facilitate faster delivery and help ensure that the correct parts for your particular tractor is received.

The tractor serial number is punched on a plate attached to the left hand side of the engine body.

For easy reference, we suggest you to write the number in the space provided in the owner's personal data.





### ► DESCRIPTION

#### • GENERAL CONSTRUCTION

The transmission case, clutch, clutch housing, engine and front axle support are bolted together to form a rigid unit.

#### • FRONT AXLE & WHEEL

The 4WD front axle is a center-pivot, reverse eliot type.

The front wheel drive mechanism is incorporated as a part of the axle.

The front wheel drive power is taken off the rear transmission and transmitted to the differential in the front axle where the power is divided into right and left and to the respective final cases.

In the final cases, the transmitted revolution is reduced by the level gears to drive the front wheel.

The 4WD mechanism with level gears provides wider steering and greater durability.

#### • ENGINE

The tractors are fitted with fuel efficient turbo charged engines with 4 cylinders of T854/T954/T1004/T1054/T1104 designed by DOOSAN INFRACORE engines company.

#### • TRANSMISSION

Tractor with IPTO(Independent Power Take Off) are fitted with hydraulic clutch assy.

The transmission gear box of T854/T954/T1004/T1104/T1054(EU), T954/T1054/T1104(US) has 32 Forward, 32 Reverse.

Presently, TYM Tractors are fitted with partial synchro mesh type gears.

#### • BRAKES

TYM tractors are provided with independent disc brakes operated by two brake rods' movement.

Use parking brake lever in case of parking the tractor.

#### • REAR AXLE & WHEELS

This is mounted on ball bearings and is enclosed in removable housing which are bolted to the transmission case. The rim & disc fitted with rear tires are bolted to the outer flange of rear axle.

#### • HYDRAULIC SYSTEM & LINKAGES

TYM tractors are fitted with Live (i.e. system is in operation even when clutch is disengaged.) independent, very touch of hydraulic System.

Three point Linkages can be used for category 2 type of implements.

#### • STEERING

It consists of hydrostatic power steering system, which has a hydraulic cylinder and tandem type hydraulic pump.

## 5. OWNER ASSISTANCE

### • ELECTRICAL SYSTEM

A 12 volt lead acid propylene battery is used to activate the engine through the starter motor and the electrical system comprising horn, head lamp.

Side indicator lamps, plough lamp, brake light, gauge lamp, hazard lamp. Generator or alternator, fuse box also from part of the electrical system.

#### WARNING

- When operating the tractor at high speed, do not attempt to make sharp turns by using the brakes. This may result in overturning of the tractor causing serious injury or death.

We at TYM CO., LTD and your TYM dealer / distributor wants you to be completely satisfied with your investment.

Normally any problems with your equipment will be handled by your dealer / distributor's service departments, however, misunderstanding can occur. If you feel that your problem has not been handled to your satisfaction, we suggest the following.

Contact the owner or general manager of the dealership, explain the problem, and request assistance. When additional assistance is needed, your dealer / distributor has direct access to your office.

If you cannot obtain satisfaction by doing this, contact the TYM CO., LTD. office and provide them with;


- Your name, address and telephone number
- Model and tractor serial number
- Dealer / distributor name & address
- Machine purchase date and hours used
- Nature of problem

Before contacting TYM CO., LTD office, be aware that your problem will likely to be resolved in the dealership using the dealer's / distributor's facilities, equipment and personnel. So it is important that your initial contact be with the dealer / distributor.



### 6. ROPS (Roll Over Protective Structure)

#### ► ROPS



TYM tractors are equipped with a frame for the protection of operators. In the case of cab tractors the frame is incorporated in the cab structure. The objective of the frame or cab structure is to protect the operator in the event of a roll over and they are designed to support the entire weight of the tractor in that event.

Each TYM ROPS frame or cab structure is designed and has been tested to meet industry and or government standards. Included in these tests were all mounting bases and bolts or other fasteners.

On some models the ROPS frame has a fold down feature, which can be used to enter low buildings etc.

Take care when lowering the upper section of the ROPS frame and take extreme care while driving the tractor with the ROPS frame lowered.

Do not wear the seat belt with the ROPS lowered and please remember that the fold down facility is for special circumstances only and must not be lowered for general use.

#### DANGER

- For ROPS frames to be effective and protect the operator, the seat belt provided must be worn in order to keep operators within the ROPS protected area in the event of a roll over. Failure to use the seat belt can still cause serious injury or death.

#### ► USE OF TRACTOR WITH ROPS LOWERED CAN CAUSE FATAL INJURIES

As the ROPS frame or cab together with the seat belt was designed to meet certain standards, they must be maintained in good order and condition. To achieve this objective, both the structure and the seat belt should be inspected on a regular basis. (Every time the tractor is serviced)

In the event that the seat belt is damaged or frayed, it should be replaced and in the event that the ROPS frame or any part of the mounting structure is damaged or cracked, the faulty component must be replaced with a new unit.

Such a unit must meet all of the test criteria of the original unit. Fitment of an inferior item or items affects the certification of the entire ROPS structure and the effectiveness of the structure in the event of an accident. Drilling or welding of the ROPS is forbidden.

► **DAMAGE OF ROPS**

If the tractor has rolled over or the ROPS has damaged (such as striking an overhead object during transport), it must be replaced to provide the original protection.

After an accident, check for damages to

- **ROPS**
- **SEAT**
- **SEAT BELT & SEAT MOUNTINGS**

Before you operate a tractor, replace all damaged parts.

 **WARNING**

- Do not weld, drill or straighten the ROPS.
- Always wear your seat belt if the tractor is equipped with ROPS.

 **WARNING**

- If the ROPS is removed or replaced, make certain that the proper hardware is used to replace the ROPS and the recommended torque values are applied to the attaching bolts.

 **WARNING**

- Never attach chains, ropes to the ROPS for pulling purposes. This will cause the tractor to tip backwards. Always pull from the tractor drawbar.
- Be careful when driving through door opening or under low overhead objects. Make sure there is sufficient overhead clearance for the ROPS fatal injuries.

**CABIN TYPE**




A



### 7. SEAT ADJUSTMENT

#### ► SEAT SLIDING



To select seat position, move adjusting lever and slide seat closer to or away from dash panel and controls.

#### DANGER

- Check whether the seat properly locked in its position before driving the tractor.
- Always use the seat belt when the ROPS is installed.
- Do not use the seat belt if a foldable ROPS is down or there is no ROPS. Check the seat belt regularly and replace if frayed or damaged.

Before operating a tractor it is important to adjust the seat to the most comfortable position & check whether it is properly locked in its position.


#### IMPORTANT

- Do not use solvents to clean the seat. Use warm water with a little detergent added.

#### WARNING

- Do not put a hand between the seat and the slides when adjusting the seat position. You can get injured unexpectedly.

#### ► SEAT BACK ANGLE, CUSHION STRENGTH ADJUSTMENT




#### ● SEAT BACK ANGLE ADJUSTMENT

The seat can be fold down or up using seat back angle adjustment lever.

#### ● CUSHION STRENGTH ADJUSTMENT

The seat cushion can be adjusted according to the weight of the driver.

Turning the cushion adjustment lever counterclockwise to the 50kg position makes the cushion lighter, and turning the lever clockwise to the 130kg position makes the cushion heavier.



# **SAFETY PRECATIONS**

- 1. SAFETY INSTRUCTIONS . . . . . B - 2
- 2. SAFE OPERATION OF TRACTOR . . . . . B - 15
- 3. DOs & DON'Ts . . . . . B - 22
- 4. SAFETY DECALS . . . . . B - 24
- 5. UNIVERSAL SYMBOLS . . . . . B - 29

# ! SAFETY PRECAUTIONS

## 1. SAFETY INSTRUCTIONS

### ► ENSURE SAFETY INFORMATION



This symbol means

**‘Attention! Your safety is involved.’**

The message that follows the symbol contains important information about safety.

Carefully read the message.

### ► SIGNAL SIGNS



A signal signs

**‘DANGER, WARNING or CAUTION’**


are used with safety alert symbol.

DANGER identifies the most serious hazards.

Safety symbols with signal signs ‘DANGER or WARNING’ are typically near specific hazards.

General precautions are listed on CAUTION safety signs.

### ► READ SAFETY INSTRUCTION



Carefully read all safety instructions given in this manual for your safety. Tempering with any of the safety devices can cause serious injuries or death.

Keep all safety signs in good condition. Replace missing or damaged safety signs.

Keep your tractor in proper condition and do not allow any unauthorized modifications to be carried out on the tractor, which may impair the function / safety and affect tractor life.

**► PROTECT CHILDREN**

Keep children and others away from the tractor while operating.

Before you reverse

- Look behind tractor for children.
- Do not let children to ride on tractor or any implement.

**► USE OF ROPS AND SEAT BELT**

The Roll Over Protective Structure (ROPS) has been certified to industry and / or government standard.

Any damage or alternation to the ROPS, mounting hardware or seat belt voids the certification and will reduce or eliminate protection for the operator in the event of a roll-over.

The ROPS, mounting hardware and seat belt should be checked after the first 100 hours of use and every 500 hours thereafter for any evidence of damage, wear or cracks.

In the event of damage or alternation, the ROPS must be replaced prior to further operation of the tractor.


The seat belt must be worn during machine operation when the machine is equipped with a certified ROPS.

Failure to do so will reduce or eliminate protection for the operator in the event of a roll-over.

**B**

## SAFETY PRECAUTIONS

### ► PRECAUTION TO AVOID TIPPING




Do not drive where the tractor could slip or tip.  
Stay alert for holes and rocks in the terrain and other hidden hazards.

Slow down before you make a sharp turn.

Driving forward out of a ditch or mired condition could cause tractor to tip over backward.

Back out of these situations if possible.

### ► PARK TRACTOR SAFELY



Before working on the tractor:

- Lower all equipment to the ground.
- Stop the engine and remove the key.

### ► KEEP RIDERS OFF TRACTOR



Do not allow riders on the tractor.

Riders on tractor are subject to injury such as being stuck by foreign objects and being thrown off of the tractor.

**▶ HANDLE FUEL SAFELY AVOIDING FIRES**

Handle fuel with care.  
It is highly flammable.

Do not refuel the tractor while smoking or near open flame or sparks.

Always stop engine before refueling tractor.

Always keep your tractor clean of accumulated grease and debris.  
Always clean up spilled fuel.


**▶ STAY CLEAR OF ROTATING SHAFTS**

Entanglement in rotating shaft can cause serious injury or death.

Keep PTO shield in place at all the time.

Wear fitting clothing.

Stop the engine and be sure PTO drive is stopped before making adjustments, connections or cleaning out of PTO driven equipment.

**▶ ALWAYS USE SAFETY LIGHTS AND DEVICES**

Use of hazard warning lights and turn signals are recommended when towing equipment on public roads unless prohibited by state or local regulations.

Use slow moving vehicle (SMV) sign when driving on public road during both day & night time unless prohibited by law.



## SAFETY PRECAUTIONS

### ► PRACTICE SAFE MAINTENANCE



Understand service procedure before doing work.

- Keep the surrounding area of the tractor clean and dry.
- Do not attempt to service tractor when it is in motion.
- Keep body and equipment to the ground.
- Stop the engine.
- Remove the key.
- Allow tractor to cool before any work repair is caused on it.
- Securely support any tractor elements that must be raised for service work.

- Keep all parts in good condition and properly installed.
- Replace worn or broken parts.
- Replace damaged / missing decals.
- Remove any build-up of grease or oil from the tractor.
- Disconnect battery ground cable ⊖ before making adjustments on electrical systems or welding on tractor.

### ► AVOID HIGH PRESSURE FLUIDS




Escaping fluid under high pressure can penetrate the skin causing serious injury. Keep hands and body away from pin holes and nozzle which eject fluids under high pressure.

If any fluid is injected into the skin, consult your doctor immediately.

**▶ PREVENT BATTERY EXPLOSION**

Keep sparks, lighted matches and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the poles.

**▶ PREVENT ACID BURNS**

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, cause holes in clothing and cause blindness if found entry into eyes.

For adequate safety always:


- Fill batteries in a well-ventilated area.
- Wear eye protection and acid proof hand gloves.
- Avoid breathing direct fumes when electrolyte is added.
- Do not add water to electrolyte as it may splash off causing severe burns.

If you spill acid on yourself:

1. Flush your skin or eyes with water for 10 ~ 15 minutes.
2. Get medical attention immediately.

## SAFETY PRECAUTIONS


### ▶ BATTERY DISCONNECTION



When working with your tractor electrical components, you must first disconnect the battery cables.

To ensure that there are no accidents from sparks, you must first disconnect the negative battery cable.


### ▶ SERVICE TRACTOR SAFELY



Do not wear a necktie, scarf or loose clothing when you work near moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.

### ▶ WORK IN VENTILATED AREA



Do not start the tractor in an enclosed building unless the doors & windows are open for proper ventilation as tractor fumes can cause sickness or death.

If it is necessary to run an engine in an enclosed area remove the exhaust fumes by connecting exhaust pipe extension.



## ► TRACTOR RUNAWAY

Engine start with transmission engaged can cause tractor to runaway resulting serious injury to the people standing nearby the tractor.

For additional safety keep the pull to stop knob (Fuel shut off control) in fully pulled out position.

Transmission in neutral position, foot brake engaged and PTO lever in disengaged position while attending to Safety Starter Switch or any other work on tractor.

## ► SAFETY START


Safety Starter switch for starting is provided on transmission main or sub shift lever and in PTO shift lever.

The tractor can be started only if main or sub shift lever is in neutral position.

### CAUTION

- Safety Starter Switch is to be replaced after every 2,000 hours/4 years, whichever is earlier.

## ► EMERGENCY EXITS




If exit from the cab side doors is blocked (following an accident or vehicle overturn) the alternative safety exits are indicated by decals.

The possible safety exits are:


- Rear window hatch (All tractors)
- Front window (for versions with openable front window).

## SAFETY PRECAUTIONS


### ► SAFETY PRECAUTIONS WHEN USING LOADER



Never let anyone get in the loader and use the loader as a workbench. Otherwise, it may lead to a fatal injury or even death.



Do not stand under the lifted loader or get close to it. Also, lower the loader arm onto the ground before leaving the tractor. Otherwise, it may lead to a fatal injury or even death.




When attaching or detaching the loader, fix all parts which are connected to the bucket and boom. The bucket or boom can be accidentally dropped down, leading to an injury or even death.




Be careful of objects falling from loader.

**IMPORTANT**

- ROPS (Roll Over Protective Structure), sun canopy or cabin are not a FOPS (Falling Object Protective Structure). It never can protect the riders against falling objects. Avoid driving the vehicle into a dangerous area such as falling rocks zone.



Do not allow loader arms or attachment to contact electrical power lines. Electrocution will cause serious injury or death.



Never carry a big object with the loader unless a proper implement is attached.

Keep a carried object low during driving.

Otherwise, it may lead to an injury or even death.



## SAFETY PRECAUTIONS

### ► TOWING SAFELY

For the maximum towable loads, refer to the 'TIRE AND MASS' section in appendix chapter if available.

Maintain a suitable speed taking into account the weight of the trailed load and the gradient, remembering that braking distances will be greater than with just the tractor.

Trailed loads with or without brakes that are too heavy for the tractor or that towed at too high speed may cause the operator to lose control of the tractor.

Always take into consideration the total weight of the implements and their loads.



### CAUTION

- Before you leave the driving seat when a trailer is hitched to the tractor, remember to put all the controls in neutral, apply the parking brake, switch off the engine, engage first gear (if the tractor has a mechanical transmission) and remove the key from the starter switch.  
If the tractor is not parked on level ground, always place chocks under the wheels of both the tractor and the trailer.

### ► TRANSPORT TRACTOR BY TRUCK

Always secure the tractor to the loader bed with chains.

Before transporting the tractor on a low loader or on a railway wagon, make sure that the engine hood, doors, openable roof (if present) and windows are all closed and securely fastened.

Never tow the tractor at speeds in excess of 10km/h.

An operator must stay in the operator position to steer and brake the tractor.



### ► FALLING OBJECT PROTECTIVE STRUCTURE (FOPS)

The term FOPS refers to structure installed on the tractor intended to reduce the risk to the operator of injury from falling objects during normal use of the vehicle

#### IMPORTANT

- This tractor is not equipped with a FOPS.
- The energy level of drop test is 1365J.

### ► OPERATOR PROTECTIVE STRUCTURE (OPS)

The term OPS refers to a protective structure installed on a tractor in order to minimize risk of operator injury caused by objects penetrating into the operator position area.

#### DANGER

- This tractor is not equipped with an OPS. If work must be performed in areas subject to the risk of the penetration of objects into the operator position, consult your dealer before starting work so that the tractor can be equipped with an appropriate protective structure.

### ► USE OF HAZARDOUS SUBSTANCES

European standard EN 15695-1 is applicable to the cabs of agricultural or forestry tractors and self-propelled sprayers.

The purpose of the standard is to limit the exposure of the operator (driver) to hazardous substances when applying plant protection products and liquid fertilizers.

In accordance with the stipulations of EN 15695-1 regarding cab classification, measurement of the internal positive pressure differential must be carried out in conformance with ISO 14269-5:

- The engine operating at nominal speed;
- The maximum quantity of air drawn from outside the cab (recirculation closed);
- Fan set to maximum speed.



## SAFETY PRECAUTIONS

The following terms and definitions are applied:

- **Hazardous substances:** substances such as dust, vapours and aerosols, with the exception of fumigants which can be dispersed during the application of plant protection products and liquid fertilizers, which may have a harmful effect on the operator.
- **Dust** general term identifying solid air-borne particles, finely divided and accumulated.
- **Aerosol:** suspension of solid, liquid or solid and liquid particulate in a gaseous medium with a negligible fall rate (generally less than 0.25 ms<sup>-1</sup>)
- **Vapour:** gaseous phase of a substance whose liquid or solid state is stable at 20°C and 1 bar (absolute).  
This cab, even when closed, does not protect against the inhalation of hazardous substances.

If the manufacturer's instructions for using these substances recommend personal protective equipment, wear the equipment even in the cab.

Cabs are classified as follows:

- **Category 1:** the cab does not provide protection against hazardous substances.
- **Category 2:** the cab provides protection exclusively from dust.
- **Category 3:** the cab provides protection from dust and aerosol.
- **Category 4:** the cab provides protection from dust, aerosol and chemical vapours.

The classification category, as stipulated by ISO 14269-5, of the cab installed on this range of tractors is given below:

- the engine operating at nominal speed
- the maximum quantity of air drawn from outside the cab (recirculation closed) with fan at maximum speed.

Table 2 – Technical data

	CATEGORY
<b>ROPS / CABIN</b> Hazardous substances protection category	<b>1</b>

### DANGER

- Use all the personal protective equipment suitable for the tasks in hand and relative substances, in compliance with the requirements of statutory legislation in your country.



## 2. SAFE OPERATION OF YOUR TRACTOR

The manufacturer of your tractor has made every effort to make it as safe as is humanly possible.

Beyond this point it is the responsibility of the operator to avoid accidents and we ask that you read and implement our suggestions for your safety.

Ensure that only trained and competent operators use this tractor and ensure that they are fully conversant with the machine and aware of all its control and safety features.

Operators should not operate the tractor or associated machinery while tired or untrained.

To avoid accidents please ensure that the operator wears clothing which will not get entangled in the moving parts of the tractor or machine and protect him or her from the elements.

When spraying or using chemicals, please ensure that clothing and protective equipment is worn which prevents respiratory or skin problems.

For full details consult the manufacturer of the chemicals.

To avoid lengthy exposure to noise ensure that ear protection is worn.

If adjustment to the tractor or machinery need to be made ensure the tractor or machine are turned off beforehand.

Use of certified Roll Over Protection Structure (ROPS) is a must while operating a tractor.

Use of seat belt is a must while operating a tractor.

In summary, ensure at all times that the safety of the operator and any other worker is paramount.

Ensure no one is between the tractor and a towed vehicle (trailer or implement).



## SAFETY PRECAUTIONS

---

### ► SAFETY TIPS DURING MAINTENANCE

1. At least on a daily basis check all oil levels. Water level in the radiator and electrolyte level in the battery and perform services according to the service schedule.
  2. Ensure tire pressure are even and the correct pressure for the job being done is maintained.
  3. Check to ensure that the all controls and preventative mechanisms of the tractor and implement work correctly and effectively.
  4. Ensure that an adequate set of the correct tools is available for maintenance and minor repairs.
  5. Ensure that all service work and repairs are carried out on a flat area with a concrete or similar floor. Do not carry out service work on a tractor until it is switched off, and the parking brake applied and wheels choked.
  6. Do not work under raised implements.
  7. When changing wheels or tires ensure that a suitable wheel stand is placed under the axle prior to removing the wheel and the wheels are chocked.
  8. Where guards or shields need to be removed to perform a service or repair, ensure that the guard or shield is correctly reinstalled before starting the tractor.
  9. Never refuel near a naked flame or with an overheated engine.
  10. The cooling system operates under pressure, take care when removing the radiator cap on a hot engine to prevent being scalded by steam or hot water. Do not add water in the radiator when the engine is hot. Add water to the radiator only after the engine cools down completely.
  11. To prevent fires keep the tractor including the engine clean and free from inflammable material and well away from fuels and other inflammable material.
- Ensure to turn off Engine before refueling.



## ► MOUNTING AND DEMOUNTING IMPLEMENTS

1. Ensure that all mounting and removal of implements is done on safe flat ground. Ensure no one is between the tractor and implement and do not get under the implement to avoid accidental injuries.
2. After mounting the implement, ensure that all sway chains are correctly adjusted and, where PTO shafts are used that the shaft is fitted and secured correctly.
3. Where heavy implements are used, ensure that the combination is well balanced or use proper ballast to achieve balance.
4. Before leaving the tractor at any time, lower the implement, stop the PTO shaft where applicable, set the parking brake and switch off the engine.
5. While operating the implements with the PTO keep all bystanders away from any moving parts and do not attempt to make adjustments while the machine is running.
6. Only the driver should ride on the tractor with the ROPS frame fitted and with the seat belt properly fastened.
7. Where young children are present, particular care should be taken and the tractor should not be moved until the whereabouts of all children is known.
8. Only trained operators should operate the tractor and so taking care to ensure that other workers are not injured. In particular they should take care during dusty operations, which will reduce visibility substantially.
9. Never start the tractor unless the transmission is out of gear, the operator is in the seat and all round safety has been checked.
10. Only operate the tractor seated in the driver's seat and never turn or brake suddenly at high speed as this can cause a roll-over and serious injury or death.
11. When traveling on a public road ensure that the tractor and driver both meet all laws relating to safety and licensing. When traveling with wide implements use red flags on the extremities and observe all legal including escort requirements.
12. When operating under adverse conditions, hilly terrain or on bad ground adjust the speed of the tractor to suit the conditions, safety



## SAFETY PRECAUTIONS

comes first.

Never drive down-hill at high speed or with the transmission in neutral. Use of the braking capacity of the engine as well as the service brakes. Do not try to change gear going up or down a steep slope, select the correct gear before starting.

13. Take care when traveling uphill with a heavy implement to ensure that it does not overbalance and tip up the front end.
14. Never remove or modify the seat belt.
15. Never remove, modify or repair the ROPS frame.

Please remember that a little bit of extra care can prevent serious injury or death and avoid damage to your tractor.

### ► THE FOLLOWING PRECAUTIONS ARE SUGGESTED TO HELP PREVENT ACCIDENTS

A careful operator is the best operator. Most accidents can be avoided by observing certain precautions.

Read and take the following precautions before operating the tractor to prevent accidents.

Tractor should be operated only by those who are responsible and properly trained to do so.

#### <THE TRACTOR>

1. Read the operator's manual carefully before using the tractor. Lack of operating knowledge can lead to accidents.
2. Use an approved rollover bar and seat belt for safe operation. Overturning of a tractor without a rollover bar can result in death or injury.
3. Do not remove ROPS (Roll Over Protective Structure). Always use the seat belt.
4. Fiberglass canopy does not give any

protection.

5. To prevent falls, keep steps and platform clear of mud and oil.
6. Do not permit anyone but the operator to ride on the tractor. There is no safety place for extra riders.
7. Replace all missing, illegible or damaged safety signs.
8. Keep safety signs clean of dirt and grease.

#### <SERVICING THE TRACTOR>

1. keep the tractor in good operating condition for your safety. An improperly maintained tractor can be hazardous.
2. Stop the engine before performing any service on the tractor.
3. The cooling system operates under pressure, which is controlled by the radiator cap. It is dangerous to remove the cap while the system is hot.



First turn the cap slowly to stop and allow the pressure to escape before removing the cap entirely.

4. Do not smoke while the refueling the tractor.  
Keep away any type of open flame.
5. The fuel in the injection system is under high pressure and can penetrate the skin.  
Unqualified persons should not remove or attempt to adjust a pump, injector, nozzle or any part of the fuel injection system.  
Failure to follow these instructions can result in serious injury.
6. Keep open flame away from battery or cold weather starting aids to prevent fire or explosions.
7. Do not modify or alter or permit anyone else to modify or alter this tractor or any of its components or any tractor functions.

### <OPERATING THE TRACTOR>

1. Before starting the tractor apply the parking brake, place the PTO (Power Take Off) lever in the “OFF” position, the position control levers in the downward position, the hydraulic control levers in the neutral position (If fitted) and the transmission in neutral.
2. Do not start the engine or controls while standing beside the tractor. Always sit on the tractor seat when the engine or operating controls.
3. Safety start:  
In order to prevent the accidental starting of the tractor, a safety switch has been provided. The starting system of the tractor is connected through this switch. On some models shuttle shifter lever and PTO button should also be in neutral position for completing the starting circuit. Do not bypass the safety switch. Consult your TYM tractor

distributor / dealer if safety switch malfunctions.

4. Avoid accidental contact with the gear shifter lever while the engine is running.  
Unexpected tractor movement can result from such contact.
5. Do not get off or climb the tractor while it is in motion.
6. Shut off the engine, remove the key and apply the parking brake before getting off the tractor.
7. Do not operate the tractor in an enclosed building without adequate ventilation.  
Exhaust fumes can cause death.
8. Do not park the tractor on a steep slope.
9. If power steering or Engine seizes to operate, stop the tractor immediately.
10. Pull only from the swinging draw bar or the lower link drawbar in the down position. Use only a drawbar pin that locks in place.



## SAFETY PRECAUTIONS

Pulling from the tractor rear axle carriers or any point above the rear axle may cause the tractor's front end to lift.

11. If the front end of the tractor tends to rise when heavy implements are attached to the three point linkage, install front end or front wheel weights.  
Do not operate the tractor with a light front end.
12. Always use hydraulic position control lever when attaching equipment / implement and when transporting equipment.  
Be sure that the hydraulic couplers are properly mounted and will disconnect safely in case of accidental detachment of implement.
13. Do not leave equipment/implement in the raised position.
14. Use the flasher / turn signal lights and Slow Moving Vehicle (SMV) signs when driving on public roads

during both day and night time, unless prohibited by law.

15. Dim tractor lights when meeting a vehicle at night.  
Be sure the lights are adjusted to prevent the blinding on the eyes of coming vehicle operator.
16. Emergency stopping instruction; If tractor fails to stop even after application of brakes.  
Pull the knob of fuel shut off control rod.

### <DRIVING THE TRACTOR>

1. Watch where you are going especially at row ends, on roads, around trees and low hanging obstacles.
2. To avoid upsets, drive the tractor with care and at speeds compatible with safety, especially when operating over rough ground, crossing ditches or slopes, and when turning at corners.

3. Lock the tractor brake pedals together when transporting on roads to provide proper wheel braking.
4. Keep the tractor in the same gear when going downhill as used when going uphill.  
Do not coast or free wheel down hills.
5. Any towed vehicle and/or trailer whose total weight exceeds that of the towing tractor, must be equipped with its own brakes for safe operation.
6. When the tractor is stuck or tires are frozen to the ground, back out to prevent upset.
7. Always check overhead clearance, especially when transporting the tractor.



### <OPERATING THE PTO>

1. When operating PTO driven equipment, shut off the engine and wait until the PTO stops before getting off the tractor and disconnecting the equipment.
2. Do not wear loose clothing when operating the power take-off or near rotating equipment.
3. When operating stationery PTO driven equipment, always apply the tractor parking brake and block the rear wheels from front and rear side.
4. To avoid injury, always move down flip part of PTO.  
Do not clean, adjust or service PTO driven equipment when the tractor engine is running.
5. Make sure the PTO master shield is installed at all times and always replace the PTO shield cap when the PTO is not in use.

### <DIESEL FUEL>

1. Keep the equipment clean and properly maintained.
2. Under no circumstances should gasoline, alcohol or blended fuels be added to diesel fire or explosive hazard.  
Such blends are more explosive than pure gasoline. In a closed container, such as a fuel tank. DO NOT USE THESE BLENDS.
3. Never remove the fuel cap or refuel the tractor with the engine running.
4. Do not smoke while refueling or when standing near fuel.
5. Maintain control of the fuel filler pipe when filling the tank.
6. Do not fill the fuel tank to capacity. Allow room for expansion.
7. Wipe up spilled fuel immediately.
8. Always tighten the fuel cap securely.
9. If the original fuel tank cap is lost, replace it with genuine cap.  
A none approved cap may not be safe.

10. Do not drive equipment near open fire.
11. Never use fuel for cleaning purpose.
12. Arrange fuel purchases so that winter grade fuel are not held over and used in the spring.
13. Use ultra-low sulfur fuel only.

#### IMPORTANT

- It is suggested that after repairs if any of the safety decals or signs are peeled or defaced, the same may be replaced immediately in interest of your safety.



## SAFETY PRECAUTIONS

### 3. DOs & DON'Ts

#### ► DOs – FOR BETTER PERFORMANCE

- DO** - Ensure that safety shields are in place and in good condition.
- DO** - Read all operating instructions before commencing to operate tractor.
- DO** - Carry out all maintenance tasks without fail.
- DO** - Keep the air cleaner clean.
- DO** - Ensure that the correct grade of lubricating oils is used and that they are replenished and changed at the recommended intervals.
- DO** - Fit new sealing rings when the filter elements are changed.
- DO** - Watch the oil pressure gauge or warning light and investigate any abnormality immediately.
- DO** - Keep the radiator filled with clean water and in cold weather use anti-freeze mixture.  
Drain the system only in an emergency and fill before starting the engine.
- DO** - Ensure that the transmission is in neutral before starting the engine.
- DO** - Keep all fuel in clean storage and use a filter when filling the tank.
- DO** - Attend to minor adjustments and repairs as soon as necessity is apparent.
- DO** - Allow the engine to cool before removing the radiator filler cap and adding water, remove the radiator cap slowly.
- DO** - Shift into low gear when driving down steep hills.
- DO** - Latch the brake pedals together when driving on a highway.
- DO** - Keep draft control lever fully down when not in use.

**► DON'Ts – FOR SAFE OPERATION**

**DON'T** - Run the engine with the air cleaner disconnected.

**DON'T** - Start the tractor in an enclosed building unless the doors and windows are open for proper ventilation.

**DON'T** - Operate the tractor or engine while lubricating or cleaning.

**DON'T** - Allow the tractor to run out of diesel fuel otherwise it will be necessary to vent the system.

**DON'T** - Temper the fuel injection pump, If seal is broken the warranty becomes void.

**DON'T** - Allow the engine to run idle for a long period.

**DON'T** - Run the engine if it is not firing on all cylinders.

**DON'T** - Ride the brake.  
This will result in excessive wear of the brake lining.

**DON'T** - Use the independent brakes for making turns on the highway or at high speeds.

**DON'T** - Refuel the tractor with the engine running.

**DON'T** - Mount or dismount from the right side of the tractor.

**DON'T** - Temper the hydraulic control levers' upper limit stops.

**DON'T** - Use draft control lever for lifting of implements.

**DON'T** - Start the engine with the PTO engaged.

**DON'T** - Use the throttle lever while driving on roads.

**DON'T** - Move the hydraulic levers rearward.



## SAFETY PRECAUTIONS

### 4. SAFETY DECALS

#### ► GENERAL INFORMATION OF DECALS

- In order to work with the machine safely, safety decals should be placed on the machine.
- Make sure to read and follow the following directions.

#### ■ **KEEP THE WARNING LABELS CLEAN AND NOT DAMAGED AT ALL TIMES.**

If a decal on the machine is dirty, wash it with soapy water and wipe it off with a soft cloth. Never use solution such as thinner or acetone because these can erase characters or pictures.

#### ■ **IF WASHED WITH HIGH PRESSURED WATER, A DECAL MAY BE PEELED OFF.**

Do not apply high pressured water directly onto decals.

#### ■ **IF A SAFETY DECAL IS DAMAGED OR LOST, ORDER A NEW ONE IMMEDIATELY AND PLACE IT ON THE MACHINE.**

When putting a new decal, wipe off the place to post the decal thoroughly and wait till it is dried. Then post the decal.  
Each decal has a part number on the bottom.

#### ■ **WHEN REPLACING A PART ATTACHED WITH A DECAL WITH A NEW PART, REPLACE THE DECAL AS WELL.**



## ► DECALS ON CHASSIS

**WARNING**

Do not use the sub shift lever at "H" position when driving backward.

1200-910-001-0

**WARNING**

Work in ventilated Area.

1200-910-003-0

**WARNING**

Operator's manual

1200-910-022-0

**WARNING**

Always fasten Your seat belt.

1200-910-018-0

**WARNING**

Never use the diff-lock at high speed or on the road as this can cause rollover and injury.

1200-910-006-0

**Caution for Operating Turbocharged Engine**

- Do not increase engine RPM rapidly after the ignition.
- Do not turn off the engine when the engine is running on the high RPM; make sure the engine is idling for a sufficient time before turning off.
- Idle the engine for 2-3 minutes before starting the tractor when the tractor has completely stopped or it has engine oil or filter changed or it is in the freeze weather. (Not following the instruction above, it may cause damage to the turbocharger.)

**Caution for Operating DeSOx**

- When DeSOx temp is on, DeSOx has to be done while the tractor is completely stopped (Neutral Position).
- Do not stop the engine while DeSOx is in progress.
- Make sure enough idling time after the completion of DeSOx.
- Not following the instruction above, it may cause damage to the engine (Please refer to the operator's manual for details).

1768-910-917-0

**WARNING**

Do not use the accelerator lever except working on the field.

1200-910-021-0

**WARNING**

1. Stay clear of raised boom and bucket  
2. Joystick button must always be locked for safety when not using implement.

LOCK UNLOCK

100-910-001-0

**WARNING**

Always set the knob to lock when

- Traveling on the road
- Replacing blades on an implement
- Making adjustment to an implement

Sudden dropping of an implement can cause serious injury or death.

100-910-010-0

**WARNING**

Do not remove radiator cap while engine is hot. Hot steam will injure you.

1200-910-015-0

**CAUTION**

Do not touch while the system is hot. It cause serious burns

1200-910-024-0

POSITION OF FUSE & RELAY

- FUSE HEATING TUBE SOA
- FUSE FUEL HEATER SOA
- FUSE CABIN SOA
- FUSE MAIN SOA
- RELAY UREA HEATING TUBE
- RELAY UREA HEATING TUBE
- RELAY ECU
- RELAY ECU
- RELAY FUEL HEATER
- RELAY STARTER
- ECU
- ECU



# SAFETY PRECAUTIONS



**⚠ DANGER**



Periodic ventilation should be made to avoid suffocation while heating or air conditioning is used. Sleeping in the cab is prohibited. 1200-910-011-0

**⚠ WARNING**



Always apply the park brake when parking. Failure to do so can cause accidents and damages. 1200-910-002-0

**⚠ DANGER**



Do not ride except operator. 1200-910-016-0



**⚠ WARNING**



Do not refuel the tractor while smoking or near naked flame or sparks. Always stop engine before refueling tractors. 1200-910-005-0

**EPA REGULATION**

**USE ULTRA LOW SULFUR FUEL ONLY**



 <p>Tilt Handle</p>	<p><b>WARNING</b></p>  <p>Do not adjust the tilt handle when traveling.</p> <p>1768-910-008-0</p>
--	--



	<p><b>WARNING</b></p> <p>Attach implements and trailers to the tractor only using the prescribed drawbar or hitch.</p> <p>1200-910-014-0</p>
---	--

	<p><b>DANGER</b></p> <p>Rotating driveline contact can cause death. KEEP AWAY!</p> <p>Keep all drive line. Tractor and equipment shields in place during operation.</p> <p>1200-910-013-0</p>
---	---

	<p><b>WARNING</b></p>  <p>1768-910-022-0</p>
---	---

B

# ! SAFETY PRECAUTIONS

## 5. UNIVERSAL SYMBOLS

Some of the universal symbols have been shown below with an indication of their meaning.

DESCRIPTION	SYMBOL	DESCRIPTION	SYMBOL	DESCRIPTION	SYMBOL
ENGINE SPEED (REV/MIN X 100)		PRESSURED, OPEN SLOWLY		CORROSIVE SUBSTANCE	
HOURES, RECORDED		CONTINUOUS VARIABLE		SLOW OR MINIMUM SETTING	
ENGINE COOLANT TEMPERATURE		DANGER, WARNING, CAUTION		FAST OR MAXIMUM SETTING	
FUEL LEVEL		HAZARD WARNING		TRANSMISSION OIL PRESSURE	
ENGINE STOP CONTROL		NEUTRAL		TURN SIGNAL	
LIGHTS		FAN		TRANSMISSION OIL TEMPERATURE	
HORN		POWER TAKE OFF ENGAGED		PARKING BRAKE	
ENGINE OIL PRESSURE		POWER TAKE OFF DISENGAGED		WORKING LAMP	
AIR FILTER CONTAMINATED		RAISE LIFT ARM		DIFFERENTIAL LOCK	
BATTERY CHARGE		LOWER LIFT ARM		REFER TO OPERATOR'S MANUAL	



# TRACTOR INSTRUMENTS

1. SWITCHES AND INSTRUMENT PANEL . . . . . C - 2
2. CONTROLS . . . . . C - 18
3. THREE POINT LINKAGE . . . . . C - 35
4. CABIN . . . . . C - 39



## 1. SWITCHES AND INSTRUMENT PANEL

### ► FIGURE OF DASHBOARD



► **MAIN SWITCH**




It is used to start and stop the engine.

- **OFF position**  
Initial position. The ignition key can be inserted and removed in this position.  
If this switch is turned to this "OFF" position during driving, the engine stops and the key can be removed from the switch.
- **ON position**  
Engine running position.  
The electric circuit is activated.
- **START position**  
Engine starting position.  
When releasing the key, the switch is returned to the "ON" position.

 **IMPORTANT**

- To start the engine, set the PTO switch in the OFF position, the shuttle shift lever in the neutral position and depress the clutch pedal fully in advance.

► **DeSOx SWITCH AND OPERATING DESCRIPTION**



1. **When the Forced DeSOx switch is set in the neutral position, the DeSOx operation is automatically performed for every 200 hours.**  
While DeSOx operation is automatically performed,  on the instrument panel is illuminated.
2. **Forced DeSOx operation OFF**  
When the DeSOx operation is performed, the exhaust gas temperature rises to a high level. Therefore, set forced DeSOx switch to OFF position when working in a greenhouse or an enclosed area

C



or work to be performed needs high power.

Then  on the instrument cluster is illuminated.

### 3. Forced DeSOx operation ON

This position can be used only while indicator blinks.

The following prerequisite conditions should be satisfied to use this switch position:

- Prerequisite condition 1: Warm up (rev up) the engine for 3 minutes to increase the coolant temperature.
- Prerequisite condition 2: Idle the engine for 15 seconds.
- Prerequisite condition 3: Apply the parking brake. Then, the parking brake indicator on the instrument cluster comes on.
- Prerequisite condition 4: Press and hold the Forced DeSOx operation switch for 2.5 seconds and release it.

When the forced DeSOx operation is activated, indicator on the instrument cluster comes on and the engine speed automatically increases. This process is performed for approx. 20 minutes.

If the pedal position is higher than 5% during the service DeSOx, it will be stopped for safety reason.

- If the driver press the service DeSOx switch at normal machine condition (Pedal position > 5%), the service DeSOx is not started.
- If the driver want to stop the service DeSOx, just increased the pedal position over 5%.
- If the driver want to operate the machine during the service DeSOx, it could be possible to work with torque derate and less than pedal position 5%.
- The fault and torque derate will be cleared after completion of the forced DeSOx.

### CAUTION

- Operating DeSOx
  1. When DeSOx lamp is on, DeSOx has to be done while the tractor is completely stopped. (Neutral Position)
  2. Do not stop the engine while DeSOx is in progress.
  3. Make sure enough idling time after the completion of DeSOx.
  4. Not following the instruction above, it may cause damage to the engine. (Please refer to the operator's manual for details)

NO.	STATUS	DESCRIPTION	SYMBOL	INDICATOR
1	DeSOx operation (Passive or Forced) < Automatic DeSOx operation (Automatically activated for every 200 hours)>	Automatic DeSOx operation activated or Exhaust gas temp. > 600 degrees		ON
2	Forced DeSOx operation required	Forced DeSOx operation		ON
		DeSOx needed or Forced DeSOx switch pressed		BLINKING
3	DeSOx operation inhibited by pressing switch	DeSOx inhibit		ON

► HAZARD FLASHER



Press the hazard flasher switch in emergency to warn other vehicles in order to prevent an accident. The hazard flasher is operated regardless of the position of the main switch. Also, the turn signal lamp function is disabled while the hazard flasher is activated.


- Position A – OFF
- Position B - The hazard flasher is activated and the turn signal indicators on the instrument cluster blink as well.

 IMPORTANT

- Use it only when necessary as it can discharge the battery and obstruct other drivers' view.



## ▶ SHUTTLE SHIFT LEVER



This device is used to select the driving direction between the forward and reverse directions.

- Set it in the neutral position unless driving.
- With the lever 1 pulled up slightly (Feeling a slight spring tension), push it forward (A) to select forward driving and pull it backward (B) to select reverse driving.


### WARNING

- Before starting the engine, set the shuttle shift lever in the neutral position and depress the clutch pedal fully to avoid an accident by abrupt starting off.

### IMPORTANT


- The shuttle shift lever consists of electric components, so forcible operation can damage the lever.
- Poor fuel quality can damage the engine. Make sure to use only the specified genuine diesel fuel.
- Use fuel for winter season in winter to enhance engine starting performance.

## ▶ COLUMN SWITCH LEVER



### (1) Lamp selection lever

- This lever is to operate the headlamps, horn and turn signal lamps.
- Position lamp  
Turn the lever (A) from the position (1) to (2).
- Horn  
Press the tip of the lever in the arrow direction.




**<Headlamp>**

- Low beam  
Turn the lever (A) from the position (2) to (3).
- High beam  
Push the lever down with the high beam activated.

**⚠ WARNING**

- The high beam can obstruct the view of other drivers coming in the opposite direction on a road, leading to an unexpected accident.



**(2) Turn signal lamp operation**

The turn signal lamps can be operated with the main switch in the "ON" position regardless of the position of the column lever.


- Left turn - Pull the lever 1 in the direction "B"
- Right turn - Pull the lever 1 in the direction "A"

**⚠ CAUTION**

- This lever is not automatically returned to the neutral position. Therefore, set it back to the neutral position after turn.



## ► INSTRUMENT PANEL



- |   |  |   |
|---|--|---|
| 1. TACHO METER                                    | 2. HOURMETER   | 3. SPEEDO METER                                   |
| 4. ERROR DISPLAY                                  | 5. FUEL GAUGE  | 6. COOLANT TEMPERATURE GAUGE                      |
| 7. LEFT TURN SIGNAL INDICATOR                     | 8. RIGHT TURN SIGNAL INDICATOR   | 9. HIGH GEAR INDICATOR                            |
| 10. LOW GEAR INDICATOR                            | 11. CHARGE WARNING LAMP  | 12. DIFFERENTIAL LOCK INDICATOR                   |
| 13. PARKING INDICATOR                             | 14. REVERSE DRIVING/LIFTING INDICATOR  | 15. TURNING-LIFTING INDICATOR                     |
| 16. PREHEAT INDICATOR                             | 17. HIGH BEAM INDICATOR  | 18. DeSOx ACTIVATION INDICATOR                    |
| 19. DeSOx DEACTIVATION INDICATOR                  | 20. ENGINE WARNING LAMP  | 21. PTO INDICATOR                                 |
| 22. FUEL LEVEL WARNING LAMP                       | 23. TRAILER BRAKE INDICATOR  | 24. 1 <sup>ST</sup> TRAILER TURN SIGNAL INDICATOR |
| 25. 2 <sup>ND</sup> TRAILER TURN SIGNAL INDICATOR | 26. 4WD INDICATOR  | 27. QUICK TURN INDICATOR                          |
| 28. ENGINE OIL PRESSRE WARNING LAMP               | 29. HYDRAULIC CLUTCH LOW PRESSRE WARNING LAMP/STRAINER CLOGGING WARNING LAMP | 30. UREA LEVEL LAMP                               |
| 30. AIR CLEANER CLOGGING WARNING LAMP             | 31. UREA LEVEL LAMP  | 32. UREA LEVEL WARNING LAMP                       |
| 33. SCR WARNING LMAP                              | 34. AUTOMATIC DeSOx ACTIVATED OR EXHAUST GAS WARNING LAMP                    |   |
| 35. WATER IN FUEL WARNING LAMP                    |  |   |



### (1) Tachometer

It indicates the engine RPM (Rotation Per Minute), The green arrow indicates the engine speed at the standard 540 RPM speed of the PTO.

#### IMPORTANT

- The engine can be damaged if increasing its speed too fast.



### (2) Hourmeter

It indicates the total time of use.

- Black digits - Whole number for hours of use
- Red digit - Decimal place for hours of use


There are 6 digits for the hour meter. The last digit indicates one tenth hours. Example) The time of use illustrated above is 234 hours and 30 minutes.



### (3) Speedometer

It indicates the driving speed (km/h) of the tractor.

C



#### (4) Error display

This indicates malfunction of the tractor. When an error code is shown on the display, stop driving and perform repair or service accordingly.




#### (5) Fuel gauge

This indicates the amount of fuel while the main switch is in the "ON" position.

- F: Full
- E: Empty

#### IMPORTANT

- Poor fuel quality can damage the engine. Make sure to use only the specified genuine diesel fuel.
- Use fuel for winter season in winter to enhance engine starting performance.



#### (6) Coolant temperature gauge

This indicates the temperature of coolant while the main switch is in the "ON" position.

- C: Cold
- H: Hot

If the needle is in the red "H" zone during driving, the coolant is overheated. In this case, stop driving and take any necessary action according to the troubleshooting instructions.



**(7) Tractor left turn signal indicator**

This indicates the turn signal lamp operation with the column lever. This blinks along with left turn signal lamp.

**(8) Tractor right turn signal indicator**


This indicates the turn signal lamp operation with the column lever. This blinks along with right turn signal lamp.

**(9) High gear indicator**

This comes on when the high speed gear is selected (2nd gear power shift).

**(10) Low gear indicator**

This comes on when the low speed gear is selected (2nd gear power shift).



**(11) Charge warning lamp**


This comes on when the main switch is turned to the "ON" position and goes off as soon as the engine is started.

**(12) Differential lock indicator**

This comes on while the differential lock is in use.

**⚠ IMPORTANT**

- If the charge warning lamp comes on while driving, the battery is not properly charged. Therefore, turn off any unnecessary electrical devices and have your vehicle checked by your workshop immediately.




**(13) Parking indicator**

This comes on when the parking brake is applied.

**(14) Reverse driving-lifting Indicator**

This comes on when the reverse driving-lifting function is selected with its button.




### (15) Turning-lifting indicator

This comes on when the turning lifting function is selected with its button.


### (16) Preheat indicator

This comes on while the engine preheating function is activated.



### (17) Headlamp indicator

This comes on with the high beam activated and goes off with the low beam activated.



### (18) DeSOx activation indicator

This lamp illuminates when the DeSOx switch is pressed. It blinks when the DeSOx process is required.

### (19) DeSOx deactivation indicator

This lamp illuminates when the DeSOx inhibit switch is pressed.



ENGINE WARNING LAMP

**(20) Engine warning lamp**

It comes on when the engine is malfunctioning.



PTO INDICATOR



FUEL LEVEL WARNING LAMP

**(21) PTO indicator**

This indicates the operating condition of the PTO shaft.

**(22) Fuel level warning lamp**

This comes on when the fuel amount in the fuel tank is not sufficient.




TRAILER BRAKE INDICATOR

**(23) Trailer brake indicator**

This comes on when the brake is operated with the tractor brake during driving.

C



### (24) 1st trailer turn signal indicator


This comes on when the trailer is connected and the tractor turn signal lamp is activated.

### (25) 2nd trailer turn signal indicator

This comes on when the trailer is connected and the tractor turn signal lamp is activated.

### WARNING

- If lowering an implement or releasing the driving clutch pedal with the PTO indicator blinking, the rotating PTO shaft can cause a dangerous situation. Make sure that no one comes within the turning radius of the tractor.




### (26) 4WD indicator

This comes on when the 4WD is activated.

### (27) Quick turn indicator (Optional)

This comes on while the quick turn function is in use.



### (28) Engine oil pressure warning lamp

The lamp comes on when an engine oil lubrication problem occurs. Stop the engine and check the engine oil level or get help from a workshop.

### IMPORTANT

- When the oil pressure warning lamp comes on, this indicates malfunction of the lubrication system. Check the engine oil immediately and have your vehicle serviced by your workshop as necessary.

**(29) Hydraulic clutch low pressure warning lamp/strainer clogging warning lamp**

This comes on when the pressure of the hydraulic clutch is excessively low or the clutch oil level is low. Also, it is illuminated when the strainer is clogged by foreign materials. If this comes on during driving, contact your dealer. This lamp may come on for a while after the engine is started. If it keeps illuminated, contact your dealer.

**IMPORTANT**

- When the oil pressure warning lamp comes on, this indicates malfunction of the hydraulic system. Check the oil immediately and have your vehicle serviced by your workshop as necessary.
- If driving with the warning lamp illuminated, the transmission can be damaged.



**(30) Air cleaner filter contamination warning lamp**

This comes on when the air cleaner is clogged by foreign materials. When this comes on, open the cover and clean the inside of the cleaner. Also, blow air through the filter in the opposite direction of air flow to clean it or replace the filter with a new one.

**IMPORTANT**

- If keeping driving with this warning lamp illuminated, the engine power can be dropped.



**(31) UREA level lamp**

This indicates the amount of urea while the main switch is in the "ON" position.

- 4 green lamps ON: 75% - 100% of urea in tank
- 3 green lamps ON: 50% - 75% of urea in tank
- 2 green lamps ON: 25% - 50% of urea in tank
- 1 green lamp ON: 25% of urea in tank
- Yellow lamp ON: 10% of urea in tank
- Red lamp ON: 5% of urea in tank
- Red lamp blinking: 2.5% of urea in tank



UREA LEVEL WARNING LAMP



SCR WARNING LAMP

### (32) Urea level warning lamp

This comes on when the urea level in the tank is below 25%.

### (33) SCR (Selective Catalytic Reduction) warning lamp

SCR(Selective Catalytic Reduction) related part malfunctions. In this case, contact your workshop.

### (34) Automatic DeSOx activated or Exhaust gas warning lamp

Automatic DeSOx operation activated or Exhaust gas temp. 600 degrees.

### (35) water in fuel warning lamp

When a certain amount of water is collected in the fuel filter, this lamp comes on. In this case, stop the engine immediately and drain water from the fuel filter.

NO.	ITEM	WARNING LEVELS (US)	VALUES	TIME	ENGINE	UREA LEVEL WARNING LAMP	SCR WARNING LAMP
1	UREA LEVEL	WARNING	< 25%		WARNING	ON	
		LEVEL 1	< 10%		REDUCING TORQUE TO 25%	ON	
		LEVEL 2	< 5%		REDUCING TORQUE TO 50% AND RPM TO 60%	BLINKING SLOWLY	
		FINAL	< 2.5%		LOW IDLE	BLINKING FAST	
2		WARNING	ERROR		WARNING		ON
		LEVEL 1	30 MIN. OR MORE	IMMEDIATELY	REDUCING TORQUE TO 25%		ON
		LEVEL 2	2 HOURS OR MORE (2.5 HOURS)	7 MIN. OR MORE	REDUCING TORQUE TO 50% AND RPM TO 60%		BLINKING SLOWLY
		FINAL	1 HOUR OR MORE (3.5 HOURS)	18 MIN. OR MORE (25 MIN)	LOW IDLE		BLINKING FAST


**C**



## 2. CONTROLS



► CLUTCH PEDAL




Depressing the clutch pedal disengages the clutch.

With the clutch pedal depressed, move the main, range or shuttle shift lever into the desired position and release the pedal.

Then, the clutch is engaged.

► BRAKE PEDALS




The brake is to stop the machine forcibly.

Unlike general automobiles, this tractor is equipped with left and right brake pedals.

Each brake pedal brakes only one rear wheel on the corresponding side.

 CAUTION

- At a low speed, the rotating force of the axle acts greatly, so depressing the brake pedal strongly with the clutch pedal released cannot brake the vehicle. To stop the vehicle, disengage the clutch first and depress the brake pedals.



There is an engaging hook for connecting the left and right brake pedals.

- Driving on road - Engage (Both brake pedals operated together)
- Working in field - Disengage (One side brake pedal operated)

 WARNING

- Connect the left and right brake pedals while driving on a road, loading/unloading the tractor or driving into/out of a field to avoid rollover and collision.
- Inspect the brake pedals periodically so that they can be operated simultaneously without any problem.


## ▶ THROTTLE PEDAL



It has the same function to the throttle lever to control the engine speed.

- Depressing - The engine speed is increased.
- Releasing - The engine idles.

## ▶ PARKING BRAKE LEVER



Pull the parking brake lever upward to apply the parking brake. To release the parking brake, press the button at the tip of the lever.

### ⚠ CAUTION

- The tractor does not move with buzzer sound when operating the shuttle shift lever with the parking brake applied. In this case, release the parking brake with shuttle shift lever in the neutral position.

### ⚠ IMPORTANT

- Make sure to park tractor, stop engine and apply parking brake. Also, chock wheels if parking on a steep slope.

## ▶ MAIN SHIFT LEVER



The lever can be shifted among 4 speed positions.

There are two buttons next to the lever for the SP model.

< Power shift button >

The transmission can be shifted to the high speed or low speed gear with the power shift button pressed even when the clutch pedal is released.

- Button 1: High speed
- Button 2: Low speed

**(7) Range shift lever**

Shifting operation can be performed in combination with the shuttle shift lever, main shift lever and range shift lever.

Speed Range:

- 32 forward driving speeds and
- 32 reverse driving speeds

 **WARNING**

- Do not drive backward with the range shift lever placed in the H position as driving backward with fast speed can lead to a dangerous situation

 **IMPORTANT**

- To operate the range shift lever, depress the clutch pedal and wait till the tractor is completely stopped.  
If operating the lever during driving, it can damage the gears.
- The main shift lever can be moved as long as the clutch pedal is fully depressed during driving as it is a synchromesh type.
- When shifting the range shift lever to the H position or the main shift lever to the 3<sup>rd</sup> or 4<sup>th</sup> gear position during starting off or with the driving speed of 3.8 km/h or slower, the warning buzzer sounds and the shuttle shift operation is disabled.


 **IMPORTANT**

- Cautions for position C of range shift lever
- When the range shift lever is in the position C, rotating force of the axle acts greatly. Therefore, misuse can lead to damage of gears and other parts. Be careful with the followings:  
Types of work appropriate for creep speed gear
  - Cultivating deeply at short intervals with rotavator
  - Cultivating with rotavator, but hard to work at standard speed due to firm ground
  - Transplanting
  - Loading/Unloading
  - Working with trencher
- Types of work inappropriate for creep speed gear
  - Escaping from wet field
  - Draft (trailer) work
  - Working with front loader
  - Construction work
  - Working with front snow plow

C




## ▶ JOYSTICK LEVER OPERATING DIRECTION



This lever is used to control a loader (when equipped).

< Joystick lever operating direction >




Boom down    Boom up    Bucket up    Bucket down

### ❏ IMPORTANT

- Do not operate the boom cylinder and bucket cylinder simultaneously. Their simultaneous operation can lead to a lack of hydraulic oil, resulting in abnormal operation of the loader.

## ▶ JOYSTICK LEVER SAFETY DEVICE




There is a switch to lock the operation of the joystick lever. Pushing it to the left locks the lever while pushing it to the right unlocks the lever.

### ❏ IMPORTANT

- A implement can be dropped suddenly by operating the joystick lever accidentally. Therefore, lock it in position with its lock switch when it is not in use.

## ▶ LOADER VALVE AND JOYSTICK LEVER



The loader valve is installed under the step on the right side and the joystick lever is installed on the right from the driver's seat in the cabin for easy installation and operation of a loader.

### ⚠ WARNING

- Abnormal operation of a loader can lead to an accident. Therefore, when connecting the hydraulic pipes, set the valve connection according to the operating directions specified on the label attached to the joystick lever.

## ▶ THROTTLE LEVER



Like the throttle pedal, it is used to control the engine speed. This lever is operated with a hand and can be used to fix the engine speed to a certain level.

- Pushing : High speed
- Pulling : Low speed

### WARNING

- Avoid using it on a road as it can cause an accident by high speed driving.


## ▶ EXTERNAL HYDRAULIC CONTROL LEVER



When using an attachment for an implement (rotavator, hydraulic plow, etc.), connect its hose to the proper port among the port A, B and C according to its use.

- Lever 1 operation → Hydraulic oil applied to valve port 1 (Forced Return Type (applied to detent types))
- Lever 2 operation → Hydraulic oil applied to valve port 2
- Lever 3 operation → Hydraulic oil applied to valve port 3

## ▶ REMOTE HYDRAULIC VALVE COUPLER



1) how to connect coupler

1. Clean the couplers on the tractor and implement thoroughly.
2. Remove the dust cover from the tractor side. Then, fit the male coupler on the implement side while moving its external ring backward slightly.
3. Pull the male coupler on the implement side backward slightly to check its firm engagement.

C



### 2) how to disconnect coupler

1. Lower the implement on the ground to release pressure in the hydraulic hose. Stop the engine and operate the remote hydraulic lever for 2 to 3 times to remove any residual pressure in the hose. Disconnect the male coupler on the implement side while pulling the external ring of the coupler on the tractor side backward slightly.
2. Wipe oil and dust from the coupler and plug the dust cover.

### WARNING

- To prevent a burn and skin damage, make sure to stop the engine before connecting or disconnecting the coupler.
- Do not use your hands to check for oil leakage.

### ► PTO SHIFT LEVER




This lever is used to select the PTO speed.

its operation is coupled with the PTO (AUTO) switch.

### < PTO speed selection >

1. Stop the PTO.
2. With the PTO switch set in the OFF position, place the PTO lever into the desired speed position.  
(540 RPM, 750 RPM or 1000 RPM)



ELECTRONIC LIFT SYSTEM CONTROL PANEL


TCU SWITCH PANEL

PTO SWITCH

C



## ▶ PTO BUTTON



This is the PTO ON/OFF switch.

To use the independent PTO, pull up the knob.

- PTO activation - Turning it clockwise with pressing.
- PTO deactivation - Pressing or turning it counter-clockwise.

### WARNING

- Keep the button pushed in when the PTO is not in use in order to prevent an accident by the suddenly rotating PTO shaft.

## ▶ ELECTRONIC LIFT SYSTEM CONTROL PANEL

< Overview >

The electronically controlled lift system can provide various functions through simple switch operations, unlike the mechanical type, to enhance the driver's convenience and efficiency. This system has the following three control modes and each mode can be selected and mixed with their corresponding control knobs for optimum working condition.


- Position control
- Draft control
- Floating function

### WARNING

- Before operating the control unit, make sure that the knobs are adjusted to the desired positions.
- Never stop and leave the tractor with an implement lifted.
- The control unit is equipped with self-diagnosis function which triggers the alarm for any found fault in the system.


### CAUTION

- To prevent damage to electronic components, keep the following instructions when arc welding the tractor equipped with the electronic lift or an attached implement.
  - Separate an implement or part to be welded from the tractor if possible.
  - Disconnect the two battery cables.
  - Set the welding machine's ground clamp as close as possible to the point to be welded.
  - Remove the control unit first if the welding spot is within 1m from the unit.
  - Make sure that the cable is not close to or over any electric or electronic lead while welding.



< Electronic lift control >

1. Control lever (Lifting/Lowering)
2. Attenuation function ON button
3. Attenuation function ON indicator
4. Diagnosis indicator
5. Lift arm upper position limit control knob
6. Lift arm lowering speed control knob
7. Position/Draft sensitivity control knob
8. Working depth control knob
9. Arm lifting indicator
10. Arm lowering indicator
11. Arm lifting indicator



< Operation of interior controls >

1. Control lever

A. Lift lift arm

B. Stop

C. Lower lift arm

D. Lower to ground rapidly

When releasing the knob in this position, the knob is automatically returned to the position B.

2. Lift arm upper position limit control knob

- Turning it clockwise decreases the upper position limit of the lift arm.

- Turning it counterclockwise increases the upper position limit of the lift arm.

3. Lift arm lowering speed control knob

- Turning the knob toward the rabbit symbol increases the lift arm lowering speed.

- Turning the knob toward the tortoise symbol decreases the lift arm lowering speed.

4. Position/Draft control knob

- Turning it counterclockwise sets the draft control with higher priority.

- Turning it clockwise sets the position control with higher priority.

5. Working depth control knob

- Turning it clockwise increases the height of the lift arm.


- Turning it counterclockwise decreases the height of the lift arm.

## ▶ EXTERNAL LIFTING/LOWERING SWITCH



<External lifting/lowering switch operation>

These switches are installed to the left and right mudguards on the back of the vehicle and can be used to lift and lower an implement.



### < Operation >

Keep the following instructions for safe and correct use of the electronic lift:

1. When starting the engine, the indicator (4) comes on to inform the driver that the interior lift controls cannot be used for now for safety reason.

The exterior lifting/lowering switches (12) on the rear mudguards are available to use. the knob (5) and place the lift control lever (1) into the lifting position (A). Then, the indicator (4) goes off and the indicator (10) comes on.

### < Hydraulic lock operation >

1. Before operation, set the lever (1) to the lifting position (A) to lift the implement.
2. Turn the knob (6) counterclockwise to its end.
3. Push the lock button (11) forward to fix the lever in the lifting position. Keep other settings as before locking the lever.


### < Swing attenuation device >

This device is to protect the hydraulic system against impact from an implement when driving the tractor equipped with an implement.

To activate this device, set the lever (1) to the lifting position (A) and press the switch (2). Then, the indicator (3) comes on to inform its activation.

### CAUTION

- If the control lever (1) is already in the lifting position (A), set it to the Stop position first and move it to the lifting position (A).
- When driving the tractor with an implement attached, press the swing attenuation button to protect the hydraulic system against impact from an swinging implement.



## < Operation >

There are three control modes for an 3P implement:

- Position control
- Draft control
- Floating mode

### • Draft control

1. Turning the position/draft sensitivity control knob (7) counterclockwise increases the priority of the draft control. Turning it counter-clockwise to its end activates only the draft control.

2. Place the lever (1) into the lowering position (C) and then use the knob (8) to set the desired working depth. Turning it counterclockwise lowers an implement while turning it clockwise lifts an implement. To lift or lower an implement at once, use the lever (1). When the working depth in a field with an implement changes greatly, turn the position/draft sensitivity control knob (7) clockwise slowly to narrow the gap.


### • Position control

1. Turning the position/draft sensitivity control knob (7) clockwise increases the priority of the position control. Turning it clockwise to its end activates only the position control.
2. Lower the implement with the lever (1) and adjust the lowering speed with the knob (6). Then, set the desired working depth with the knob (8). When lowering or lifting an implement, use the lever (1) only to keep the settings.

### • Floating mode


Turn the knob (8) counterclockwise completely to allow swinging motion of the arm in order to use the lift in the floating mode.

► TCU SWITCH PANEL



1. Rear wheel differential lock button
2. 4WD (automatic) button
3. 4WD button
4. Reverse driving-lifting button
5. Turning-lifting button
6. PTO automatic operation button

C



## < Differential lock >

The differential lock is designed to lock the differential system in order to rotate the left and right wheels at the same speed. Use this device when the rear wheels slip or one wheel spins with no traction.

### 1. Manual mode

It is possible to control the differential manually by a driver for easier operation.

Pressing the button once turns on the lamp and activates the manual mode.

Pressing it once again turns off the lamp and deactivates the manual mode.


- Examples of useful conditions of differential lock
1. One wheel slips or tractor cannot be driven forward when moving into/out of a field.
  2. A wheel slips during work requiring traction, such as plowing.
  3. One wheel is stuck into a soft field and can't escape.

## CAUTION

- Never use the differential lock when driving on a road. A collision or rollover can occur.
- Make sure to deactivate the function before turning. Otherwise, it can lead to an injury or accident.

## IMPORTANT

- When using the differential lock, run the engine at a low speed.
- The differential lock is disengaged when depressing the brake pedal.
- The differential lock is disengaged when the vehicle speed exceeds 15km/h.



## < 4WD >

The 4WD function can be operated in any gear during driving (forward/reverse driving).

### 1. Automatic mode

The 4WD function is automatically deactivated when the angle of one of the front wheels is over 20 degrees or the vehicle speed exceeds 15 km/h.

Pressing the button once turns on the lamp and activates the automatic mode. Pressing it once again turns off the lamp and deactivates the automatic mode.

## 2. Manual mode

It is possible to control the 4WD function manually by a driver for easier operation.

Pressing the button once turns on the lamp and activates the manual mode. Pressing it once again turns off the lamp and deactivates the manual mode.


- Examples of useful conditions of 4WD

The 4WD can be useful under the following conditions:

1. When cultivating in a field
2. When traction is required on a slope, in a wet field or for towing a trailer
3. When working in a wet or sandy field
4. When cultivating on firm soil with a rotavator to prevent the tractor from being pushed forward
5. When driving into/out of a field or going over a field bank

### IMPORTANT

- Avoid using the 4WD on a road or hard soil. The tires can be worn excessively.
- If stopping the engine while the 4WD is engaged, starting the engine again automatically engages the 4WD.




6. Reverse driving-lifting  
This function is to lift implement automatically when vehicle is driven backward. Pressing the button once turns on lamp and activates reverse driving-lifting function. Pressing it once again turns off lamp and deactivates function.
7. Turning-lifting  
This function is to lift implement automatically when vehicle is being turned. Pressing the button once turns on the lamp and activates the turning- lifting function. Pressing it once again turns off the lamp and deactivates the function.



## IMPORTANT

- Do not activate the reverse driving-lifting function or turning-lifting function while driving on a road.



PTO ROTATION


### 8. PTO (AUTO)

The PTO shaft is automatically stopped for safety when the implement is lifted to the preset height. Also, the PTO shaft is automatically stopped when depressing the clutch pedal. Pressing the button once turns on the lamp and activates the automatic PTO function. Pressing it once again turns off the lamp and deactivates the function.

## CAUTION

- The PTO shaft is not stopped when depressing the driving clutch pedal while the PTO (AUTO) button is pressed OFF.  
Set the PTO button into the OFF position when working on hard soil with a rotavator. Otherwise, the tractor may spring up, leading to a dangerous situation.

3. THREE POINT LINKAGE



C



## ▶ TOP LINK ADJUSTMENT



1. The angle of an implement can be adjusted by extending or retracting the top link.
2. After adjustment, fix the adjusting handle so that the link does not become loose.
3. The mounting location of the top link is different by the type of an implement. The 1st and 2<sup>nd</sup> holes from the top are generally used.

## ▶ LIFT ROD ADJUSTMENT




Turn the handle clockwise to extend the rod and turn it counterclockwise to retract the rod.

Adjust the length of the lift rod to keep the implement in balance.

1. To adjust the height, lift the adjusting handle. After adjustment, lower the handle and fix it.
2. Adjust the length according to the type of an implement.

## ▶ LOWER LINK CONNECTING HOLE



- C: for rotary tiller and other types of implements
- D: for rotary tiller

▶ **ADJUSTING LINK**



The adjusting link can be adjusted to relieve vibration and shock.

▶ **LOWER LINK**



An implement can be attached to this. The installation type is Category II. (Implement mounting hole diameter: 25.4 mm)

 **IMPORTANT**

- When no implement is attached, fix the lower links with the left and right check links so that they do not touch the rear wheels.
- Engage the top link with the hook.

▶ **TOWING HITCH**



Install only an implement applicable to this tractor.


 **WARNING**

- Make sure to use the towing hitch for towing to avoid rollover. Never tow anything by connecting a rope to the top link bracket, axle or safety frame.
- When using a rotavator that draws power through the universal joint from the PTO shaft, remove the towing hitch from the tractor. Otherwise, the universal joint hits and damages the towing hitch, leading to an accident.

C




## ► DRAWBAR ADJUSTMENT



Adjust the drawbar as follows:

1. Use the fixing pin (1) to prevent any lateral sway.
2. To adjust the distance between the PTO and drawbar, move the fixing pin to another hole in the drawbar.

## ► PTO SHAFT CAP



When the PTO shaft is not in use, apply grease and place its cap to it.

### CAUTION

- It is dangerous to use an implement at a high speed if it is designed to be operated at a low speed.
- Before using an implement, make sure to read its owner's manual.


### DANGER

- If caught by the PTO shaft, a severe injury or even death can occur.
- Stay out of the PTO shaft while it is rotating.
- When the PTO shaft is not in use, fit a cap to it.
- Also, never remove the PTO safety cover.

4. CABIN



C



▶ **DOOR LEVER**



Press the button on the lever to open the door from outside.  
Push the lever down to open the door from inside.

▶ **REAR WINDOW LEVER**



To open the window, push the lever on the center of the rear window in the cabin gently.  
To close the window, hold the lever and pull it gently.

 **IMPORTANT**

- The rear window may not be able to be opened depending on the type of an attached implement. Make sure to check it in advance.
- Avoid driving at a high speed or driving on a bumpy road with the window open. The window may be broken.

▶ **SIDE WINDOW HANDLE**



Hold the handle and push it outward to open the window.

 **CAUTION**

- When opening and closing the side window, be careful not to get caught by the handle edge or in the window.

C



## ▶ WORKING LAMP



There are 4 work lamps installed on the front and back of the cabin roof. They can be operated by the buttons on the panel on the right side in the cabin.

### **WARNING**

- Do not turn on the work lamps at nighttime while driving on a road. They can obstruct other drivers' view.

## ▶ OUTSIDE REARVIEW MIRROR



To avoid a collision with an obstacle outside, adjust their positions to suit the driver.



The switches for the windshield/rear wipers/washers and work lamps are located on the right side from the driver's seat.

- (6) Windshield/Rear wiper switches
  - Only the wiper is operated when turned ON.
  - The wiper is not operated when turned OFF.
- (7) Windshield/Rear washer switches  
When pressing this switch, washer fluid is sprayed and the wiper is operated.
- (8) Front/Rear work lamp switch  
Pressing this switch turns on the LED and work lamps for work at nighttime. Pressing it again turns off work lamps.

► HANGER



Clothes and small bag can be hung on it.

► 12V POWER SOCKET (OPTIONAL)



It is possible to use 12v 120w accessory by connecting it to the power socket.

 **WARNING**

- Never place any part of your body, such as your filter, or a conductive object into the power socket. You can get a shock or a fire can break out.
- Use it only while the engine is running. After use, remove the plug from the socket. If using it with the engine stopped or plugging an electric device to it for an extended period of time, the battery can be discharged.
- Close its cover when it is not in use.

► SUN VISOR



Use this to protect the driver's view from sunlight.

Pull down the handle of the sun visor and release it at the desired position. Then, it is automatically fixed to that point.

To retract it, press the rewind button on the right top of it.

C

► **INSIDE OF CABIN**




► **SUN ROOF**




Use it to ventilate the cabin.  
 To open the sunroof, turn the lever clockwise and push it up.  
 To close the sunroof, hold the lever, pull it down and turn it counterclockwise.

► **FAN SPEED CONTROL DIAL**



The fan speed can be adjusted in four steps for the air conditioner and heater.



< Heater >

- how to use
  1. To use the heater, turn the temperature control dial clockwise.
  2. Operate the fan speed control dial (1st to 4th step).
  3. Warm air can be provided when the engine coolant is sufficiently warm.
  
- Cautions for using heater
  1. Make sure to use antifreeze for the winter season in winter. General engine antifreeze can freeze in winter.
  2. Check the heater hose before use.


C



### < Air conditioner >

- how to use
- 1. To use the A/C, turn the temperature control dial counterclockwise.
- 2. Operate the fan speed control dial (1st to 4th step).
- 3. Turn the air conditioner dial to the "ON" position.

- Cautions for using air conditioner
- 1. This air conditioner uses new refrigerant, R134-a. Make sure to check the refrigerant type before adding it.
- 2. When adding refrigerant, add compressor oil as well.
- 3. When repair or adjustment is needed, contact your workshop.
- 4. Do not disconnect the A/C hose or pipe connection or apply excessive force to it.



### WARNING

- Ventilate the cabin periodically when working in the cabin with the A/C or heater ON for an extended period of time to avoid suffocation.
- Never sleep in the cabin.
- If refrigerant gets on your skin, you can get burnt severely. Therefore, any system service should be performed by qualified technicians.

**+** IMPORTANT

- If operating the A/C without refrigerant, the compressor is not sufficiently lubricated, resulting in mechanical failure. Make sure to check the refrigerant level frequently.
- Avoid using the A/C for an extended period of time with the tractor stopped. The compressor can be overloaded.
- If refrigerant gets on your skin, you can get burnt severely. Therefore, any system service should be performed by qualified technicians.
- For superior cooling performance, keep the engine speed over 1,000 RPM.

▶ **AUDIO SYSTEM**



Refer to the manufacture's user manual.

▶ **FRESH AIR SUCTION FILTER**



When using the A/C or heater in the fresh air mode, fresh air is drawn into the cabin through the filters installed on the left and right sides of the roof.

C



## ⚠ WARNING

- If the cabin needs to be ventilated, select the fresh air mode. Then, fresh air is drawn into the cabin from outside through the filter.
- The air suction filter can be clogged by dirt and foreign materials during work.
- Clean it periodically and replace it when necessary.

## ⚠ IMPORTANT

- The fresh air suction filter can remove dust in air, but not chemicals in pesticides. Misuse of such chemicals can harm driver and others' health. Make sure to follow dust inhalation safety instruction, personal hygiene guidance and other precautions from the manufacturers of the tractor and chemicals.

## ▶ FRESH AIR MODE AND RECIRCULATION MODE




There are two circulation modes for the A/C and heater operation: fresh air mode and recirculation mode.

<Fresh air/recirculation mode selection>

The fresh air mode or recirculation mode can be selected by opening or closing four vents on the roof in the cabin.

- Open - Recirculation mode
- Closed - Fresh air mode

## ▶ DRIVER'S SEAT



1. **Seat sliding**  
The seat position can be slid forward or backward with the lever in front of it pushed to the left. After adjustment, make sure that the seat is firmly secured.
2. **Seat cushion adjustment**  
Turn the lever on the front of the seat to adjust the cushion properly according to the driver's weight.
3. **Seatback reclining**  
The angle of the seatback can be adjusted by pulling up the angle control lever.

4. Seat belt


Before driving, adjust the length of the seat belt properly and fit its tongue into the receptacle until it clicks.

5. Headrest

The headrest position can be adjusted to fit to the driver. Its height can be adjusted by pressing the lock on the seatback and headrest mounting section.

 **WARNING**


- Make sure to fasten your seat belt to protect yourself in case of rollover or collision.
- Never adjust the seat during driving.



6. Seat height adjustment

Pull up or push down the height adjustment lever to adjust the seat height in 4 steps. Suitability of each position is as follows:

- A. Standard position
- B. When working while observing the back
- C. When working while observing the front area near the vehicle.
- D. When the seat is too low for the driver



- Lifting seat
  - In the position (a) with the seat empty, push down the height adjustment lever. Then, the front section of the seat is lifted, setting the seat into the position (b).

C



- When trying to adjust the seat from the position (b) to the position (c) or vice versa, the seat is returned to the position (d).

- Lowering seat

- With the height adjustment lever lifted in the position (d), press the rear section of the seat to lower the rear section, setting the seat in the position (b).

- With the height adjustment lever pushed down in the position (d), press the front section of the seat to lower the front section, setting the seat in the position (c).

- When trying to adjust the seat from the position (b) to the position (c) or vice versa, the seat is returned to the position (a).

### ► TILT LEVER



The angle of the steering wheel can be adjusted to suit the driver.

The tilt lever is installed under the steering wheel. Use this lever (1) to adjust the position. To fix the position, push down the lever.

- Pushing down the lever (1) fixes the steering wheel into the position.
- Pulling up the lever (1) enables the steering wheel to be adjusted.

### ⚠ WARNING

- Adjust the position of the steering only when the tractor is stationary. Adjusting it during driving can cause an accident.

### ► SECONDARY SEAT

The secondary seat is only for an instructor or inspector.


### ⚠ DANGER

- No one, except the driver, should ride the tractor while moving or driving on a road.
- When anyone, other than the driver, rides the tractor, he/she cannot be protected in the cabin in case of rollover, leading to a severe accident and injury.

► **INTAKE/EXHAUST SYSTEM**

<General Information>

- general Information  
Our new engine applies all applicable advanced technologies to satisfy the tightened restrictions exhaust, while also improving fuel efficiency and reducing exhaust gas. The exhaust reduction system features a diesel oxidation catalyst (DOC) device to reduce soot particles and an exhaust gas recirculation (EGR) system and (SCR) system to reduce the nitrogen oxide (NOx) from the engine exhaust gas.
1. The EGR system is a device that recirculates exhaust gas to reduce NOx emissions.
  2. The muffler has a diesel oxidation catalyst (DOC) device in it.  
- This DOC device reduces HC and CO emissions in exhaust gas with reduction catalysts.
  3. SCR is used to reduce NOx in emissions by spraying urea into the SCR catalyst.



- |                                 |                                |
|---------------------------------|--------------------------------|
| (1) Diesel Engine               | (9) AdBlue® Temperature Sensor |
| (2) Dosing Module with Injector | (10) AdBlue® Level Sensor      |
| (3) Temperature Sensor          | (11) Dosing Control Unit       |
| (4) SCR Catalyst                | (12) Actuators                 |
| (5) Temperature Sensor          | (13) Sensors                   |
| (6) Filter                      | (14) Engine CAN                |
| (7) AdBlue® Supply Module       | (15) Diagnostic CAN            |
| (8) AdBlue® Tank                |                                |

Note) SCR; Selective Catalytic Reduction





## **OPERATION**


1. START & STOP OF ENGINE . . . . . D - 2
2. OPERATING TRACTOR . . . . . D - 4
3. OPERATION OF PTO . . . . . D - 7
4. IMPLEMENTS . . . . . D - 9
5. TOWING THE TRACTOR . . . . . D - 10
6. CHECKS DURING DRIVING . . . . . D - 12
7. WORK PROCEDURES . . . . . D - 14
8. OPERATION TIPS . . . . . D - 20



## OPERATION

### 1. START & STOP OF ENGINE

#### ▶ HOW TO START ENGINE



1. Make sure that there is no obstacle around the tractor.
2. Seat on driver's seat and confirm that parking brake is applied.
3. Check that each shift lever and PTO switch are in the neutral position.
4. Push down clutch to activate the safety-starting switch.
5. Insert the key into key switch and turn it to 「ON」 position.  
Check that warning lights are working and come off.
6. Turn the key switch to the 「START」 position.  
When engine is started, release the switch.
7. Ensure that all warning lamps go off.


#### ⚠ IMPORTANT

- Never turn the key to 「start」 position while engine is running as this can cause serious damage to starter and engine flywheel.
- Avoiding running the start motor over 10 second.  
It consumes lots of current.
- If engine cannot be started within 10 second, wait for 30 second and try it again.
- Especially in cold weather, always allow the tractor to idle for a while to warm up and build up for a while to warm up and build up sufficient oil pressure to ensure normal operating temperature for longer engine life.

#### ⚠ WARNING

- Never start engine by connecting start motor terminal or safety switch directly.  
The tractor may move suddenly and cause an accident.

#### ▶ PRINCIPLE OF AUTO PREHEATING SYSTEM




When key switch is in 「ON」 position, engine is automatically preheated as necessary.

Glow lamp is on as well.

As soon as preheating operation is completed, the lamp also goes off.

Engine can be started while the preheating operation is in progress.

▶ **STOPPING ENGINE**



1. Idle engine before stopping it.
2. Turn the key switch to 「OFF」 position.
3. Remove key from the switch.

**IMPORTANT**

- After long or heavy work allow the engine to idle for 5-10 minutes and turn the key off.

▶ **ENGINE IDLING**

After starting engine, idle engine for 5 ~ 10 minute so that oil is delivered to each part of engine.

**WARNING**

- Make sure to apply the parking brake while idling the engine.
- Never idle the engine in a poorly ventilated area. It can cause carbon monoxide poisoning by emissions.

**IMPORTANT**

- If the engine is loaded right after it is started, it may cause engine stalling and failure. Make sure to idle the engine first.
- If neglecting to idle the engine, it can cause:
  - seizure of the hydraulic pump
  - Failure in the hydraulic system.

▶ **IDLING IN COLD WEATHER**

Hydraulic oil in this vehicle is also used as transmission fluid.

If the temperature drops in winter so oil gets cold, its viscosity rises and the hydraulic pump cannot suck oil in, causing malfunction.

Make sure to idle the engine in winter according to the following instructions.

TEMPERATURE	TIME
Above 50°F (10°C or higher)	5 ~ 10 min.
50°F ~ 32°F (10°C ~ 0°C)	10 ~ 20 min.
32°F ~ 14°F (- 0°C ~ - 10°C)	20 ~ 30 min.
14°F ~ - 4°F (- 10°C ~ -20°C)	30 ~ 40 min.
- 4°F or less (- 20°C or less)	more than 40 min.

**WARNING**


- Proper ventilation is needed when engine idling is performed indoors.

D



## 2. OPERATING TRACTOR

### ▶ STARTING OFF



1. Confirm that left and right brake pedals are interlocked when two brake pedals are installed. Make sure to interlock left and right brake pedals unless working in a field.
2. Lift an implement.
3. Place main and sub shift lever into the desired position.
4. Depress brake pedal to release parking brake.
5. Use throttle lever or pedal to increase engine speed.


### ▶ SHIFTING AND DRIVING

To shift during driving, depress the brake pedal to stop the vehicle in advance.

#### WARNING

- The driving speed in the reverse direction is almost the same to the speed in the forward direction. Make sure to check the surroundings carefully when driving backward.
- Especially, never drive backwards with the sub shift lever in the position high speed. The driving speed becomes faster and it can cause an accident.
- Connect the left and right brake pedals when it is about to drive when two brake pedals are installed.

### ▶ TURNING IN FIELD



When two brake pedals are installed.

1. To turn in a field, release hook for left and right brake pedals.
2. Turn steering wheel and depress brake pedal for desired direction.
3. While turning, keep engine speed low and turn slowly.


When single brake pedal is installed.

Turn steering wheel to desired direction.

#### WARNING

- Avoid turning at a high speed. The tractor can fall on its side.
- When the tractor is installed with an implement, its overall length becomes large. Be extra care with other people and objects around when turning.

► **PARKING THE TRACTOR**



1. Stop tractor completely in level ground.
2. If an implement is attached to vehicle, lower it.
3. Set levers in neutral position.
4. Apply parking brake.
5. Remove key from key switch.

 **WARNING**

- After parking, make sure to apply the parking brake.
- Avoid parking on a slope if possible. If it is absolutely necessary to park on a slope, chock the rear wheels.

► **START ON STEEP SLOPE**

1. Depress the brake pedals.
2. Place sub shift lever in the low speed position.
3. Set engine at the mid speed with the throttle lever.
4. Depress the throttle pedal or use throttle lever to increase engine revolution.
5. Release the brake pedal at the same time.

► **TIPS FOR DRIVING ON SLOPE**

1. Set range shift lever in low speed position on a slope to prevent engine from stopping.
2. Keep driving speed low on a downhill road.
3. Do not set sub shift lever in neutral position on a downhill road.

 **IMPORTANT**

- When the needle on the coolant temperature gauge is pointing at 「H」 or coolant lamp comes on, engine is overheated. If running the engine under this condition continuously, the engine parts can be severely damaged. Make sure to take an appropriate action immediately.

 **WARNING**

- On a downhill road, use the engine brake. Otherwise, it can cause an accident.



### ► CAUTIONS FOR DRIVING INTO OR OUT OF FIELD

1. Check that left and right brake pedals are connected.
2. It is dangerous to drive into/out of a field if the field is deep from its bank. Use ramps.
3. Move in the perpendicular direction to the bank.
4. When driving out of the field, lower the implement so that the front wheels cannot be lifted.
5. It is recommended to drive into a field backward to utilize full power.

#### WARNING

- Be careful to keep the tractor's balance when working on a slope. The tractor may become out of balance and roll over.
- It is very dangerous to ride a person as a front weight.

### ► LOADING TO OR UNLOAD FROM TRUCK

1. When loading the tractor onto a truck, drive backward.
2. Be extra careful when using ramps.
3. If the engine stops on ramps, depress the brake pedals immediately and release them slowly to move onto the ground. Then, start the engine again to climb the ramps again.

### ► CAUTIONS FOR DRIVING ON ROAD

1. When changing the direction on a road, use the turn signal lamp to inform other drivers.
2. Use the low beam when there is any vehicle coming on the other side at nighttime.
3. Check that the left and right brake pedals are connected.
4. Keep the work lamps off when driving at night.
5. Follow any applicable laws and keep safe driving.
6. Never let anyone ride the tractor, except yourself as a driver.

#### WARNING

- If driving on a road with an implement attached, the front side of the tractor tends to be lifted and vehicle may not be steered properly.

### 3. OPERATION OF PTO

Rear PTO is provided for variable utility. The engine will not start if PTO switch is ON position.

The engine will shut-off if the operator leaves the seat with parking brake released and PTO engaged.



PTO speed can be selected by PTO shift lever.

PTO	PTO speed
REAR	540 / 750 / 1,000 RPM

 **WARNING**

- To avoid damage of transmission and implement, do not engage PTO with the engine running at high speed.
- Do not operate any implement at a high speed than is specified for it.
- When making adjustments to the implement, stop the engine to avoid serious injury.
- When leaving the tractor stop the engine and remove the key. Apply parking brake.

► **OPERATING PTO**



Follow next steps to use PTO.

1. Decrease engine speed to near idle.
2. Change PTO auto switch to manual or auto and set PTO shift lever to desired position.
3. Turn on the PTO switch.
4. Increase engine RPM to desired speed.

► **PTO MONITOR LAMP**



PTO monitor lamp indicates the state of the PTO shaft.

- **If the PTO lamp glows:**  
The PTO is rotating.
- **If the PTO lamp is off:**  
The PTO is off.
- **If the PTO lamp blinks:**  
The PTO is presently stationary but will instantly start rotating of the implements lowered.

D



## ► PTO ROTATION TABLE

N/A : not applicable

PTO ON/OFF SWITCH	PTO SHIFT LEVER	PTO MODE SWITCH	POSITION LEVER	PTO MONITOR LAMP	PTO SHAFT ROTATING
OFF	N/A			OFF	OFF
N/A	Neutral	N/A		OFF	OFF
ON	540/750/1,000	AUTO	RAISED	BLINK	OFF
ON	540/750/1,000	AUTO	LOWERED	GLOW	ON
ON	540/750/1,000	MANUAL	N/A	GLOW	ON

- From the table above we learn about the safety features of the PTO. When the monitor on the dash panel is blinking it indicates to the operator that the PTO is in the on position but temporarily not rotating because the implement is lifted off the ground or both. The PTO will start rotating instantaneously when the implement is lowered to the ground.
- The operator must use this blinking signal to clear the area around the tractor off bystanders/onlookers as the rotating blades of certain implements can accidentally cause injuries to the persons standing near the tractor.
- The stopping of the PTO when the implement is lifted off the ground with the position control prevents the damage to the implement or the PTO shaft.

### WARNING

- When the PTO mode switch is in manual position the PTO does not stop rotating. If working on hard soils, pavements with a rotary implement the PTO ON/OFF switch must be put to the OFF position to stop the PTO from rotating. If this is not done, the rotating blades of the implement will push on the hard ground below and in turn push the tractor toward causing accident which can lead to serious injuries or death.
- Extra precaution must be taken to clear the area of bystanders/onlookers when using PTO driven implements. The rotating blades of the implements can cause serious injuries on contact. The warning that is indicated by the blinking PTO monitor is to make the operator aware that the PTO is in on position and will instantly start rotating if the implement is lowered or both.
- In no case the specified rotating speeds indicated by the implement manufacturer be crossed as the same can lead to serious damage to the tractor/equipment and can lead to serious injuries to persons around.

## 4. IMPLEMENTS

### ► CONNECTION TO IMPLEMENTS

1. Make sure to stop the engine before connecting the implements.
  2. Move the double acting valve lever forward and backward for 4 to 5 times to release pressure in the hydraulic line of tractor. Otherwise, it is hard to connect the couplers, and hydraulic fluid can be sprayed from the line and get in to your eyes while connecting them.
  3. Remove any foreign material around male and female couplers. If foreign material enters the hydraulic components, it can lead to malfunction of the system.
  4. Open dust-proof cover of female coupler of the tractor and insert the male coupler of the implement. A clicking sound is heard when the couplers are engaged.
  5. Pull the hydraulic hose of the implement to check that the couplers are properly connected.
- ※ **Hydraulic control valves may not exist depending on tractor model.**

### ► DISCONNECTION FROM IMPLEMENTS

1. Make sure to stop the engine before disconnecting it.
  2. Release any residual pressure in the hydraulic hoses of the implement and tractor by operating the double acting valve lever 4 to 5 times.
  3. Remove any foreign material around the couplers.
  4. Keep the implement balanced by removing any load applied (lowering it onto the ground, for example).
- If disconnecting the hose while outer load is applied to the implement, it is hard to connect the implement in the future.
5. Remove the male coupler by pushing the female coupler boss of the tractor backward.
  6. Close the dust-proof cover of the female coupler of the tractor. Wrap the male coupler of the implement with a plastic bag to prevent contamination.

### ► MOUNTING IMPLEMENTS

If the PTO is used, remove the safety cover off the PTO shaft. Adjust the yoke rod on the lower links to suit the implement in use. Attach the left lower link, then attach the right lower link using the adjusting handle on the leveling box if required. Attach the top link. Attach PTO shaft to the tractor if used, making sure that it is locked in place. Adjust the check chains to suit the implement and tighten the locknuts.


#### WARNING

- Never connect or disconnect the implement hydraulic hose while the pressure in it is not released or the engine is running. It's hard to connect and disconnect the hose and hydraulic fluid can be sprayed from the hose, and get into your eyes or skin.
- stop engine and wear protective glasses and gloves before work.



## 5. TOWING THE TRACTOR

### ► TOWING THE TRACTOR



The tractor can be towed only for short distances, such as, for example, from inside to outside a building.

A broken down tractor should be towed for the minimum indispensable distance to remove it from potentially dangerous conditions.

Observe all legal provisions as envisaged in the highway code relative to national legislation regarding towing manoeuvres.

#### DANGER

- NEVER permit other persons to access the tractor operator position during towing.

#### WARNING

- We recommend transporting the tractor on a low loader in the case of longer transport distances. Comply with the maximum width and height regulations for road transport. Check that the loader is suitable for the weight of the tractor to be transported.

#### CAUTION

- An operator must always be at the tractor's controls when the tractor is being towed.

### ► TOWING WITH ENGINE RUNNING

Towing with the engine running can be performed if forced gearbox lubrication is ensured:

- Engine speed between 1,200 ~ 1,300 rpm.
- Maximum towing speed 8km/h
- Maximum towing distance 1km

For towing the tractor use only a standard bar applied to the front towing hitch approved by the manufacturer.

Make sure to use the correct pin for the towing hitch and that it is secured with its locking pin.

Clean all lights required for road use, front and rear, and make sure they are in working order.

Before starting towing check the following conditions:

- Unhitch any implement from the tractor;
- Lock the two brake pedals together with the connecting latch;
- Disengage the power take-off and differential locks;

- Set the shuttle control lever and gear lever to neutral;
- Move the range lever to the 「FAST」 position;
- Move the creeper lever to neutral;
- Display the SMV (Slow Moving Vehicle) sign and turn on the rotating beacon and hazard lights
- Travel speed must always be such as to allow complete control and stability of the tractor in all conditions.

 **DANGER**

- Never attempt to tow the tractor with ropes (including steel ropes) because rope breakage can cause serious injury.

 **WARNING**

- Switch on the hazard warning lights and revolving warning lights. Affix suitable notices indicating that the tractor is being towed. Observe and follow the relevant national regulations. Observe local safety regulations.

During road transfers observe the following instructions:

- Wait until traffic thins before joining the road. Exert caution in the proximity of unregulated intersections. Slow down until you have a clear view in both directions.
- Keep in your lane and drive as close as possible to the kerb.
- If a tailback builds up behind you pull into a lay-by as soon as possible to allow the traffic to pass
- When stopping the tractor (in any circumstances) apply the parking brake.

► **TOWING WITH ENGINE OFF**

With engine stopped and with forced gearbox lubrication system inoperative the tractor should not be towed except when safety is at risk.

 **IMPORTANT**

- With engine stopped and with forced gearbox lubrication system inoperative the tractor can be transferred to a service center only when loaded onto a transporter.

D




## 6. CHECKS DURING DRIVING

### ► CHECK DURING DRIVING

Constantly monitor the warning lamps on the monitor panel and if any comes on, stop the tractor to determine the cause.


### ► OIL PRESSURE



If the oil pressure lamp comes on check the oil level first of all.

If the oil level is OK, ask a qualified dealer to check the reason for the light coming on.

### ► BATTERY CHARGING



If the alternator warning lamp comes on check all connections and ensure that the fan belt is not broken.

If all connections and the fan belt are intact consult your dealer to determine the cause of the problem.

► FUEL GAUGE



To avoid excessive condensation in the fuel tank refill at the end of each day's work and ensure during the day that it does not drop to a low level where the fuel system will require bleeding to expel air in the system after refilling the tank.

► COOLANT TEMPERATURE



If the needle of the coolant gauge points at "H," stop the engine and check the followings:


- Radiator coolant
- Radiator fin for clogging
- Fan belt for looseness

If necessary, have your tractor checked by workshop.

 **DANGER**

- Allow the engine to cool down before opening radiator cap as serious burns may result due to hot steam and boiling water.

► TRAILER SOCKET



The socket is ready to operate the electrical systems of implements, trailer lighting, warning lamps and etc.

 **WARNING**

- When traveling on public or farm roads, connect both brake pedals and allow for the weight of any mounted implement to ensure that unit is not unbalanced.
- Where fitted use the hazard lights provided.
- Strictly follow the local traffic regulations.
- When operating near others with an implement attached take particular care to allow for the width of the implement and avoid accidents.

D



## 7. WORK PROCEDURES

### ► PRECAUTIONS FOR HANDLING IMPLEMENTS

1. When driving the tractor to attach or detach an implement, make sure that there is no one in between or around the tractor and implement.
2. Install and remove the implement only on safe and level ground.
3. When installing a heavy implement, install weight on the front to keep balance.
4. When adjusting an implement, apply the parking brake, stop the engine and set the PTO switch in the OFF position in advance.
5. To tow anything, use the towing hitch only.
6. When working with a front loader, install an implement to the back to keep balance (if necessary).

#### WARNING

- Read instructions on warning decals on each implement thoroughly before work.
- To avoid an injury due to mishandling of an implement, read the user's manual of the implement thoroughly and work safely and precisely with caution.
- Installation of an improper implement can lead to an injury. Install only implements specified by the manufacturer.

### ► GENERAL IMPLEMENT

#### <Safety precautions for rotavator>

Never remove the safety cover of the rotavator.

Do not remove the PTO shaft cover and safety cover on the universal joint.


When adjusting each part, disengage the PTO and stop the engine in advance.

When driving on a road, keep the PTO disengaged.

Also, keep the rotavator lowered on a road as long as it does not hit the ground.

For the universal joint, its inner shaft and outer shaft should be overlapped at least 15 cm.


Check that the universal joint is firmly fixed to the tractor and rotavator shaft.



### 1. Sequential returning plowing pattern

- This pattern can be useful in a well-planned field in a good condition.
- The border shown in the figure is the effective plowing width of the rotavator and should be set a little narrower than three times of one plowing width.
- The starting point is the ending point.
- Plow in a sequential pattern from (1) to (6) and in a circular pattern from (7) to (18).
- When driving forward to plow, have the bank on the right side.
- Be careful not to press already plowed soil with the wheels.

D




## 2. Alternating returning plowing pattern

- This pattern is useful for narrow or short fields or poorly planned fields in which are not easy to turn.
- In the figure, the plowing width for (1), (2), (3) and (4) should be overlapped with the one for (5), (6) and (7) for approx. 10 cm.
- For the sections (1) to (7), perform plowing in an alternating pattern. For the sections (8) to (19), plow in a circular pattern.
- Refer to the sequential returning pattern for other details.





## ▶ FRONT LOADER VALVE



When installing for loader, the loader should be facing up, but a loader the left when not installed.


### WARNING

- When connecting the hydraulic pipes, set them according to the operating directions specified on the label attached to the side of the joystick lever.
- Abnormal operation of a loader can lead to an accident.


### IMPORTANT

- If it is hard to steer the tractor for plowing as the front wheels are lifted, install additional weight to the front. (if no loader is installed.)

## ▶ FOR SAFE LOADER WORK




Keep the balance between the front and rear by installing a weight to the back of the tractor or attaching a weight or implement using the 3-point link.



When transporting things with a loader, lower the loader and keep the driving speed slow.


Keep the loader 30 to 50 cm off the ground and the driving speed below 5 km/h.

When going onto a slope or unpaved area, lower the speed and drive with care.




Do not lift anything only with one side of the tractor. If so, the tractor may fall on its side.

Make sure to distribute the load evenly.



Keep the clearance between the rear wheels as large as possible for safety of the tractor.



 **WARNING**

- Do not let anyone ride a loader for work, such as spreading fertilizer. He/she may fall off the loader, leading to an injury or even death.
- Always lower the loader to the ground before leaving the tractor.

 **IMPORTANT**

- This chapter only provides brief descriptions and instructions for a rotavator and loader. Therefore, for detailed operational instructions and other descriptions, refer to the user's manual of each implement.

D



### 8. OPERATION TIPS

To save fuel & oil in your tractor, following things should always be kept in mind.

#### ► AIR CLEANING SYSTEM

1. Clean the air cleaner regularly so that dust does not settle down.
2. For every 50 hours & every day in sandy/dusty conditions.
  - Clean the air cleaner filter element with compressed air.
  - If the rubber ring is cut or expanded then change it with an appropriate one.  
Fix the rubber at the proper location & check for leakages if any.
  - If air is leaking through the hose connection, check & rectify other leakages, too.

#### ✚ IMPORTANT

- If air cleaning system is not properly maintained, it will lead to early wear of piston rings & sleeves. This will lead to problems like loss of engine power, excessive oil consumption fuel consumption.

#### ► ENGINE

1. Put the engine oil on load after the engine is heated & the water temperature gauge indicates the needle to be in the green zone.
2. If excessive black smoke is visible, then the paper element of air cleaner, Fuel injection pump or nozzles should be checked.
3. Do not run the engine without load for more than 2 minutes.  
It is better to stop the engine rather than run it idle.  
This will help in saving of fuel.

**► BRAKE**

1. If the tractor has to be stopped for a long period, it is advisable to bring the transmission in neutral position.
2. Do not override the brake pedals.
3. While coming down from a slope, reduce the engine throttle & use low gear.  
Do not depend only on the brakes for stoppage.

**► OIL SYSTEM**

1. Always use recommended grade of oil.
2. Every day before starting the engine, check the oil level with a dipstick & refill between the minimum & maximum level.
3. Charge the engine oil.  
Replace filter & O-ring, as & when required.

**► LUBRICATING OIL****• GENERAL**

Modern diesel engines place very high demands on the lubricating oil to be used. The specific engine performances which have increased constantly over the last few years lead to an increased thermal load on the lubricating oil. The lubricating oil is also more exposed to contamination due to reduced oil consumption and longer oil change intervals. For this reason it is necessary to observe requirements and recommendations described in this operating manual in order not to shorten the life of the engine. Lubricating oils always consist of a base oil and an additive package. The most important tasks of a lubricating oil (e.g. wear protection, corrosion protection, neutralization of acids from combustion products, prevention of coke and soot deposits on the engine parts) are assumed by the additives. The properties of the base oil are also decisive for the quality of the




product, e.g. with regard to thermal load capacity. In principle, all engine oils of the same specification can be mixed. However, mixing of engine oils should be avoided because the worst properties of the mixture are always dominant.

### • VISCOSITY

The ambient temperature at the installation site or in the application area of the engine is decisive for choosing the right viscosity class. Too high a viscosity can lead to starting difficulties, too low a viscosity can endanger the lubrication effect and cause high lubricating oil consumption. The viscosity is classified according to SAE. Multipurpose lubricating oils should be used basically.

#### IMPORTANT

- The prescribed lubricating oil quality must be observed when selecting the viscosity class.



1. Always use filtered diesel for the fuel system.
2. At the end of the day's working, it is preferable to fill the diesel tank so that it may prevent condensation.
3. Change the filter, if the system gets choked.

Do not change both the filters at the same time.

If the above directives are not adhered to, the fuel injection pump & injection nozzle will lose its life early.

Also, it will lead to excessive black smoke & excessive diesel consumption.

※ Please refer to 「APPENDIX」 chapter for more details of diesel fuel.

### ▶ WINTER OPERATION WITH DIESEL FUEL

Special demands are placed on the cold behavior (temperature limit value of the filterability) for winter operation.

Suitable fuels are available at filling stations in winter.

At low ambient temperatures paraffin discharges can lead to blockages in the fuel system and cause operating faults.

#### IMPORTANT

- For engines with common rail injection, the mixing of petroleum and adding of extra low additives is not permissible.

### ▶ COOLING SYSTEM

1. Check the fan belt tension regularly. Adjust, if required.
2. Check the coolant level in the radiator fins always clean.
3. Replace the radiator cap with a genuine cap only, if required.
4. Do not remove the thermostat but replace with a new one, if required.
5. Do not change the radiator water often.

※ Please refer to 「APPENDIX」 chapter for more details of coolant.

### ▶ OTHERS

In liquid-cooled engines, the coolant must be conditioned and monitored, otherwise the engine could be damaged by:

- Corrosion
- Cavitation
- Freezing
- Overheating






# **MAINTENANCE**

- 1. OPENING COVERS · · · · · E – 2
- 2. INSPECTION ITEMS · · · · · E – 3
- 3. SERVICING EACH PART · · · · · E – 4
- 4. MAINTENANCE AND ADJUSTMENT  
SCHEDULE · · · · · E – 30
- 5. INSPECTING ELECTROHYDRAULIC SYSTEM · · E – 33



## 1. OPENING COVERS

### ► OPENING HOOD



1. Push the hood opening handle under the hood front grill to the left as shown in the figure to unlock the hood.
2. Lift the hood with hands slightly. Then, the hood is automatically opened by its damper.

## 2. INSPECTION ITEMS

To prevent any possible failure, some items should be checked daily. Make sure to perform inspection before driving.

### ► INSPECTION ITEMS

- Inspect each part in the following order:
1. Check the items that were faulty yesterday
  2. Go around the tractor and check:
    - Lamps for proper illumination and damage
    - Tires for inflation pressure, crack, damage and wear
    - Rotating parts, including tires, for loose bolts and nuts
    - Transmission fluid level
    - Implement attachment status
    - Pre-cleaner for cleanliness
  3. Open the hood and check:
    - Engine oil level
    - Coolant level
    - Fan belt for looseness and damage
    - A/C belt for looseness and damage
  4. Sit on the driver's seat, turn the main switch to the "ON" position and check:
    - Fuel gauge for proper operation
    - Fuel level
    - UREA Level gauge
    - Engine oil and charge warning lamps for blinking operation
    - Turn signal lamp
    - Horn operation
    - Brake pedal free play
    - Clutch pedal play
  5. Start the engine, drive the tractor slowly and check:
    - Emission color
    - Brake pedal operation
    - One brake pedal operation
    - Heaviness and vibration of steering wheel
    - Coolant gauge operation
    - Hydraulic operation of 3-point link



## 3. SERVICING EACH PART

### ► INSPECTING AND CHANGING ENGINE COOLANT



#### (1) Inspection

Open the Coolant cap and check if coolant is filled up to the filler neck. If not, add more coolant to the radiator.

#### WARNING

- Do not open the cap when the engine is hot. Otherwise, hot steam can burn you seriously. Wait until the engine is sufficiently cooled down.



#### (2) Change

1. To drain coolant rapidly, open the drain cork and remove the radiator cap simultaneously. At this time, set the heater cork to the Open position to drain coolant.
2. Flush the inside of the radiator with clean water thoroughly.
3. Fit the drain cork and add coolant.
4. Start and idle the engine for approx. 5 minutes and check the coolant level in the reservoir tank. Add more coolant as necessary.

### ► ANTI-FREEZE


If coolant freezes, the engine can be damaged.

- Clean the radiator thoroughly before adding antifreeze.
- The mixture ratio of antifreeze is different by manufacturers and temperature. Refer to the manufacturer's manual.
- Mix antifreeze with water sufficiently before adding it.
- Adding antifreeze
  - If evaporated: Add water for the reduced amount.
  - If leaked: Add mixture of antifreeze and water with the same mixture ratio.

#### WARNING

- If engine coolant gets on your skin, it can irritate the skin and cause a skin condition. Make sure to clean your skin with soap and water or hand cleaner thoroughly.

► **CLEANING RADIATOR GRILL AND CONDENSER GRILL**



When working in a grassy field or working at night, the radiator or condenser grille may be clogged by grass, straws or bugs, reducing cooling performance. Clean the grill in this case. If dust is stuck between the fin and tube, flush the area with clean water.

**IMPORTANT**

- Do not clean the radiator fin with water jet. It can deform the fin.

► **CLEANING CONDENSER GRILL AND OIL COOLER**




Turn the opening lever to access to the condenser and oil cooler. Clean them with clean water. Remove the grill by unscrewing the pin (1) and moving it in the arrow direction.


► **CHECKING AND CHANGING ENGINE OIL**



(1) Inspection

1. Pull out the dipstick, wipe its tip and insert it again. Then, pull it out and check that the oil level is between the upper and lower limits.
2. If the level is below the lower limit, add oil.





## ⚠ CAUTION

- If engine oil gets on your skin, it can irritate the skin and cause a skin condition. Make sure to clean your skin with soap and water or hand cleaner thoroughly.

## ⚠ IMPORTANT


- Do not add engine oil over the upper limit level.
- Check the engine oil before starting the engine or at least in 5 minutes after the engine is stopped.
- When trying to use new oil from a different manufacturer or oil with different viscosity, drain used oil completely before adding new oil.

## (2) Changing

- Unscrew the drain plug on the lower section of the engine to drain contaminated engine oil. Since hot oil flows out of the engine first, be careful not to get burnt.
- After draining oil, tighten the engine oil drain plug.
- Add the specified amount of the specified engine oil through the filler hole.

\* There is one engine oil drain hole on each side of the engine.


## ▶ CHECKING AND CHANGING TRANSMISSION FLUID



## (1) Inspection

Perform inspection while the engine is stopped.

1. Pull out the dipstick, wipe its tip and insert it again. Then, pull it out and check that the oil level is between the upper and lower limits.
2. If the level is below the lower limit, add fluid.



**⚠ CAUTION**

- If transmission fluid gets on your skin, it can irritate the skin and cause a skin condition. Make sure to clean your skin with soap and water or hand cleaner thoroughly.

**⚠ IMPORTANT**

- Do not add fluid over the upper limit level.
- Check the fluid before starting the engine or at least in 5 minutes after the engine is stopped.
- When trying to use new fluid from a different manufacturer or fluid with different viscosity, drain used fluid completely before adding new fluid.
- This tractor uses transmission fluid as hydraulic oil.
- Therefore, keep the oil change interval.

**⚠ IMPORTANT**



- The transmission is already filled with transmission fluid properly.
- When using a hydraulic implement, add more fluid for the amount of the implement.

(2) Changing

1. Unscrew the drain plug on the lower section of the transmission to drain contaminated transmission fluid.  
As hot fluid flows out of the transmission first, be careful not to get burnt.
2. After draining fluid, tighten the transmission fluid drain plug.
3. Pour the specified amount of the specified transmission fluid through the filler hole.



## ► INSPECTING AND CHANGING FRONT AXLE OIL



### (1) Inspection

1. Pull out the dipstick, wipe its tip and insert it again.  
Then, pull it out and check that the oil level is between the upper and lower limits.
2. If insufficient, add oil.

### (2) Changing


1. Unscrew the drain plugs from the bottom of the axle and left/right final cases to drain contaminated engine oil.  
Since hot fluid flows out of the engine first, be careful not to get burnt.
2. After draining oil, tighten the oil drain plug.
3. Add the specified amount of the specified oil through the filler hole.

### ⚠ CAUTION

- If oil gets on your skin, it can irritate the skin and cause a skin condition.  
Make sure to clean your skin with soap and water or hand cleaner thoroughly.

### ⚠ IMPORTANT

- Do not add front axle oil over the upper limit level.
- Check the front axle oil before starting the engine or at least in 5 minutes after the engine is stopped.
- When trying to use new fluid from a different manufacturer or fluid with different viscosity, drain used fluid completely before adding new fluid.



1. Make sure that the amount of fuel in the fuel tank is sufficient.
2. If air is mixed in the pre-filter or main filter, unscrew its bleeding bolt (2), shown in the figure, and turn the main switch to run the start motor.  
Then, air in the fuel filter is bled through the bleeding bolt as shown in the figure above.

 **CAUTION**


- Avoid to run the start motor for over 5 consecutive seconds, but run it several times at shorter intervals.

 **IMPORTANT**

- If filling the port with fuel before installing the fuel port, it is not necessary to bleed the filter.




### ► REPLACING TRANSMISSION HYDRAULIC OIL FILTER




1. Remove the hydraulic oil filter element by turning it counterclockwise with a wrench.
2. Apply a thin film of oil to the O-ring of a new cartridge and install the new cartridge by tightening it with a hand.  
When its packing touches the sealing surface, turn it approx. 2/3 turns further with a wrench.
3. Add the specified amount of hydraulic oil.
4. Check the oil level with the dipstick again.  
If still insufficient, add more.

### ► REPLACING AND SERVICING HIGH PRESSURE FILTER



1. When the indicator is turned on in red after the engine is started, the element needs to be replaced.
2. Stop the engine and turn the cover counterclockwise with a spanner to remove it.
3. Pull down the cartridge to remove it.
4. Replace the element.
5. Apply a thin film of oil to the O-ring and push it up to fit it.
6. Wash the removed cover with hydraulic oil and install it with a spanner.
7. Start the engine and confirm that the indicator is turned on in green.

### ► REPLACING ENGINE OIL FILTER CARTRIDGE



1. Remove the engine oil filter cartridge by turning it counterclockwise with a wrench.
2. Apply a thin film of oil to the O-ring of a new cartridge and install the new cartridge by tightening it with a hand.  
When its packing touches the sealing surface, turn it approx. 2/3 turns further with a wrench.
3. Add the specified amount of engine oil.

4. Run the engine for approx. 5 minutes and check for proper operation through the engine oil warning lamp on the instrument cluster.  
Then, stop the engine. (This warning lamp should be turned off while the engine is running.)
5. Check the oil level with the dipstick again.  
If still insufficient, add more.

**► FUEL**




Use only low sulfur or ultra low sulfur diesel fuel.

(1) Fuel filler port

**⚠ DANGER**

- When checking the fuel system or fueling, keep flammable items, such as a lit cigarette, away from the tractor.
- The tractor may catch fire.



(2) How to bleed fuel system  
It is necessary to bleed the system under the following conditions:


- The engine is stopped due to the empty fuel tank.
- The filter or pipe is removed.

Bleed the system according to the following procedures:

- ① Disconnect the connector.
- ② Press the priming pump repeatedly to bleed the system.



## ► FUEL FILTER DRAINING




### (1) Loosen the drain valve

1. Loosen the drain valve (A) at the bottom of the fuel filter.

### ⚠ CAUTION

- Do not use tools to loosen the drain valve. Use of tools may damage the drain valve.




### (2) Drain the fuel filter

1. Discharge water from the fuel filter through the drain valve (A) for about 10 seconds.

### ⚠ CAUTION

- Periodically check the fuel filter and drain the water from it. Otherwise, moisture may flow into the fuel unit of the engine, resulting in critical faults in the fuel injection pump, the fuel injection pipe, the common rail, and injectors. In addition, the performance of the fuel filter may be degraded or damaged.
- Fuel may be drained when water is drained from the fuel filter. Fuel is highly inflammable. Fire may occur when you smoke or use fire near the engine when draining water from the fuel filter.
- Use clean, specified, and qualified fuel only. Using irregular or unspecified fuel may result in more water in the fuel filter. Drain the water from the fuel filter
- if the fuel filter alarm lamp is turned on. Otherwise, moisture may flow into the fuel unit, causing the engine to stop.



(3) Tighten the drain valve

1. Tighten the drain valve (A) at the bottom of the fuel filter.

**CAUTION**


- Do not use tools to loosen the drain valve. Use of tools may damage the drain valve.

► **CLEANING FUEL FILTER**

Drain water and remove foreign materials from the fuel filter at every 100 hours of operation.

1. Remove the plug (1) on the bottom of the filter. It can be removed by unscrewing it.
2. Drain water and remove foreign materials completely. Then, fit the plug.
3. Then, run the engine to bleed the system.

► **REPLACING FUEL FILTER ELEMENT**



1. Open the drain plug (1) to drain fuel in the filter.
2. Unscrew the filter (2) from the filter head.
3. Push and turn the element in the filter counterclockwise to remove it from the filter body.
4. Screw in a new O-ring and element into the filter body.
5. Turn the filter until the filter body touches the filter head.

E



### ► UREA TANK FILLER PORT



When the urea amount in the tank is below 25%, the urea level warning lamp comes on. In this case, add more urea into the tank.


1. Stop the engine and remove the urea filler cap.
2. Pour urea through the filler port until the urea level reaches the mark on the gauge which is located on the right side of the cap.
3. Turn the filler cap clockwise completely.




※ The urea level gauge is located on the multi-display.

### ▲ CAUTION

- The engine power is limited when driving only with 10% of the full urea capacity.
- Never add any fluid, such as diesel fuel, gasoline and alcohol, into the urea tank other than the recommended urea (complying with ISO22241 or DIN70070).
- Do not add urea over the middle mark in the tank gauge. The tank may overflow.
- Also, the tank can be frozen and broken in winter.
- The urea tank gauge is designed to prevent overflow of the tank. It is not designed to be used as a level gauge.
- The urea level in the tank can be checked on the multi-display screen.
- If using poor-quality urea or fluid other than the recommended, it can damage the after-treatment system and other parts in the vehicle.
- If using poor-quality fuel, foreign materials are collected in the SCR catalyst, leading to piling up and breaking of the catalyst.

### ► UREA FILTER REPLACEMENT






3. Insert the tool till it clips on guide.







1. Remove the filter cover required.
- Tool : 27mm (1.06 inch) Wrench with 20 + 5N · m Torque



2. Remove the equalizing element.



E



4. Then rotate in clockwise direction as shown in front view.

5. When no further rotation possible (after ca. 45°), then pull out the filter.

- Distance of the tool from SM when in pull out position : ca.27mm. (1.06 inch)



6. Distance of the tool edge from SM when filter is completely demounted : ca. 140.7mm.(5.5inch)
7. Install a new filter, new equalizing element.

INGREDIENT	UNIT	ITEM		TEST METHOD
		MIN.	MAX.	
Urea concentration <sup>a</sup>	%(m/m) <sup>b</sup>	31.8	33.2	ISO 22241-2 Annex B <sup>c</sup> ISO 22241-2 Annex C <sup>c</sup>
Density (at 20°C <sup>d</sup> )	kg/m <sup>3</sup>	1,087	1,093	ISO 3675 or ISO 12185
Refractive index (at 20°C <sup>e</sup> )	-	1.3814	1.3843	ISO 22241 2 Annex C
Ammonia alkalinity	%(m/m) <sup>b</sup>	-	0.2	ISO 22241 2 Annex D
Biuret	%(m/m) <sup>b</sup>	-	0.3	ISO 22241 2 Annex E
Aldehyde	mg/kg	-	5	ISO 22241 2 Annex F
Insoluble matter	mg/kg	-	20	ISO 22241 2 Annex G
Phosphate (PO <sub>4</sub> )	mg/kg	-	0.5	ISO 22241 2 Annex H
Calcium	mg/kg	-	0.5	ISO 22241 2 Annex I
Iron	mg/kg	-	0.5	
Copper	mg/kg	-	0.2	
Zinc	mg/kg	-	0.2	
Chromium	mg/kg	-	0.2	
Nickel	mg/kg	-	0.2	
Aluminum	mg/kg	-	0.5	
Magnesium	mg/kg	-	0.5	
Sodium	mg/kg	-	0.5	
Potassium	mg/kg	-	0.5	
Identical equation	-	Identical		ISO 22241 2 Annex J

**a.** Standard: 32.5%(m/m).

**b.** The unit "%(m/m)" is used to indicate mass fraction of matter according to the international standard.

**c.** Standard: 1.3829

**c.** Calculated without excluding ammonia nitrogen

**d.** Standard: 1,090 kg/m<sup>3</sup>



It is necessary to add a tracer element to AUS 32. Make sure that the SCR system is not damaged by the quality of AUS 32 specified in the table and tracer element.

### CAUTION

- Important information before storing and restart after storing.
  - Concentration of DEF must be more than 32.5% As per regulation AUS 32 ISO 22241.
  - Must make sure the battery is on for more than 2 minutes until automatic DEF withdrawal process is completed.
  - DEF storing guidance is 2 months under -40°C~40°C (-40F~104F) and 4 months under -40°C~25°C(-40F~77F).

### IMPORTANT

- The condition of ISO 4259 within the range should be applied in between the maximum and minimum values. Also, the minimum difference of  $4 \times R$  ( $R$  = reproducibility of test method) should be considered.  
However, in order to keep the quality high,  $4 \times R$  is not considered for the urea concentration.
- Values for the urea concentration, density and refractive index are actual values. (Refer to ISO 4259 for actual values.)
- The AUS 32 manufacturer produces products based on the values for the annotation a, d and e.
- It is necessary to check if urea is satisfied with the required specifications.  
The ISO 4259 conditions should be applied.

<Urea Crystallization issue during long storage>


Following recommissioning procedure is to part of operator manual/storage instructions.

- The DEF tank must be filled to maximum level before storage of vehicle
- After the idle period and during restart of the tractor, stored adblue to be drained & the DEF tank should be re-filled to maximum level and then the tractor should be started.

**CAUTION**

- If the change schedule is overdue, the urea can be degraded or diluted, causing a problem. Therefore, perform the following procedures in this case:
  1. Fill the tank with new urea completely.
  2. Replace the main filter equipped in supply module.
  3. Run the engine for the sufficient amount of time until it is heated up and after treatment system is fully functioning.
  4. If an error code is noticed or the tractor is in abnormal condition, turn off the engine and make sure after treatment system.
  5. If the problematic condition continues, please visit the nearest service center.

**▶ AIR CLEANER SERVICING**



Check and clean the air cleaner periodically as follows:

<Cleaning vacuum valve>

Pull out the valve with a hand and remove dust from its inside. If it is dirty or watery, wipe it with a dry rag thoroughly before fitting it again.

<Precautions for inspection and service of air cleaner>

1. Use only standard elements and do not apply oil on it.
2. Foreign materials in the cover should be removed thoroughly as well.
3. Make sure to install it securely so that foreign materials do not enter the cover.

4. Never drive the vehicle with the element removed.

<Cleaning element>

Blow compressed air from the inside toward the outside of the element. Keep proper distance between the air nozzle and element.

<Replacing element>

After cleaning the element 5 times or if it is damaged, replace it with a new one.

<Cleaning cover>

Undo the clip and remove the cover to wash it thoroughly with water.



## ▶ ADJUSTING TREAD

<Adjusting front wheel tread>

The tread can be adjusted by switching the rims and discs on the left and right sides.

<Adjusting rear wheel tread>

The tread can be adjusted by switching the rims and discs on the left and right sides.


### ⚠ WARNING

- For safety, have tread adjustment performed by your dealer or workshop.
- Never remove tires if there is no safe supporting device. The tractor can roll over.

Possible combination of rear wheel with front wheel table.

REAR	FRONT					
A	A					
B	A	B	C			
C	A	B	C	D		
D	B	C	D	E	F	G
E	D	E	F	G		
F	F	G				

## ▶ STANDARD FOR TREAD ADJUSTMENT



► **GREASING POINTS**

For general greasing points, refer to the fuel, oil and fluid specification chart. However, add grease before work if the tractor is to be used in a wet field.

► **CHECKING HOSES**

Rubber parts, such as the fuel hose and radiator hose, are aged by time even when the tractor is not in use. Therefore, such parts should be replaced with their tightening bands every 2 years or when they are damaged.


 **WARNING**

- If any fuel hose is damaged, fuel leaks and it can catch fire. Make sure to check the fuel hose and take a necessary action.

► **CHECKING AND CHARGING BATTERY**

 **DANGER**

- When charging the battery after removing it from the tractor, it produces hydrogen gas, presenting a fire risk. Charge the battery only in a well-ventilated area.
- The battery produces highly flammable hydrogen gas which can explode. Keep flammable items and spark away from the battery.
- The battery electrolyte is sulfuric acid so can burn your skin and eyes. Be careful not to spill any.
- If the battery electrolyte gets on your eyes, skin, clothes or object, rinse it with water thoroughly. If you swallowed it, drink a lot of water. Also, get medical attention immediately if acid contacts your eye or is swallowed.
- If keeping using or charging the battery with its electrolyte level below the “LOWER LEVEL” mark, it can lead to battery damage or even explosion.




The battery has the charge indicator:

- Green - Fully charged
- Red - Charging required
- White - Insufficient electrolyte

### < Checking >


1. Checking battery charging level
  - If the battery is not used for over two weeks, it may become hard to start the engine. Charge the battery in this case.
  - The exact charging level can be measured with a hydrometer or through a certain test.
2. Check that the electrolyte level is between the upper and lower limits. If insufficient, add battery acid to the upper level.
3. If the battery terminal is corroded, it cannot deliver current. If it is corroded or contaminated, wipe it with sandpaper or a brush.



### < Charging >

1. Turn the ignition switch to the "OFF" position and remove the battery from the tractor.
  2. Charge the battery in a well-ventilated area.
  3. Charge the battery with the normal procedures and avoid quick charging.
  4. Open the electrolyte filler hole of the battery.
  5. Turn the battery switch OFF and connect the cables to the negative and positive battery terminals correctly.
- When using a charger, its charging current should be below 10 A.

► **JUMP START**



1. Turn off all electric devices.
2. Connect the positive terminal of the normal battery to the positive terminal of the discharged battery with the jump cable.
3. Connect the negative terminal of the normal battery to the engine body of the tractor for the discharged battery with the jump cable.
4. Firstly, start the engine of the vehicle with the normal battery. Then, start the engine of the tractor with the discharged battery.
5. After the engine is started, disconnect the negative cable first. Then, disconnect the positive cable.

6. Charge the discharged battery for approx. 30 minutes after the engine is started.

 **WARNING**


- Make sure to connect the positive terminal first and connect the negative terminal to the engine body of the tractor with the discharged battery.

► **CHECKING ELECTRIC WIRING**

1. Loose wiring terminals can cause contact failure and damaged wirings can lead to performance deterioration of electric devices, short circuit and fire. Replace or repair aged and damaged wirings.
2. If wiring sheath is peeled off, wrap wiring with insulating plastic tape.
3. If fasteners or bands to fix wirings are damaged, fix wirings with clamps.
4. Have wirings checked by your workshop once a year regularly to avoid fire.



## ► DISCONNECTING BATTERY



The function of the battery disconnect switch is to disconnect the power supply to the electrical system by interrupting the connection to the battery.

This has benefits for tractor safety and operation, in particular:

1. Protects the electrical system against short circuit;
2. Reduces battery self-discharge when the tractor is left idling for prolonged periods;
3. Allows maintenance and repairs to be carried out in conditions of safety.



Turn the knob to “OFF” to disconnect the battery and back to “ON” to resume normal operation.

The battery disconnect knob (1) is located on the bracket to the right of the battery.

The battery disconnect knob may be removed for safety purposes in the manner described below.

<Removal of the knob>

1. Press the knob in and continue to turn it counter-clockwise as far as it will go.



<Refitting the knob>

1. Press and turn the knob clockwise, positioning it at "ON".

### ⚠ CAUTION

- When the ignition switch is turned to the OFF position, urea is returned to the tank automatically. However, this may take up to 2 minutes do not disconnect battery within less than 2 minutes from engine shut down.

► **CHECKING AND REPLACING FUSE**



(1) Body fuse box


Fuses are installed in this tractor to prevent any possible accident in case of wiring circuit malfunction.

If the electric system is malfunctioning during driving, check for any blown fuse.

1. Remove the cover of the fuse box.
2. Remove the blown fuse.
3. Fit a new fuse with the same capacity.
4. The function and capacity of each fuse are indicated on the cover of the fuse box.

 **WARNING**

- If using fuses other than the specified, wirings can be overheated, leading to a fire. Never use a fuse with different capacity. Also, never use a steel wire or foil instead of a fuse.




(2) Fuse

This tractor has 5 slow-blow fuses installed to its wirings (1 for battery positive terminal).

These fuses are blown to cut current to the electric circuit in order to protect wirings. Find the cause for blown fuses and replace them with the specified genuine parts.



## ► CABIN RELAY BOX




This supplies power to the cabin control panel and cabin electric devices. If any cabin electric device is not operating properly, check this part. If defect is found, replace it with a new one. (The cabin relay box is installed in the roof.)

## ► REPLACING LAMP BULB

If a lamp does not come on by operating the corresponding switch:


1. Check the corresponding fuse.
2. If the fuse is intact, remove the bulb socket from the lamp.
3. Remove the bulb from the socket and check for blown filament.
4. If the filament is blown, replace the bulb with a new bulb with the same capacity.

## ► REPLACING TURN SIGNAL LAMP/POSITION LAMP




1. Remove the lamp lens using a flat-bladed screwdriver.

BULB	SPEC.
HAND LAMP	12V 55W/55W
TURN SIGNAL LAMP (F)	12V 21W
TURN SIGNAL LAMP (R)	12V 21W
POSITION LAMP (F)	12V 8W
STOP/POSITION LAMP (R)	12V 21W/5W
BACKUP LAMP	12V 21W
INTERIOR LAMP	12V 10W
WORK LAMP	H3 12V 35W




2. Remove the bulb by pressing it and turning it counterclockwise. Fit a new bulb by pressing it turning it clockwise.



3. Install the lamp lens by pressing it against the cover from one side.

► **ADJUSTING PEDAL PLAY**



<Adjusting clutch pedal inching cable>  
After prolonged use of clutch pedal, play of its inching cable can become excessive.

<Adjusting clutch pedal play>  
Adjust and fix cable play so that main valve inching spool stroke is 12mm when the clutch pedal is fully depressed. For precise adjustment, have your system checked by your dealer.


 **WARNING**

- If the tractor moves slowly with clutch pedal depressed, have inching cable adjusted by your dealer or workshop.
- Never adjust the inching cable by yourself.

E




### ▶ CHECKING AND ADJUSTING WATER PUMP BELT




1. Unscrew the Water pump mounting bolts slightly and move the water pump to adjust the tension of the belt.
2. Check the belt tension. Press the center of the belt. If it is deflected for 7 ~ 9 mm, it is normal.

### ▶ CHECKING AND ADJUSTING A/C COMPRESSOR BELT




- Check and adjust the tension of the A/C compressor belt regularly.
1. Unscrew the tension adjusting bolt of the compressor belt.
  2. Pull the bolt to adjust the tension. Then, tighten the bolt.
  3. Press the center of the belt with a filter. If it is deflected for 7 ~ 9mm, the tension is proper.

### ▶ CHECKING AND ADJUSTING FAN BELT



1. Unscrew the alternator mounting bolts slightly and move the alternator to adjust the tension of the belt.
2. Check the belt tension. Press the center of the belt. If it is deflected for 7 ~ 9 mm (2.7 ~ 3.5 inch), it is normal.

**► TIRE INFLATION PRESSURE**



Check if the inflation pressure of the front and rear tires is correct.  
If not, adjust it to the specification.

MODEL	ITEM	SPECIFICATIONS		AIR PRESSURE
T854, T954, T1004	FRONT	13.6-24	6PR	1.6(kg/cm <sup>2</sup> )
	REAR	16.9-34	8PR	1.6(kg/cm <sup>2</sup> )
T1104	FRONT	13.6-24	6PR	1.6(kg/cm <sup>2</sup> )
	REAR	18.4-34	10PR	1.6(kg/cm <sup>2</sup> )



## 4. MAINTENANCE AND ADJUSTMENT SCHEDULE

### ► PERIODICAL CHECK AND SERVICE TABLE

- ▮ Check or adjust each part only when engine is stopped.
- ▮ When any hot part should be serviced, wait until it is cooled down.

- : Check · Add · Adjust
- : Replace
- ★ : Service by work shop
- △ : Clean

NO	ITEM	SERVICE INTERVAL (HOUR METER, MARK)															
		DAILY	50	100	150	200	250	300	350	400	450	500	550	600	1YEAR	2YEAR	
1	ENGINE OIL & CARTIRIDGE	○											●		●		
2	AIR CLEANER						○					●					
3	RADIATOR COOLANT	○														●	
4	FUEL	○															
5	FUEL FILTER	○										●			●		
6	FAN BELT	○															
7	UREA FILTER	REPLACE EVERY 3,000 HOURS															
8	BATTERY			○													
9	LOOSE NUTS & BOLTS	○															
10	RADIATOR HOSE CLAMP	○															
11	TRANSMISSION OIL & CARTRIDGE		★					○					●		●		
12	CLUTCH PEDAL PLAY	○															


- Check or adjust each part only when engine is stopped.
- When any hot part should be serviced, wait until it is cooled down.

- : Check · Add · Adjust
- : Replace
- ★ : Service by work shop
- △ : Clean

NO	ITEM	SERVICE INTERVAL (HOUR METER, MARK)														
		DAILY	50	100	150	200	250	300	350	400	450	500	550	600	1YEAR	2YEAR
13	STATE OF BOTH BRAKE PEDALS	○														
14	OPERATION OF EACH LEVER	○														
15	FREE PLAY OF STEERING WHEEL	○														
16	TOE-IN							○						○		
17	GREASE IN FRONT WHEEL HUB							○								
18	CHECK THE STEERING WHEEL JOINT							○						○		
19	WHEEL NUT FASTENING TORQUE	○														
20	OPERATION OF THE INSTRUMENT	○														
21	ADJUSTMENT OF THROTTLE PEDAL							○								
22	GREASE EACH NIPPLE		○	○	○	○	○	○	○	○	○	○	○	○		
23	OIL OF 4WD FRONT AXLE		★					○					●		●	
24	CHECK ELECTRIC WIRING	○						○								
25	HYDRAULIC HOSE & PIPES							○								




## ► FUEL, OIL AND FLUID SPECIFICATION CHART



NO	TYPE	SPEC.	ℓ (gallon)
1	COOLANT	ANTI-FREEZE	13.7ℓ (3.61)
2	ENGINE	ENGINE OIL API CJ-4 SAE 15W/40	15ℓ (3.96)
3	TRANSMISSION OIL	API GL-4 - BELOW -20°C ISO VG32 - ABOVE -20°C ISO VG46	75ℓ (19.81)
4	FRONT AXLE OIL	GEAR OIL API GL-4 SAE 80W/90	17.5ℓ (4.62)
5	FUEL TANK	DIESEL	110ℓ (29.05)
6	LIFT ROD, CHECK LINK	GREASE	-
7	FRONT AXLE TIE ROD	GREASE	-
8	UREA	ISO22241 OR DIN70070	18ℓ (4.75)

## 5. INSPECTING ELECTROHYDRAULIC SYSTEM

### ► CALIBRATION FOR REPLACEMENT OF POSITION SENSOR/EHR-B (BOSCH ECU)



Step 1: Start the engine.


Step 2: Set the dial to the control mode on the Bosch control panel as shown in the figure.

Step 3: Set the dial to the set point 1 as shown in the figure.

Step 4: Press the external hitch lifting button to lift the 3-point hitch.

Step 5: Press and hold the external hitch lifting button even after the 3-point hitch is fully lifted.

Step 6: Hold the external hitch lifting button until the status LED on the Bosch control panel blinks and then stops.



Step 7: When the LED on the Bosch control panel stops blinking, release the external hitch lifting button.

Step 8: Set the dial to the set point 2.

Step 9: Press the external hitch lowering button to lower the 3-point hitch.

Step 10: Press and hold the external hitch lowering button even after the 3-point hitch is fully lowered.

Step 11: Hold the external hitch lowering button until the status LED on the Bosch control panel blinks and then stops.

Step 12: When the LED on the Bosch control panel stops blinking, release the external hitch lowering button.

Step 13: Stop the engine, wait for 5 seconds and turn the ignition switch to the "ON" position for 5 seconds.




### ► ERROR CODE DISPLAY FOR HYDRAULIC SYSTEM

If an error is occurred in the hydraulic lifting/lowering system:

1. The type of the error is displayed by blinking of the status LED on the control panel.
2. The error code is displayed through the indicator on the meter panel simultaneously.

### ► ERROR CODE DISPLAY OF CONTROL PANEL STATUS LED



When there is an electric or electronic fault, the indicator (1) blinks according to the setting in the system to inform the type of the fault.

To read the error code properly, observe the number and sequence of blinking of the indicator (1) carefully.

Read an error code according to the following steps:

**Step 1:** The LED on the control panel stops for approx. 2 seconds before indicating a code.

**Step 2:** After a brief stop, it blinks for the number of the first digit of the error code at a short interval.

**Step 3:** After delivering the first digit, it stops blinking for approx. 1 second.

**Step 4:** After a brief stop, it blinks for the number of the second digit of the error code at a short interval.

The control panel LED displays one error code with the highest priority (severe fault) at one time.

To check for any other error codes, this code with the highest priority should be cleared. Then, the control panel LED displays another error code if there is any.

#### CAUTION

- Errors, that prevents the lift controls from operation, has the highest priority.

► **LED BLINKING BY ERROR CODE**

If there is an error in the system, the status LED indicates this error by blinking in the specified setting.

● : ON ○ : OFF

FAULTS CODE	1 PHASE	2 PHASE	3 PHASE	4 PHASE	DESCRIPTION
	2 SEC.	1 <sup>st</sup> DIGIT	1 SEC.	2 <sup>nd</sup> DIGIT	
11	○	●	○	●	Indicates Circuit Fault of the Lift Arm solenoid for Raising
12	○	●	○	●●	Indicates Circuit Fault of the Lift Arm solenoid for Lowering
13	○	●	○	●●●	Indicates Short Fault of the Lift Solenoid for Raising/Lowering
14	○	●	○	●●●●	Indicates Connecting Fault of Exterior (Raise and Lower) control button for Raising
15	○	●	○	●●●●●	Indicates Connecting Fault of Exterior (Raise and Lower) control button for Lowering
16	○	●	○	●●●●●●	Indicates power Supply Fault of the Lift Arm controller (In short Circuit to +10V)
17	○	●	○	●●●●●●●	Indicates power Supply Fault of the Lift Arm controller (In short Circuit to +10V)
22	○	●●	○	●●	Indicates Position Sensor Fault
23	○	●●	○	●●●	Indicates Setpoint knob fault
24	○	●●	○	●●●●	Indicates Upper limit knob fault
28	○	●●	○	●●●●●●●●	Indicates Control Lever(Lift / stop / lowering) Switch fault
31	○	●●●	○	●	Indicates Left Draft Sensor Fault
32	○	●●●	○	●●	Indicates Left Draft Sensor Fault
33	○	●●●	○	●●●	Indicates Low battery voltage fault (below+8v)
34	○	●●●	○	●●●●	Indicates Lowering speed control knob fault
36	○	●●●	○	●●●●●	Indicates Position / Draft sensitivity control knob fault
44	○	●●●●	○	●●●●	Indicates Position Sensor needs calibration

E




### ► ERROR CODE IS DISPLAYED THROUGH THE INDICATOR ON METER PANEL SIMULTANEOUSLY

Error codes are displayed for 3P device and other devices' failure.

Find the cause and take any necessary action.

FAULT CODE	DESCRIPTION
11	Indicates Circuit Fault of the Lift Arm solenoid for Raising
12	Indicates Circuit Fault of the Lift Arm solenoid for Lowering
13	Indicates Short Fault of the Lift Solenoid for Raising/Lowering
14	Indicates Connecting Fault of the Exterior (raise and Lower) control button for Raising
15	Indicates Connecting Fault of the Exterior (raise and Lower) Control Button for Lowering
16	Indicate Power Supply Fault of the Lift Arm Controller (In short Circuit to +10V)
17	Indicate Power Supply Fault of the Lift Arm Controller (In short Circuit over +16V)
22	Indicates Position Sensor Fault
31	Indicates Right Daft Sensor Fault
32	Indicates Left Daft Sensor Fault
1301	Pressure too low at Hydraulic Clutch
1402	Short or Connecting fault at 4WD drive Solenoid
1403	Short or Connecting fault at Power shift (High/Low speed) Solenoid
1405	Short or Connecting fault at Forward Drive Terminal Solenoid
1406	Short or Connecting fault at Reverse Drive Terminal Solenoid
2301	Short or Connecting fault at Shuttle S/W
2302	Short or Connecting fault at strainer



# **TROUBLESHOOTING**

1. ENGINE TROUBLESHOOTING . . . . . F – 2
2. BRAKE, CLUTCH TROUBLESHOOTING . . . . . F – 5
3. STEERING WHEEL & HYDRAULIC SYSTEM  
TROUBLESHOOTING . . . . . F – 6
4. ELECTRIC INSTRUMENTS TROUBLESHOOTING . . F – 7

## 1. ENGINE TROUBLESHOOTING

### ► ENGINE

	ISSUE	CAUSE	ACTION
ENGINE	The start motor does not rotate when the key switch is turned	<ul style="list-style-type: none"> <li>• Clutch pedal is released</li> <li>• PTO switch is on 「ON」 position</li> <li>• Defective safety switch</li> <li>• Battery discharged</li> <li>• Loose terminal</li> <li>• Faulty key switch</li> <li>• Defective start motor</li> </ul>	<ul style="list-style-type: none"> <li>• Depress clutch pedal</li> <li>• Set PTO switch into 「OFF」 position</li> <li>• Have it repaired or replaced by workshop</li> <li>• Charge battery</li> <li>• Check for looseness and corrosion Clean, tighten and apply grease</li> <li>• Have it repaired or replaced by workshop</li> <li>• Have it repaired or replaced by workshop</li> </ul>
	The start motor runs, but its speed cannot be increased	<ul style="list-style-type: none"> <li>• Weak battery</li> <li>• Poor ground</li> <li>• Incorrect viscosity of engine oil</li> </ul>	<ul style="list-style-type: none"> <li>• Charge battery.</li> <li>• Clean contact and connect ground firmly</li> <li>• Change engine oil with proper viscosity</li> </ul>
	The start motor runs, but engine cannot be started	<ul style="list-style-type: none"> <li>• Air in fuel system</li> <li>• Clogged fuel filter</li> <li>• No fuel supply</li> <li>• Defective engine</li> <li>• Defective key stop unit</li> </ul>	<ul style="list-style-type: none"> <li>• Bleed the system</li> <li>• Clean or replace the filter</li> <li>• Open the cork and add fuel</li> <li>• Have it repaired or replaced by workshop</li> <li>• Have it repaired or replaced by workshop</li> </ul>
	Engine runs irregularly	<ul style="list-style-type: none"> <li>• Air in fuel system</li> <li>• Clogged fuel filter</li> <li>• Clogged injection nozzle</li> <li>• Fuel leak from pipe</li> <li>• Poor fuel injection</li> </ul>	<ul style="list-style-type: none"> <li>• Bleed the system</li> <li>• Clean or replace the filter</li> <li>• Have it repaired or replaced by workshop</li> <li>• Tighten clamp, replace pipe or machine surface of copper washer before installation</li> <li>• Have it repaired or replaced by workshop</li> </ul>
	Engine stops at low speed	<ul style="list-style-type: none"> <li>• Defective injection pump</li> <li>• Incorrect engine valve clearance</li> <li>• Low idle speed</li> <li>• Faulty nozzle</li> </ul>	<ul style="list-style-type: none"> <li>• Have it repaired or replaced by workshop</li> <li>• Have it repaired or replaced by workshop</li> <li>• Adjust speed to the rated speed</li> <li>• Have it repaired or replaced by workshop</li> </ul>

	ISSUE	CAUSE	ACTION
<b>E N G I N E</b>	The engine overruns	<ul style="list-style-type: none"> <li>• Clogged governor by foreign material or dust</li> <li>• Oil increased</li> </ul>	<ul style="list-style-type: none"> <li>• Have it repaired or replaced by workshop</li> <li>• Have it repaired or replaced by workshop</li> </ul>
	The engine stalls suddenly	<ul style="list-style-type: none"> <li>• Insufficient fuel</li> <li>• Faulty nozzle</li> <li>• Engine seizure by insufficient oil or poor lubrication</li> </ul>	<ul style="list-style-type: none"> <li>• Add more fuel and bleed the system</li> <li>• Have it repaired or replaced by workshop</li> <li>• Have it repaired or replaced by workshop</li> <li>• Pull the fan belt.</li> </ul> <p>If crank pulley is moved, it may indicate insufficient fuel and faulty nozzle</p>
	The engine is overheated	<ul style="list-style-type: none"> <li>• Insufficient coolant amount</li> <li>• Loose or damaged fan belt</li> <li>• Clogged radiator</li> <li>• Insufficient engine oil</li> </ul>	<ul style="list-style-type: none"> <li>• Add coolant</li> <li>• Adjust fan belt tension or replace it</li> <li>• Clean radiator</li> <li>• Inspect and replenish</li> </ul>
	The engine produces white or black smoke	<p>White smoke</p> <ul style="list-style-type: none"> <li>• Clogged air cleaner</li> <li>• Excessive engine oil amount</li> <li>• Insufficient fuel delivery amount</li> </ul> <p>Black smoke</p> <ul style="list-style-type: none"> <li>• Low quality fuel</li> <li>• Excessive fuel amount delivery</li> <li>• Insufficient nozzle pressure</li> </ul>	<p>White smoke</p> <ul style="list-style-type: none"> <li>• Clean air cleaner element</li> <li>• Check and set the proper amount</li> <li>• Have it repaired or replaced by workshop</li> </ul> <p>Black smoke</p> <ul style="list-style-type: none"> <li>• Add specified fuel</li> <li>• Have it repaired or replaced by workshop</li> <li>• Have it repaired or replaced by workshop</li> </ul>



	ISSUE	CAUSE	ACTION
E N G I N E	The engine power is insufficient	<ul style="list-style-type: none"><li>• Clogged or carbon on nozzle tip</li><li>• Insufficient compression or gas leak from valve seat</li><li>• Incorrectly adjusted valve clearance</li><li>• Incorrect injection timing</li><li>• Insufficient fuel</li><li>• Clogged air cleaner</li></ul>	<ul style="list-style-type: none"><li>• Have it repaired or replaced by workshop</li><li>• Add more fuel</li><li>• Clean the air cleaner element</li></ul>
	The oil warning lamp comes on during driving	<ul style="list-style-type: none"><li>• Low engine oil level</li><li>• Low viscosity of engine oil</li><li>• Faulty pressure switch</li><li>• Defective oil pump</li><li>• Oil filter element clogged</li></ul>	<ul style="list-style-type: none"><li>• Add engine oil to specified level</li><li>• Change oil with proper viscosity</li><li>• Replace the switch</li><li>• Have it repaired by workshop</li><li>• Replace the element</li></ul>
	The charge warning lamp comes on during driving	<ul style="list-style-type: none"><li>• Defective wiring</li><li>• Defective alternator</li><li>• Defective battery or insufficient distilled water</li><li>• Loose or damaged fan belt</li></ul>	<ul style="list-style-type: none"><li>• Check for loose or missing terminal, short circuit and poor ground and repair as necessary</li><li>• Have it repaired by workshop</li><li>• Replace the battery or add distilled water</li><li>• Adjust the tension or replace the belt</li></ul>

**2. BRAKE, CLUTCH TROUBLESHOOTING****► BRAKE**

	ISSUE	CAUSE	ACTION
<b>B R A K E</b>	Brake does not operate or brake on one side operates only	<ul style="list-style-type: none"> <li>• Excessive brake pedal free play</li> <li>• Worn or seized liner</li> <li>• Different play of left and right pedals</li> </ul>	<ul style="list-style-type: none"> <li>• Adjust the free play</li> <li>• Have it repaired by workshop</li> <li>• Set the left and right free play to the same</li> </ul>
	The brake pedal does not return to its original position properly	<ul style="list-style-type: none"> <li>• Damaged brake return spring</li> <li>• No grease on sliding part</li> </ul>	<ul style="list-style-type: none"> <li>• Replace the spring</li> <li>• Remove rust and apply grease</li> </ul>

**► CLUTCH**

	ISSUE	CAUSE	ACTION
<b>C L U T C H</b>	The clutch slips	<ul style="list-style-type: none"> <li>• Poorly adjusted pedal</li> <li>• Worn or seized clutch lining</li> </ul>	<ul style="list-style-type: none"> <li>• Adjust the pedal free play</li> <li>• Have it repaired or replaced by workshop</li> </ul>
	The clutch cannot be disengaged	<ul style="list-style-type: none"> <li>• Corroded clutch lining</li> <li>• Poorly adjusted pedal</li> </ul>	<ul style="list-style-type: none"> <li>• Have it repaired by workshop</li> <li>• Adjusted pedal free play</li> </ul>

### 3. STEERING WHEEL & HYDRAULIC SYSTEM TROUBLESHOOTING

#### ► STEERING WHEEL

	ISSUE	CAUSE	ACTION
S T E E R I N G	The steering wheel feels heavy or The steering wheel vibrates	<ul style="list-style-type: none"> <li>• Improper toe-in</li> <li>• Incorrect tire inflation pressure</li> <li>• Vibration from each connection</li> </ul>	<ul style="list-style-type: none"> <li>• Adjust toe-in</li> <li>• Set left and right tires to same specified pressure</li> <li>• Tighten or replace connection</li> </ul>
	The free movement of steering wheel is excessive	<ul style="list-style-type: none"> <li>• Worn steering wheel shaft</li> <li>• Worn metal parts</li> <li>• Free play from each connection</li> </ul>	<ul style="list-style-type: none"> <li>• Have it repaired by workshop</li> <li>• Have it repaired by workshop</li> <li>• Tighten free play of each connection</li> </ul>

#### ► HYDRAULIC SYSTEM

	ISSUE	CAUSE	ACTION
H Y D R A U L I C	Oil leaks from the pipe or hose	<ul style="list-style-type: none"> <li>• Loose clamps</li> <li>• Cracked pipes</li> </ul>	<ul style="list-style-type: none"> <li>• Tighten clamps</li> <li>• Have it replaced by workshop</li> </ul>
	Hydraulic pressure won't be decreased	<ul style="list-style-type: none"> <li>• Lowering speed control lever fixed</li> <li>• Defective valve</li> <li>• Damaged cylinder</li> <li>• Damaged and seized lift shaft rotating part</li> </ul>	<ul style="list-style-type: none"> <li>• Set it to the lowering position</li> <li>• Have it repaired by workshop</li> <li>• Have it repaired by workshop</li> <li>• Have it repaired by workshop</li> </ul>
S Y S T E M	The hydraulic pressure won't be increased	<ul style="list-style-type: none"> <li>• Insufficient engine RPM</li> <li>• Insufficient transmission fluid</li> <li>• Air sucked into suction pipe</li> <li>• Clogged oil filter</li> <li>• Defective hydraulic pump</li> <li>• Defective valve</li> <li>• Damaged cylinder</li> </ul>	<ul style="list-style-type: none"> <li>• Set the speed to 1,000 to 1,500 RPM</li> <li>• Add to the specified level</li> <li>• Tighten the connection. If any pipe or hose is cracked or O-ring is damaged, replace them.</li> <li>• Have it repaired by workshop</li> <li>• Have it repaired by workshop</li> <li>• Have it repaired by workshop</li> </ul>

**4. ELECTRIC SYSTEM TROUBLESHOOTING**

**► ELECTRIC SYSTEM**

	ISSUE	CAUSE	ACTION
<b>E L E C T R I C  S Y S T E M</b>	The battery won't be charged	<ul style="list-style-type: none"> <li>• Blown fusible link</li> <li>• Defective wiring</li>   <li>• Defective alternator</li> <li>• Loose or damaged fan belt</li> <li>• Defective battery function</li> </ul>	<ul style="list-style-type: none"> <li>• Check the wiring and replace the fusible link</li> <li>• Check for loose or missing terminal, short circuit and poor ground and repair as necessary</li> <li>• Have it repaired by workshop</li> <li>• Adjust the tension or replace the belt</li> <li>• Check for loose or corroded terminal and insufficient electrolyte and take any necessary action</li> </ul>
	The headlamp does not produce enough light	<ul style="list-style-type: none"> <li>• Low charging level of battery</li> <li>• Contact failure in wiring</li> </ul>	<ul style="list-style-type: none"> <li>• Charge</li> <li>• Check, clean and re-tighten the ground and terminal</li> </ul>
	The headlamp does not come on	<ul style="list-style-type: none"> <li>• Blown bulb</li> <li>• Blown fuse</li> <li>• Contact failure</li> </ul>	<ul style="list-style-type: none"> <li>• Replace the bulb</li> <li>• Check the wiring and replace the fuse</li> <li>• Check and clean the ground and terminal</li> </ul>
	The horn does not operate	<ul style="list-style-type: none"> <li>• Defective horn switch</li> <li>• Defective wiring</li> <li>• Damaged horn</li> </ul>	<ul style="list-style-type: none"> <li>• Replace</li> <li>• Repair</li> <li>• Repair or replace</li> </ul>
	The turn signal lamp does not blink	<ul style="list-style-type: none"> <li>• Blown bulb</li> <li>• Defective flasher unit</li> <li>• Poor contact</li> </ul>	<ul style="list-style-type: none"> <li>• Replace the bulb</li> <li>• Replace</li> <li>• Check and clean the ground and terminal</li> </ul>
	The work lamp does not come on	<ul style="list-style-type: none"> <li>• Blown bulb</li> <li>• Contact failure</li> </ul>	<ul style="list-style-type: none"> <li>• Replace the bulb</li> <li>• Check and clean the ground and terminal</li> </ul>

**F**





## **STANDARD FOR FARMWORK**

TO ENSURE SAFE AGRICULTURAL WORK, SAFETY PRECAUTIONS FOR USE OF AGRICULTURAL MACHINERY ARE SET BY THE NATIONAL INSTITUTE OF AGRICULTURAL ENGINEERING.

READ THIS INFORMATION THOROUGHLY ALONG WITH THE USER MANUAL TO ENSURE SAFE WORK.



## 1. STANDARD FOR FARMWORK

### ► SAFETY MARK

Always make sure to check the operating condition of the safety lamp (such as turn signal lamp) before operating the machine.

※ If any lighting system is removed※  
It may lead to an unexpected accident because it is not possible to give signals to people or machine nearby.

### ► INSTRUCTION BEFORE USE

Operator must attend his/her health and should get enough rest.

Before using the machine, check it and repair if there is a malfunction.

- Check if the assembly of front and rear wheels is okay.
- Check the tightening of bolts and nuts in each unit.

Do not drive if you are mentally unstable, drunk, pregnant, under the age of 16, not trained, overworked, sick, under the influence of drugs, and any other reason that may affect normal operation of the machine.

Please wear the appropriate working clothing.

- Put on a hard hat to protect your head.
- Put on a hat and a working clothes, to prevent an injury such as being twined into the machine.

- Protective measures to prevent any injury on foot or slipping - Put on an appropriate non-slippery shoes to prevent a fall from the machine, scattering soil, and slippery surface.
- Measures against dust and toxic gas.
- Wear an appropriate protective gear.
- Measures against the herbicide : wear protective gear to protect respiratory system, eyes and skin.
- Measures against noise : wear a protective gear to protect your ears.
- Handling protective gear : do neither let children get on the machine nor get close to the machine.

If it is not possible to park the agricultural machine on a road either due to a breakdown or any other reason, operator must take an action such as moving the equipment to a place other than a road.

Also, put a signal that there is a broken car, 100m behind and 200m at night in accordance with Automobile Regulation Article 23.

When starting to drive, make sure to check around carefully.

- Do not let anyone such as a child get close to the machine, keep them away and then drive the machine.

Do not load flammable, explosive material (diesel, gasoline , etc) on the machine.

When getting on and off a truck, have a helper give you signal and follow his/her lead.

Refer to chapter A in user's manual regarding the decals on the machine.

### ▶ CHECKUP LIST FOR OPERATION

Before using the machine, check it and repair if there is a malfunction.

Check engine oil.

- Pull out level gauge, wipe off any fuel leak, put it back in, and pull it out again to see if the oil level is between 「upper limit」 and 「lower limit」 .

Before any operation, check for any foreign materials caught on the engine, muffler, battery, and the fuel tank. Remove them immediately.

Covers that are removed during the maintenance work should be reinstalled to their original positions.

- Attach the cover correctly and firmly.

### ▶ CAUTIONS DURING THE WORK

Do not load anything that can interfere driving.

- Always keep the driver's seat clean.

Always buckle up when driving.

Opening radiator cap when heated can spring out the steam to have the operator burned.

Open the cap after it is sufficiently cooled down.

Do not drive with depressing the differential gear pedal.

Prohibit anyone to get on the machine.

- Prohibit anyone to get on the machine other than the designated place.
- Even though there are some designated place, do not let people more than capacity get on the machine.



- Never let any passenger mount on the machine.  
Also, do not put any object on the machine.  
Keep people away from the machine.
- Do not jump on/off the operating machine except for emergency.

Be cautious not to let anyone touch the belt .

Always check the connected area of belt. When two people are working collaboratively, exchange signals each other.

Prevent injury.

- Do not touch power transmission gear, rotating unit, and other dangerous parts.
- Pay special attention if you are working with the machine with blade or sharp projection.
- Be careful not to injure from the work where soils and stones are scattered around.

Safety in inspection, adjustment, etc.

- Make sure to stop the motor and carry out the work in a safe environment.
- When leaving the machine for a break, or other reason, leave the machine in a safe place and descend the working unit to keep them in a safe stopped state.

Removing and installing should be carried out in a safe place and with a safe method.

Do neither stay nor insert foot under the working units.

## ► CAUTIONS WHEN DRIVING ON FARM ROAD

Driving on roads

- Drive safely observing the relevant regulation.
- Drive at safe speed.
- Be careful not to disturb other drivers.
- When driving a machine with sharp blade or bump, put on a warning sign or detach in advance to prevent any injury.
- Do not drive fast particularly on winding roads with projecting rocks.
- When driving at night, do not detach lighting device. (headlight, turn indicator, work light, brake light, etc.)
- Do not drive fast, abrupt starting, abrupt acceleration, sudden stop, and quick turning.
- When driving at high speed, do not slam on the brake. Never slam on the brake especially when turning at high speed.

When loading/unloading the machine

- Choose a place with a leveled and safe ground.
- Drive at low speed.
- Use a ramp with anti-slippery.

When entering paved road

- Use a ramp to cross a ditch or a bank.
- Make sure to use a ramp to enter/exit a high footpath. Be careful with fall and not to overturn.
- Check the safety around the surrounding before starting to drive.

When driving on a slope

- Drive at the minimum speed, lower the operating machine as low as possible and low the center position.

### ► INSTRUCTION AFTER USE

When the work is completed, stop the engine on a leveled ground, check the machine to clean. (remove any foreign materials)

- Remove straws, dirt, etc. and clean around the engine, silencer, and fuel tank.

Lay a cover on the transplanter (equipment) after the muffler and engine cool down.

Get a regular inspection after the season is over.

- When discarding a part (battery, oil, etc.) or scrap a machine, consult to a dealer and proceed accordingly.

For long-term storage, remove the battery from the machine and store it or disconnect the negative battery cable.

### ► CAUTIONS FOR INSPECTION & MAINTENANCE

Do not refuel either when the engine is still hot or while driving.

Measures against a fire: Every working place with a risk of fire should be provided with a fire extinguisher. Prevent a fire by taking measures such as making a smoking area.

Always wipe off the leaked fuel.

Be seated in the cab when starting the engine.

After refueling, tighten the fuel cap and check if there is any fuel leakage from tank or pipe.

When opening a cap to supply water to radiator, be careful because steam or boiling water may spray due to overheating.



## ► TRACTOR

When getting off the cab, turn off the engine, lock the parking brake and remove the ignition key.

If it is inevitable to park on a slope, choke the wheels.

Park on a leveled and safe ground safely.

Check if the wiring code is in contact with other parts, peeled, loose or having spacing.

Manage PTO

- Stop PTO before stopping the engine.
- Do not remove the PTO protective cover or protective panel for operating machine.
- Do not use PTO adaptor in order to extend the PTO coupler or universal joint to outside of PTO protective cover.

To repair, secure the wheel width, or changing the wheel under either tractor or trailer, with the tractor or trailer raised, choke the wheels that are on the ground.

Do not use hydraulic jack for operating machine or tractor. Instead, use block or stand.

Safety frame

- Do neither weld nor drill a hole on the attached safety frame. Also do not modify it.
- Replace the damaged safety frame with a new one.

- If the safety frame was removed for specialized work, restore it immediately.

Be careful to touch dangerous area such as power transmission gear, rotating unit, etc. Put on a protective cover.

Do neither modify nor remove the safety device.

When checking and replacing the blade to plow the ground

- Stop the engine.
- Prevent the rotary from falling by turning the fall adjusting handle to stop hydraulic pressure.
- Apply the parking brake.
- Do not stand between tractor and rotary.

When working with rotary

- Do not put your hands near the rotating part such as blade axle and universal joint.

- Do not ride on the rotary.
- When driving backward or turning quickly with the rotary raised up, make sure to check behind the machine.
- Adjust the rear cover.


### ► OTHER PRECAUTIONS

The following items can affect the tractor performance and safety.

Therefore, Repair of these items should be done by your workshop.

- Injection pump, nozzle, engine valve clearance, hydraulic valve, hydraulic pump and evaporator.





## **APPENDIX**

- 1. SPECIFICATION . . . . . H - 2
- 2. STANDARD PARTS . . . . . H - 4
- 3. MAJOR CONSUMABLES . . . . . H - 5
- 4. ENGINE EMISSION WARRANTY . . . . . H - 7



## 1. SPECIFICATION

ITEM		T854	T954(US), T954/T1004(EU)	T1054/T1104
DIMENSIONS	OVERALL LENGTH	177 (4,500)	177 (4,500)	177 (4,500)
	OVERALL WIDTH	97.2 (2,470)	97.2 (2,470)	99 (2,517)
	OVERALL HEIGHT	107.9 (2,740)	107.9 (2,740)	107.9 (2,740)
	MIN. GROUND CLEARANCE	18.3 (465)	18.3 (465)	18.3 (465)
	WEIGHT	155 (3,941)	155 (3,941)	155 (3,941)
ENGINE	MANUFACTURER	DOOSAN INFRACORE	DOOSAN INFRACORE	DOOSAN INFRACORE
	MODEL NUMBER	DL03-LEA06	DL03-LEA05	DL03-LEA04
	DISPLACEMENT	3,409	3,409	3,409
	POWER/ROTATION SPEED	63.4/2,300	70.9 / 2,300	78.3 / 2,300
	OPERATING FUEL	Diesel fuel	Diesel fuel	Diesel fuel
	FUEL TANK CAPACITY	110	110	110
TIRES	FRONT TIRE	13.6 - 24	13.6 - 24	13.6 - 24
	REAR TIRE	16.9 - 34	16.9 - 34	18.4 - 34
DRIVE SYSTEM	CLUTCH (DAMPER)	Dry	Dry	Dry
	BRAKING	Hydraulic	Hydraulic	Hydraulic
	TRANSMISSION TYPE	Power Shuttle, Power Shift	Power Shuttle, Power Shift	Power Shuttle, Power Shift
	NUMBER OF SPEED	F32/ R32	F32/ R32	F32/ R32
	MAX SPEED	FORWARD	0.25 (0.4) ~ 22.4 (36)	0.25 (0.4) ~ 22.4 (36)
REVERSE		0.25 (0.4) ~ 22.2 (35.80)	0.25 (0.4) ~ 22.2 (35.80)	0.25 (0.4) ~ 23 (37.00)
PTO	REVOLUTION	540 / 750 / 1000	540 / 750 / 1000	540 / 750 / 1000
IMPLEMENT CONTROL TYPE		Electronically Controlled - Position/Draft		
DRAFT SYSTEM		Swing Drawbar		

► **DRIVING SPEED (T1054/T1104)**

Range Shift		C				L				M				H				MAX RPM
Main Shift		1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4	
Forward	Low	0.42	0.56	0.79	1.02	1.27	1.70	2.38	3.10	3.78	5.05	7.08	9.21	12.81	17.14	24.02	31.24	
	High	0.50	0.67	0.94	1.22	1.51	2.02	2.83	3.69	4.50	6.02	8.43	10.97	15.24	20.40	28.59	37.18	39.61
Reverse	Low	0.42	0.56	0.78	1.02	1.26	1.69	2.37	3.08	3.76	5.03	7.05	9.17	12.74	17.05	23.90	31.09	
	High	0.48	0.65	0.90	1.18	1.46	1.95	2.74	3.56	4.35	5.81	8.15	10.60	14.74	19.72	27.64	35.94	


► **DRIVING SPEED (T954/US) (T854,T954,T1004/EU)**

Range Shift		C				L				M				H				Max RPM
Main Shift		1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4	
Forward	Low	0.41	0.54	0.76	0.99	1.23	1.64	2.30	3.00	3.65	4.89	6.85	8.91	12.39	16.58	23.24	30.23	
	High	0.48	0.65	0.91	1.18	1.46	1.96	2.74	3.57	4.35	5.82	8.16	10.61	14.75	19.73	27.66	35.98	38.32
Reverse	Low	0.40	0.54	0.76	0.98	1.22	1.64	2.29	2.98	3.64	4.87	6.82	8.87	12.33	16.50	23.13	30.08	
	High	0.47	0.62	0.88	1.14	1.41	1.89	2.65	3.45	4.20	5.63	7.89	10.26	14.26	19.08	26.74	34.78	

※ The above driving speed table is based on the engine speed at 2,300 RPM.


※ The specifications are subject to change for the purpose of improvement without notice.

**2. STANDARD PARTS**




NO	ITEM	SPEC.	QTY.
1	OPERATOR MANUAL		1
2	HYDRAULIC FILTER CART.		2
3	KEY SET		1
4	BALL		2
5	MANUAL FOR BLUETOOTH		1
6	REMOTE CONTROLLER		1
7	BOLT SET		2
8	BAG		1


### 3. MAJOR CONSUMABLES




FUEL FILTER ELEMENT




ENGINE OIL FILTER




HYDRAULIC OIL FILTER CARTRIDGE



FAN BELT



A/C BELT



HIGH-PRESSURE FILTER ELEMENT

H



<b>NO</b>	<b>COMPONENT</b>	<b>APPLICABLE ITEM</b>	<b>QUANTITY</b>
1	Fuel filter element	Fuel	1
2	Engine oil filter	Engine oil	1
3	Hydraulic oil filter cartridge	Hydraulic oil	2
4	Fan belt	Engine	1
5	A/C belt	A/C	1
6	High-pressure filter element	Hydraulic oil	1

## 4. ENGINE EMISSION WARRANTY

### ► OWNER'S WARRANTY RIGHTS AND OBLIGATIONS

The U.S. Environmental Protection Agency (EPA), the California Air Resources Board (ARB), and DOOSAN INFRACORE are pleased to explain the Federal and California Emission Control System Warranty on your 2021MY to 2023MY non-road engine. DOOSAN INFRACORE has designed, built and equipped the engine so as to conform at the time of sale with all applicable regulations of the EPA and of the California ARB. In California, new heavy-duty off-road engines must be designed, built and equipped to meet the State's stringent anti-smog standards.

DOOSAN INFRACORE must warrant to the initial owner, and each subsequent owner, the emission control system on your engine for the periods of time listed below provided there has been no abuse, neglect, improper maintenance or unapproved modifications of your engine. Your emission control system may include those parts listed next:

- 1. Fuel Metering System**  
Fuel Supply Pump (HP Pump), Injector, Common Rail, Air Heater
- 2. Air-Induction System**  
Intake Manifold, Turbocharger System
- 3. Exhaust Gas Recirculation (EGR) System**  
EGR Valve, EGR Cooler
- 4. Catalyst or Thermal Reactor System**  
Diesel Oxidation Catalyst (DOC), Exhaust Manifold, SCR System, Catalyst, NOx sensor
- 5. Positive Crankcase Ventilation (PCV) System**  
PCV Valve
- 6. Electronic Control System**  
ECU, Cam/ Crank Sensor, Coolant Temperature Sensor, MAF Sensor, MAP Sensor (Manifold Pressure Sensor), Inlet Boost Temperature Sensor, Fuel Temperature Sensor, Common Rail Pressure Sensor

- 7. Miscellaneous Items Used In Above Systems**  
Vacuum, Temperature and time sensitive valve and switches, Electronic control units, sensors, Solenoids and wiring harnesses, Hoses, clamps, fittings and tubing, Emission control information labels

Where a warrantable condition exists, TYM-USA (hereafter "TYM") will repair your heavy-duty off-road engine at no cost to you including diagnosis, parts, and labor.

### ► MANUFACTURER'S WARRANTY COVERAGE

The 2021MY to 2023MY heavy-duty off-road engines are warranted for **five years or 3,000 hours** of operation, whichever occurs first.

If any emission-related part on your engine is defective, the part will be repaired or replaced by TYM.

The warranty period shall begin on the date the machine is delivered to the first retail customer.

### ► OWNER'S WARRANTY RESPONSIBILITIES

As the heavy-duty off-road engine owner, you are responsible for the performance of the **required maintenance listed in the Operation and Maintenance Manual.**

DOOSAN INFRACORE and TYM recommends that you retain all receipts covering maintenance on your heavy-duty off-road engine, but DOOSAN INFRACORE and TYM cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

As the heavy-duty off-road engine owner, you should however be aware that DOOSAN INFRACORE and TYM may deny you warranty coverage if your heavy-duty off-road engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

Your engine is designed to operate on **Ultra Low Sulfur Diesel Fuel Only.**

Use of any other fuel may result in your engine no longer operating in compliance with the EPA's emissions requirements.

You are responsible for initiating the warranty process.

The EPA and California ARB suggest that you present your heavy-duty off-road engine to a TYM dealer as soon as a problem exists.

The warranty repairs should be completed by the dealer as expeditiously as possible.

If you have any questions regarding your warranty rights and responsibilities, you should contact your nearest authorized TYM dealer or contact TYM at

#### **TYM-USA**

4734 Potato House CT. Wilson, NC 27893, USA, 1-252-293-1224



# INDEX

1. INDEX ..... | - 2



## 0 ~ 9

12V SOCKET . . . . . C-43

## A

ABOUT THIS MANUAL . . . . . A-6

ADJUSTING LINK . . . . . C-37

ADJUSTING PEDAL PLAY . . . . . E-27

ADJUSTING TREAD . . . . . E-20

AIR CLEANER SERVICING . . . . . E-19

AIR CLEANING SYSTEM . . . . . D-20

ALWAYS USE SAFETY LIGHTS AND DEVICES . . . . . B-5

ANTI-FREEZE . . . . . E-4

APPENDIX . . . . . H-1

AUDIO SYSTEM . . . . . C-47

AVOID HIGH PRESSURE FLUIDS . . . . . B-6

## B

BACK SIDE OF THE TRACTOR . . . . . A-4

BATTERY CHARGING . . . . . D-12

BATTERY DISCONNECTION . . . . . B-8

BRAKE . . . . . D-21

BRAKE PEDAL . . . . . C-19

BRAKE TROUBLESHOOTING . . . . . F-5

## C

CABIN . . . . . C-39

CABIN REPLAY BOX . . . . . E-26

CALIBRATION FOR REPLACEMENT OF POSITION SENSOR/EHR-B (BOSCH ECU) . E-33

CAUTIONS FOF DRIVING ON ROAD . . . . D-6

CAUTIONS FOR DRIVING INTO OR OUT OF FIELD . . . . . D-6

CHECKING AND ADJUSTING A/C COMPRESSOR BELT . . . . . E-28

CHECKING AND ADJUSTING FAN BELT . . E-28

CHECKING AND ADJUSTING WATER PUMP BELT . . . . . E-28

CHECKING AND CHANGING ENGINE OIL . E-5

CHECKING AND CHANGING TRANSMISSION FLUID . . . . . E-6

CHECKING AND CHARGING BATTERY . . E-21

CHECKING AND REPLACING FUSE . . . . E-25

CHECKING ELECTRIC WIRING . . . . . E-23

CHECKS DURING DRIVING . . . . . D-12

CLEANING CONDENSER GRILL AND OIL COOLER . . . . . E-5

CLEANING FUEL FILTER . . . . . E-13

CLEANING RADIATOR GRILL AND CONDENSER GRILL . . . . . E-5

CLUTCH PEDAL . . . . . C-19

CLUTCH TROUBLESHOOTING . . . . . F-5

COLUMN SWITCH LEVER . . . . . C-6

CONNECTION TO IMPLEMENTS . . . . . D-9

CONTROLS . . . . . C-18

COOLANT TEMPERATURE . . . . . D-13

COOLING SYSTEM . . . . . D-23

## D

DAMAGE OF ROPS . . . . . A-11

DECALS ON CHASSIS . . . . . B-25

DESCRIPTION . . . . . A-8

DeSOx SWITCH AND OPERATING DESCRIPTION . . . . . C-4

DISCONNECTING BATTERY . . . . . E-24

DISCONNECTION FROM IMPLEMENTS . . D-9

DON'Ts – FOR SAFE OPERATION . . . . . B-23

DOOR LEVER . . . . . C-41

DOs – FOR BETTER PERFORMANCE . . . . B-22

DOs & DON'Ts . . . . . B-22

DRAWBAR ADJUSTMENT . . . . . C-40

DRIVER'S SEAT . . . . . C-50

## E

ELECTRIC SYSTEM TROULESHOOTING . . F-7

ELECTRONIC LIFT SYSTEM CONTROL PANEL . . . . . C-26

EMERGENCY EXITS . . . . . B-9

ENGINE . . . . . D-20

ENGINE IDLING . . . . . D-3

ENGINE TROULESHOOTING . . . . . F-2

ENSURE SAFETY INFORMATION . . . . . B-2

ERROR CODE DISPLAY FOR HYDRAULIC SYSTEM . . . . . E-34

ERROR CODE DISPLAY OF CONTROL PANEL STATUS LED . . . . . E-34

ERROR CODE IS DISPLAYED THROUGH THE INDICATOR ON METER PANEL SIMULTANEOUSLY . . . . . E-36  
 EXTERIOR VIEW . . . . . A-2  
 EXTERNAL HYDRAULIC CONTROL LEVER . . . . . C-23  
 EXTERNAL LIFTING/LOWERING SWITCH . . . . . C-28

**F**

FALLING OBJECT PROTECTIVE STRUCTURE (FOPS) . . . . . B-13  
 FAN SPEED CONTROL DIAL . . . . . C-45  
 FIGURE OF DASHBOARD . . . . . C-2  
 FOR SAFE LOADER WORK . . . . . D-18  
 FRESH AIR MODE AND RECIRCULATION MODE . . . . . C-48  
 FRESH AIR SUCTION FILTER . . . . . C-47  
 FUEL FILTER DRAINING . . . . . E-12  
 FUEL GAUGE . . . . . D-13  
 FUEL, OIL AND FLUID SPECIFICATION CHART . . . . . E-32

**G**

GENERAL IMPLEMENT . . . . . D-14  
 GENERAL INFORMATION . . . . . A-1  
 GENERAL INFORMATION OF DECALS . . . . . B-24  
 GREASING POINTS . . . . . E-21

**H**

HANDLE FUEL SAFELY AVOIDING FIRES . . . . . B-5  
 HANGER . . . . . C-43  
 HAZARD FLASHER . . . . . C-5  
 HOW TO START ENGINE . . . . . D-2

**I**

IDLING IN COLD WEATHER . . . . . D-3  
 IMPLEMENTS . . . . . D-9  
 INDEX . . . . . I-2  
 INSPECTING AND CHANGING ENGINE COOLANT . . . . . E-4  
 INSPECTING AND CHANGING FRONT AXLE OIL . . . . . E-8  
 INSPECTING ELECTROHYDRAULIC SYSTEM . . . . . E-33  
 INSPECTION ITEMS . . . . . E-3  
 INSTRUMENT PANEL . . . . . C-8  
 INTAKE/EXHAUST SYSTEM . . . . . C-51  
 INTRODUCTION & DESCRIPTION . . . . . A-7  
 INTRODUCTION OF A TRACTOR . . . . . A-7

**J**

JOYSTICK LEVER OPERATING DIRECTION . . . . . C-22  
 JOYSTICK LEVER SAFETY DEVICE . . . . . C-22  
 JUMP START . . . . . E-23

**K**

KEEP RIDERS OFF TRACTOR . . . . . B-4

**L**

LED BLINKING BY ERROR CODE . . . . . E-35  
 LEFT SIDE OF THE TRACTOR . . . . . A-3  
 LIFT ROD ADJUSTMENT . . . . . C-36  
 LOADER . . . . . D-18  
 LOADER VALVE AND JOYSTICK LEVER . . . . . C-22  
 LOADING TO OR UNLOAD FROM TRUCK . . . . . D-6  
 LOWER LINK . . . . . C-37  
 LOWER LINK CONNECTING HOLE . . . . . C-36  
 LUBRICATING OIL . . . . . D-21

**M**

MAIN SHIFT LEVER . . . . . C-20  
 MAIN SWITCH . . . . . C-3  
 MAINTENANCE . . . . . E-1  
 MAINTENANCE AND ADJUSTMENT SCHEDULE . . . . . E-30  
 MAJOR CONSUMABLES . . . . . H-5  
 MOUNTING AND DEMOUNTING IMPLEMENTS . . . . . B-17  
 MOUNTING IMPLEMENTS . . . . . D-9

**O**

OIL PRESSURE . . . . . D-12  
 OIL SYSTEM . . . . . D-21  
 OPENING COVERS . . . . . E-2  
 OPENING HOOD . . . . . E-2



OPERATING PTO . . . . .	D-7	PTO SHAFT CAP . . . . .	C-38	SAFETY TIPS DURING MAINTENANCE . . . . .	B-16
OPERATING TRACTOR . . . . .	D-4	PTO SHIFT LEVER . . . . .	C-24	SEAT ADJUSTMENT . . . . .	A-12
OPERATION . . . . .	D-1			SEAT BACK ANGLE, CUSHION STRENGTH	
OPERATION OF PTO . . . . .	D-7	<b>R</b>		ADJUSTMENT . . . . .	A-12
OPERATION TIPS . . . . .	D-20	READ SAFETY INSTRUCTION . . . . .	B-2	SEAT SLIDING . . . . .	A-12
OPERATOR PROTECTIVE STRUCTURE		REAR WINDOW LEVER . . . . .	C-41	SECONDARY SEAT . . . . .	C-50
(OPS) . . . . .	B-13	REMOTE HYDRAULIC VALVE COUPLER . . . . .	C-23	SERVICE & PARTS . . . . .	A-5
OTHERS . . . . .	D-23	REPLACING AND SERVICING HIGH		SERVICE TRACTOR SAFELY . . . . .	B-8
OUTSIDE REARVIEW MIRROR . . . . .	C-42	PRESSURE FILTER . . . . .	E-10	SERVICING EACH PART . . . . .	E-4
OWNER ASSISTANCE . . . . .	A-9	REPLACING ENGINE OIL FILTER		SHIFTING AND DRIVING . . . . .	D-4
		CARTRIDGE . . . . .	E-10	SHUTTLE SHIFT LEVER . . . . .	C-6
		REPLACING FUEL FILTER ELEMENT . . . . .	E-13	SIDE WINDOW HANDLE . . . . .	C-41
		REPLACING LAMP BULB . . . . .	E-26	SIGNAL SIGNS . . . . .	B-2
		REPLACING TRANSMISSION HYDRAULIC		SPECIFICATION . . . . .	H-2
		OIL FILTER . . . . .	E-10	STANDARD FOR FARMWORK . . . . .	G-2
		REPLACING TURN SIGNAL		STANDARD FOR TREAD ADJUSTMENT . . . . .	E-20
		LAMP/POSITION LAMP . . . . .	E-26	STANDARD PARTS . . . . .	H-4
		RIGHT SIDE OF THE TRACTOR . . . . .	A-2	START & STOP OF ENGINE . . . . .	D-2
		ROPS . . . . .	A-10	START ON STEEP SLOPE . . . . .	D-5
				STARTING OFF . . . . .	D-4
		<b>S</b>		STAY CLEAR OF ROTATING SHAFTS . . . . .	B-5
		SAFE OPERATION OF YOUR TRACTOR . . . . .	B-15	STEERING WHEEL & HYDRAULIC SYSTEM	
		SAFETY DECALS . . . . .	B-24	TROUBLESHOOTING . . . . .	F-6
		SAFETY INSTRUCTIONS . . . . .	B-2	STOPPING ENGINE . . . . .	D-3
		SAFETY PRECAUTIONS . . . . .	B-1	SUN ROOF . . . . .	C-45
		SAFETY PRECAUTIONS WHEN USING		SUN VISOR . . . . .	C-43
		LOADER . . . . .	B-10	SWITCHES AND INSTRUMENT PANEL . . . . .	C-2
		SAFETY START . . . . .	B-9		

## T

THE FOLLOWING PRECAUTIONS ARE SUGGESTED TO HELP PREVENT

- ACCIDENTS . . . . . B-18
- THREE POINT LINKAGE . . . . . C-35
- THROTTLE LEVER . . . . . C-23
- THROTTLE PEDAL . . . . . C-20
- TIPS FOR DRIVING ON SLOPE . . . . . D-5
- TIRE INFLATION PRESSURE . . . . . E-29
- TOP LINK ADJUSTMENT . . . . . C-36
- TOWING HITCH . . . . . C-37
- TOWING SAFELY . . . . . B-12
- TOWING THE TRACTOR . . . . . D-10
- TOWING WITH ENGINE OFF . . . . . D-11
- TOWING WITH ENGINE RUNNING . . . . . D-10
- TRACTOR IDENTIFICATION . . . . . A-5
- TRACTOR INSTRUMENTS . . . . . C-1
- TRACTOR RUNAWAY . . . . . B-9
- TRAILER SOCKET . . . . . D-13
- TRANSPORT TRACTOR BY TRUCK . . . . . B-12
- TROUBLESHOOTING . . . . . F-1
- TURNING IN FIELD . . . . . D-4
- TYPE OR NUMBER OF ENGINE & CHASSIS . . . . . A-5

**U**

- UNIVERSAL SYMBOLS . . . . . B-29
- UREA FILTER REPLACEMENT . . . . . E-14
- UREA TANK FILLER PORT . . . . . E-14
- USE OF HAZARDOUS SUBSTANCES . . . . . B-13

- USE OF ROPS AND SEAT BELT . . . . . B-3
- USE OF TRACTOR WITH ROPS LOWERED CAN CAUSE FATAL INJURIES . . . . . A-10

**W**

- WARRANTY OF THE PRODUCT . . . . . A-5
- WINTER OPERATION WITH DIESEL FUEL . . . . . D-23
- WORK IN VENTILATED AREA . . . . . B-8
- WORK PROCEDURES . . . . . D-14
- WORKING LAMP . . . . . C-42



# **T954, T1054, T1104 (US) T854, T954, T1004, T1054, T1104(EU)**

## **OPERATOR'S MANUAL FOR TYM TRACTORS**

⚠ ALL INFORMATION, ILLUSTRATIONS AND SPECIFICATIONS IN THIS MANUAL ARE BASED ON LATEST INFORMATION AVAILABLE AT THE TIME OF PUBLICATION.  
THE RIGHT IS RESERVED TO MAKE CHANGES AT ANY TIME WITHOUT A NOTICE.

221012

PART NO.  
1871-930-001-1