

PART LIST

(OEM)

KUKJE MACHINERY CO.,LTD.

ENGINE PART

- A01. CYLINDER BLOCK
- A02. OIL PAN
- A03. CYLINDER HEAD A04. GEAR CASE
- A05. HEAD COVER A06. OIL FILTER A07. OIL GAUGE
- A08. MAIN BEARING CASE
- A09. CAM SHAFT & IDLE SHAFT A10. PISTON & CRANK SHAFT A11. FLYWHELL
- A12. FUEL CAM SHAFT & GOVERNOR SHAFT A13. IDLE APPARATUS
- A14. FUEL INJECTION PUMP A15. GOVERNOR
- A16. SPEED CONTROL PLATE A17. INJECTOR & GLOW PLUG
- A18. WATER PUMP FLANGE % THERMOSTAT A19. WATER PUMP
- A20. ROCKER ARM
- A21. INTAKE MANIFOLD A22. EXHAUST MANIFOLD A23. STOP SOLENOID
- A24. ALTERNATOR & PULLY A25. STARTING MOTOR
- A26. EXHAUST SILENCER A27. COOLING PAN
- A28. OIL PRESSURE SWITCH
- A29. DATA PLATE A30. WATER PIPE A31. LOOSED PARTS

CONTENT

A. ENGINE PART

A1100N2-TUTR 4

A01. CYLINDER BLOCK

No. Part No. Part Name

(Q'ty)

A1100N2

Remarks

1	HT01010000A	COMP. BLOCK, CYLINDER	1	X	
2	HT01010101F	BLOCK, CYLINDER	1	X	
3	27241-280000	PLUG, EXPANSION	4	X	
4	27241-300000	PLUG, EXPANSION	1	X	
5	HM23030000A	PLUG, THREADED	1	X	
6	HT01010400A	BUSHING, MAIN	1	X	
7	HT01010900A	BUSHING, GOVERNOR	1	X	
8	HT01010200A	PLUG, PIPE	3	X	PT 1/16"
9	HT01010300A	PLUG, PIPE	3	X	PT 1/4"
10	23871-010000	PLUG, PIPE	3	X	
11	27231-180000	PLUG, EXPANSION	3	X	
12	27231-450000	PLUG, EXPANSION	1	X	
13	HT01010500A	PIN, DOWEL	2	X	
14	22312-080140	PIN, DOWEL	2	X	
15	22351-060012	PIN, SPRING	2	X	
16	HT01010600A	PIN, PIPE	2	X	
17	HT01010700A	CAP, SEALING	1	X	
18	HT01010800A	PIN, STATER SPRING	1	X	
20	23871-020000	PLUG, PIPE	1	X	PT 1/4"

No.	Part No.	Part Name	(Q'ty)	A1100N2	Remarks
1	EA00000865C	ASS'Y PAN, OIL	1	X	
2	EA00001475A	DRAIN PLUG	1	X	
3	24311-000140	O-RING	1	X	
4	26013-060122	BOLT	22	X	M6X12
5	EA00000869A	ASS'Y FILTER, OIL	1	X	
6	26013-080162	BOLT	1	X	M8X16
7	24311-000160	SEAL, O-RING	1	X	
8	HF01470000A	MAGNET	1	X	

No.	Part No.	Part	Name	(Q'ty)	
A1100N2					
Remarks					
1	EA00005521A	COMP. HEAD. CYLINDER		1	X
2	EA00005520A	COMP. HEAD, CYLINDER		1	X
3	EA00005519A	HEAD, CYLINDER		1	X
4	27241-300000	PLUG, EXPANSION		1	X
5	27241-180000	PULG, EXPANSION		2	X
6	HT03010102A	GUIDE, INLET VALVE		3	X
7	HT03010103A	GUIDE, EXHAUST VALVE		3	X
8	EA00004365A	CHAMBER, INJECTION		3	X
9	23871-010000	PLUG, PIPE		3	X PT 1/8"
10	HT03010200A	VALVE, INLET		3	X
11	HT03010300A	VALVE, EXHAUST		3	X
12	HT03010400A	SPRING, VALVE		6	X
13	HT03010500A	RETAINER, VALVE SPRING		6	X
14	HT03010600A	COLLCET, VALVE SPRING		12	X
15	HC03090000A	SEAL, VALVE STEM		6	X
17	HT03020000A	HOOK, ENGINE		2	X
19	26013-080122	BOLT		3	X M8X12
20	HT03030000A	BOLT, CYLINDER HEAD		14	X
22	HT03040000B	GASKET, CYLINDER HEAD		1	X
23	EA00000545A	CAP, VALVE		6	X
24	EA00000961A	SEAT, INLET		3	X
25	EA00000962A	SEAT, EXHAUST		3	X

No.	Part No.	Part	Name	(Q'ty)	A1100N2
Remarks					
1	EA00005393A	COMP. CASE GEAR		1	X
2	HT04010100D	CASE, GEAR		1	X
3	23871-030000	PLUG, EXPANSION		2	X
4	23871-010000	PLUG, EXPANSION		1	X
5	EA00001446A	SEAL, OIL		1	X
7	22117-180000	WASHER, PLAIN		1	X
8	HT04020100A	PIPE, JOINT		1	X
9	HT04020200B	SPRING		1	X
10	HT04020300A	SEAT		1	X
11	24190-160001	BALL, STEEL		1	X
12	HT04030000A	ASS'Y ROTOR, OIL PUMP		1	X
13	26577-060202	SCREW		5	X
14	HT04050000A	COVER, OIL PUMP		1	X
15	HT04060000A	GASKET, GEAR CASE		1	X
16	26013-060452	BOLT		3	X M6X45
17	26013-060502	BOLT		5	X M6X50
18	26013-060552	BOLT		3	X M6X55
19	HT04070000A	BOLT		1	X M6X68
20	26013-060602	BOLT		1	X M6X60
21	26216-060452	STUD		1	X
22	26716-060002	NUT		1	X M6
23	22217-060000	WASHER, LOCK		1	X
24	24311-240100	SEAL, O-RING		2	X
25	24311-000150	SEAL, O-RING		2	X
26	HC03470000B	CAP, FILLER		1	X
27	24311-000320	SEAL, O-RING		1	X
28	22117-060000	WASHER, PLAIN		1	X

No.	Part No.	Part	Name	(Q'ty)	
A1100N2					
Remarks					
1	HT05080000C	COMP. COVER. CYL. HEAD		1	X
2	HT05080100E	COVER, CYL. HEAD		1	X
3	HT05080200A	GASKET, HEAD COVER		1	X
4	HT05080300A	COVER, BREATHER		1	X
5	HT05080400A	SPRING, BREATHER		1	X
6	HT05080500A	PLATE, SPRING		1	X
7	HT05080600A	VALVE, BREATHER		1	X
8	26022-050102	SCREW, WASHER		4	X
9	HT05080700A	SHIELD, BREATHER		1	X
10	26022-030062	SCREW, WASHER		2	X
11	HT05080800B	JOINT, BREATHER		1	X
14	26667-080002	NUT, CAP		3	X
15	23414-080012	WASHER, SEALING		3	X
16	HT05100000A	PIPE, BREATHER		1	X

17	23000-016000	CLIP, V BAND		2	X	
18	HT05080800B	JOINT, BREATHER		1	X	
No.	Part No.	Part Name	(Q'ty)			
A1100N2						
Remarks						
01	EA0003786A	ELEMENT, LUB. OIL FILTER		1	X	
No.	Part No.	Part Name	(Q'ty)		A1100N2	Remarks
1	EA00004584A	GAUIDE, OIL GAUGE		1	X	
02	EA00005296A	OIL GAUGE		1	X	
No.	Part No.	Part Name	(Q'ty)			
A1100N2						
Remarks						
1	HT08010000A	ASS'Y CASE(A), MAIN BRG.		1	X	
2	HT08010100A	CASE(A), MAIN BRG.		1	X	
3	22312-040080	PIN, DOWEL		2	X	
4	HT08010103A	BOLT 1, BRG. CASE		2	X	
5	HT08020000A	GASKET, BRG. CASE		1	X	
6	HT08030000B	ASS'Y COVER, BRG. CASE		1	X	
7	HT08030100A	COVER, BRG. CASE		1	X	
8	EA00001308A	SEAL, OIL		1	X	
9	HT08040000A	GASKET, BRG. CASE COVER		1	X	
10	26014-060252	SCREW, CAPTIVE WASHER CAP		8	X	
11	26014-060202	SCREW, CAPTIVE WASHER CAP		9	X	
12	HT08050000A	ASS'Y CASE(C), MAIN BRG.		1	X	
13	HT08050100A	CASE(C), MAIN BRG.		1	X	
14	22312-040080	PIN, DOWEL		2	X	
15	HT08010103A	BOLT 1, BRG. CASE		2	X	
16	HT08060000A	BOLT 2, BRG. CASE		2	X	
17	HT08070000A	ASS'Y CASE(B), MAIN BRG.		1	X	
18	HT08070100A	CASE(B), MAIN BRG.		1	X	
19	22312-040080	PIN, DOWEL		2	X	
20	HT08010103A	BOLT 1, BRG. CASE		2	X	
21	22117-060000	WASHER, PLAIN		9	X	
22	22217-060000	WASHER, SPRING		9	X	
No.	Part No.	Part Name	(Q'ty)			
A1100N2						
Remarks						
1	HT09010000A	TAPPET		6	X	
2	HT09020000A	PUSH ROD		6	X	
3	HT09030000A	COMP. CAMSHAFT		1	X	
4	HT09030100A	CAMSHAFT		1	X	
5	HT09030200A	GEAR, CAMSHAFT		1	X	
6	22512-050180	KEY, SQUARE		1	X	
7	HT09030300A	STOPPER, CAMSHAFT		1	X	
8	26013-060142	BOLT		2	X	M6X14
9	HT09040000A	COMP. GEAR(A), IDLE		1	X	
10	HT09040200A	BUSH, IDLE GEAR		1	X	
11	HT09050000A	COLLAR 1, IDLE GEAR		1	X	
12	HT09060000A	COLLAR 2, IDLE GEAR		1	X	
13	HT09070000A	CIR. CLIP, IDLE GEAR		1	X	
14	HT09080000A	SHAFT(A), IDLE GEAR		1	X	
15	26013-060162	BOLT		3	X	M6X16
No.	Part No.	Part Name	(Q'ty)		A1100N2	Remarks
01	HT10010000B	PISTON		3	X	
02	HT10020000A	COMP. RING, PISTON		3	X	
03	HT10020100A	RING(1st), PISTON		3	X	
04	HT10020200A	RING(2nd), PISTON		3	X	
05	HT10020300A	RING, OIL		3	X	
06	HT10030000A	PIN, PISTON		3	X	
07	HT10040000A	CIR. CLIP, PISTON PIN		6	X	
08	HT10050000A	ASS'Y CONNECTING ROD		3	X	
09	HT10050100A	CONNECTING ROD		3	X	
10	HT10050200A	BUSHING, PISTON PIN		3	X	
11	HT10050300A	BOLT, CONNECTING ROD		6	X	
12	HT10060000A	COMP. METAL, CRANKPIN		3	X	
	HT10060100A	METAL, CRANKPIN		6	X	

13	HT10070000B	COMP. CRANKSHAFT	1	X
14	HT10070100A	CRANKSHAFT	1	X
15	HT10070200A	GEAR, CRANK SHAFT	1	X
16	22512-040160	KEY, SQUARE	1	X
17	HT10070300A	GEAR, OIL PUMP DRIVE	1	X
18	HT10080000A	ASS'Y METAL(B) CRANKSHAFT	2	X
	HT10080100A	METAL(B), CRANKSHAFT	4	X

No. Part No. Part Name (Q'ty)

A1100N2

Remarks

19	HT10090000A	COMP. METAL(A) CRANKSHAFT	1	X
	HT10090100A	METAL(A), CRANKSHAFT	2	X
20	HT10100000A	COMP. METAL, SIDE	2	X
21	HT10100100A	UPPER, SIDE METAL	2	X
22	HT10100200A	LOWER, SIDE METAL	2	X
23	22512-040160	KEY, SQUARE	1	X
24	22312-080140	PIN, DOWEL	1	X

No. Part No. Part Name (Q'ty)

A1100N2

Remarks

1	EA00003087A	ASS'Y FLYWHEEL	1	X	
	EA00003086A	FLYWHEEL		X	
2	HT11010200A	GEAR, RING	1	X	
3	CE21200000A	BEARING, DRY	1	X	15X18X23
4	HT11020000A	BOLT, FLYWHEEL	6	X	
5	EA00003046A	PLATE, REAR	1	X	
6	26013-100252	BOLT	8	X	M10X25

No.

Part No. Part Name (Q'ty) A1100N2

Remarks

1	HT12010000A	CAMSHAFT, FUEL	1	X	
2	24101-062024	BALL BEARING	1	X	
3	24121-062044	BALL BEARING	1	X	
6	HT12040000A	NUT, CAP	1	X	
7	HT12050000A	KEY, WOODRUFF	1	X	
8	EA00005347A	GEAR, INJECTION PUMP	1	X	
10	HT12070000A	STOPPER, FUEL.CAMSHAFT	1	X	
11	26013-060122	BOLT	2	X	M6X12
12	EA00005568A	COMP. SHAFT, GOVERNOR	1	X	
13	EA00005571A	SHAFT, GOVERNOR	1	X	
14	EA00005567A	HOLDER, GOVERNOR GEAR	1	X	
15	24190-170003	STEEL BALL	7	X	
16	EA00005569A	SLEEVE, GOVERNOR	1	X	
17	HS12080300B	GEAR, GOVERNOR	1	X	
18	24101-062054	BALL BEARING	1	X	
19	TCA2010000A	CIR. CLIP, GOVERNOR SHAFT	1	X	
20	HT12100000A	SCREW(A), SET	1	X	

No. Part No. Part Name (Q'ty) A1100N2 Remarks

1	HT13010000A	COMP. APPARTUS, IDLE	1	X	
2	HT13010100A	COMP. BOLT, ADJUSTING	1	X	
3	HT13010101A	BOLT(A), ADJUSTING	1	X	
4	HT13010102A	SPRING, ADJUSTING	1	X	
5	HT13010200A	NUT	1	X	
6	HT13010300A	NUT, CAP	1	X	
7	HT13010400A	PACKING	2	X	
8	HT13010500A	CAP	1	X	
9	HT13020000A	BOLT(B), ADJUSTING	1	X	
10	HT13010200A	NUT	1	X	
11	HT13010300A	NUT, CAP	1	X	
12	HT13010400A	PACKING	2	X	
13	HT13010500A	CAP	1	X	

No. Part No. Part Name (Q'ty) A1100N2

Remarks

1	EA00005387A	JOINT, EYE	1	X	
2	HT14020000A	ASS'Y PUMP, INJECTION	1	X	
3	HT14030000B	COMP. SHIM, INJECTION PUMP	1	X	
03-1	HT14030100A	SHIM(A), INJECTION PUMP	2	X	0.28
03-2	HT14030200A	SHIM(B), INJECTION PUMP	1	X	0.38
4	26450-060202	BOLT	2	X	

5	26216-060202	STUD	2	X	
6	HT14040000A	NUT, CAP	2	X	
7	22217-060000	WASHER, LOCK	4	X	
No.	Part No.	Part Name	(Q'ty)		
A1100N2		Remarks			
1	HT15010000A	SPRING, START	1	X	
2	HT15020000C	SPRING(A), GOVERNOR	1	X	
3	HT15040000B	COMP. LEVER, FORK	1	X	
4	EA00005431A	ASS'Y LEVER(A), FORK	1	X	
5	HT15040101C	LEVER(A), FORK	1	X	
6	HT15040102A	PIN	1	X	
7	HT15040103D	SPRING	1	X	
8	24190-050001	BALL, STEEL	1	X	
9	EA00005432A	SCREW(B), SET	1	X	
10	HT15040105B	LEVER, THRUST	1	X	
11	HT15040106A	PIN (A)	2	X	
12	EA00004225A	BEARING	2	X	
13	HT15040107A	PIN (B)	2	X	
14	HT15040200A	WASHER, PLAIN	1	X	
15	HT15040300B	LEVER(B), FORK	1	X	
16	HT15040400C	SHAFT, FORK LEVER	1	X	
17	HT15040500A	BEARING 699, MINIATURIZE	1	X	
18	HT15040600A	CIR. CLIP, EXTERNAL	1	X	
19	HT15050000A	COLLAR	1	X	
20	HT15060000A	PACKING	1	X	
21	HT15070000A	COVER, FORK LEVER SHAFT	1	X	
22	26012-060182	STUD	2	X	M6X18
23	26367-060002	NUT, HEXAGON FLANGE	2	X	M6
24	HT15080000A	BEARING 698, MINIATURIZE	1	X	
25	EA00005437A	NUT, HEXAGON	1	X	
No.	Part No.	Part Name	(Q'ty)		
A1100N2		Remarks			
1	HT16010000B	ASS'Y PLATE, SPEED CONTROL	1	X	
2	HT16010100B	PLATE, SPEED CONTROL	1	X	
3	HT16010200D	ASS'Y LEVER, GOVERNOR	1	X	
4	24311-000100	SEAL, O-RING	1	X	
5	HT16010300A	LEVER(A), SPEED CONTROL	1	X	
6	22351-040020	PIN, SPRING	2	X	
7	HT16010400A	LEVER(B), SPEED CONTROL	1	X	
8	HT16010500A	SPRING, RETURN	1	X	
9	HT16010600C	ASS'Y SHAFT, STOP LEVER	1	X	
10	RR26090000A	SEAL, OIL	1	X	
11	HT16010700A	LEVER(C), SPEED CONTROL	1	X	
12	HT16010800A	LEVER, ENGINE STOP	1	X	
13	HT16010900A	WASHER, PLAIN	2	X	
14	26716-060002	NUT	4	X	
15	HT16020000A	GASKET	1	X	
16	26216-060182	STUD	4	X	
17	26716-060002	NUT, REGULAR HEXAGON	4	X	M6
18	22217-060000	WASHER, LOCK	4	X	
19	HT16030000A	BOLT, ADJUSTING	3	X	
20	26716-060002	NUT, REGULAR HEXAGON	3	X	
21	22451-100200	WIRE	2	X	
22	HA14270000A	LEAD, SEALING	2	X	
No.	Part No.	Part Name	(Q'ty)		
A1100N2		Remarks			
1	HT17010000A	ASS'Y PIPE, OVER FLOW	1	X	
2	EA00004961A	COMP, INJECTOR	3	X	
3	EA00000642A	COMP, INJECTOR	3	X	
4	HRA0404900A	SEAL, GASKET	3	X	
5	HRA0405000A	SPACER	3	X	
6	HK13440000A	GASKET, FUEL MANIFOLD	3	X	
7	HK13450000A	NUT, REGULAR HEXAGON	3	X	
8	HT17040000A	PIPE(A), INJECTION	1	X	
9	HT17050000A	PIPE(B), INJECTION	1	X	
10	HT17060000A	PIPE(C), INJECTION	1	X	
11	HT17070000A	CLAMP(A), PIPE	2	X	
12	HT17080000A	CLAMP(B), PIPE	2	X	
13	EA00001717A	SCREW	2	X	
14	HT17160000A	PLUG, GLOW	3	X	

15	HT17090000A	CORD, GLOW PLUG	1	X	
16	HT17100000A	HOSE(A), OVER FLOW	1	X	
17	23080-010000	CLIP, V BAND	6	X	
18	HT17120000A	HOSE(B), OVER FLOW	1	X	
19	HT17130000A	HOSE(C), OVER FLOW	1	X	
20	HT17140000A	CONNECTOR, T	1	X	

No. Part No. Part Name (Q'ty)

A1100N2

Remarks

1	EA00001166A	ASS'Y FLANGE, WATER PUMP	1	X	
2	HT19010200A	PIPE	1	X	
3	HT19020000A	GASKET, W/PUMP FLANGE	1	X	
4	26013-060162	BOLT	3	X	M6X16
5	26013-060602	BOLT	1	X	M6X60
6	HT19030000A	HOSE, WATER RETURN	1	X	
7	23000-016000	CLIP, V BAND	2	X	
8	HT19050000A	THERMOSTAT	1	X	
9	HC09160000B	COVER, THERMOSTAT	1	X	
10	HT19060000A	GASKET	1	X	M8X18
11	26106-080182	BOLT	2	X	
12	HH12190000A	SENSOR, WATER	1	X	
13	23414-160000	WASHER, SEALING	1	X	
14	HH12210000A	SENSOR, GLOW PLUG	1	X	
15	23414-100014	WASHER, SEALING	1	X	

No. Part No. Part Name (Q'ty) A1100N2 Remarks

1	EA00005386A	ASS'Y PUMP, WATER	1	X	
2	HT20010100A	BODY, WATER PUMP	1	X	
3	HRA1200102A	BEARING, WATER PUMP	1	X	
4	HA10060000A	SEAL, MECHANICAL	1	X	
5	EA00004587A	IMPELLER, WATER PUMP	1	X	
6	HT20010300A	FLANGE, WATER PUMP	1	X	
7	HT19010200A	PIPE	1	X	
8	HT20020000A	GASKET, WATER PUMP	1	X	
9	26013-060252	BOLT	4	X	M6X25
10	26013-060852	BOLT	2	X	M6X85

No. Part No. Part Name (Q'ty)

A1100N2

Remarks

1	HT21010000A	ASS'Y ROCKER ARM	1	X	
2	HT21010100A	ASS'Y SHAFT, ROCKER ARM A	1	X	
3	22242-000130	CIR. CLIP	2	X	
4	HT21010200A	SUPPORTER, ROCKER ARM A	3	X	
5	HT21010300A	WASHER, ROCKER ARM SHAFT	2	X	
6	HT21010400A	SPRING, ROCKER ARM	2	X	
7	HT21010500A	ROCKER ARM	6	X	
8	HT21010600A	SCREW, ADJUSTING	6	X	
9	HT21010700A	NUT	6	X	
10	HT21020000A	STUD, ROCKER ARM	3	X	
11	26717-080002	NUT, REGULAR HEXAGON	3	X	M8
12	22117-080000	WASHER, PLAIN	3	X	

No. Part No. Part Name (Q'ty)

A1100N2

Remarks

1	HT22010000B	MANIFOLD, INTAKE	1	X	
2	HT22020000A	PACKING, INTAKE MANIFOLD	1	X	
3	26013-060182	BOLT	3	X	M6X18
4	26013-060302	BOLT	1	X	M6X30
5	26013-060502	BOLT	2	X	M6X50


No. Part No. Part Name (Q'ty)




A1100N2

Remarks

1	HT23010000A	MANIFOLD, EXHAUST	1	X	
2	HT23020000A	GASKET, EX-MANIFOLD	1	X	
3	26216-080222	STUD	1	X	
4	26366-080002	NUT, HEXAGON FLANGE	1	X	M8
5	26216-080222	STUD	4	X	
6	26106-080352	BOLT	2	X	M8X35
7	26106-080652	BOLT	2	X	M8X65

8	26106-080852	BOLT		1	X	M8X85
No.	Part No.					
Part	Name	(Q'ty)	A1100N2	Remarks		
1	HT24010000A	ASS'Y SOLENOID		1	X	
2	26013-060169	SCREW		2	X	M6X16
3	HT24020000A	GASKET, ASS'Y SOLENOID		1	X	
No.	Part No.	Part Name	(Q'ty)	A1100N2	Remarks	
1	EA00004191A	ASS'Y ALTERNATOR		1	X	
2	HT25010000A	BRACKET, ALTERNATOR		1	X	
3	26013-080302	WASHER		1	X	M8X30
4	EA00000613A	SCREW		1	X	
5	26716-100002	NUT, REGULAR HEXAGON		1	X	M10
6	22127-100000	WASHER, PLAIN		1	X	
7	RR15170000A	BOLT		1	X	
8	22217-100000	WASHER, SPRING		1	X	
9	26013-060182	BOLT		1	X	M6X18
10	22127-060000	WASHER, PLAIN		1	X	
11	HT25030000B	PULLEY, FAN DRIVE		1	X	
12	HT25040000A	NUT, V-PULLY		1	X	
13	EA00005570A	ENDCAP		1	X	
No.	Part No.	Part Name	(Q'ty)	A1100N2	Remarks	
1	EA00004199A	MOTOR, STARTING	1	X		
2	26013-120252	BOLT	2	X		M12X25
No.	Part No.	Part Name	(Q'ty)	A1100N2	Remarks	
01	EA00000405E	SILENCER, EXHAUST	1	X		
02	26366-080002	NUT, HEXAGON FLANGNUT, HEXAGON FLANGE	4	X		M8
03	HT27020000A	GASKET, EXHAUST SI GASKET, EXHAUST SILENC	1	X		
04	26106-080162	BOLT,HEXAGON FLAN BOLT,HEXAGON FLANGE	1	X		
No.	Part No.	Part Name	(Q'ty)	A1100N2	Remarks	
1	EA00005385A	FAN, COOLING	1	X		Ø330
2	EA00003006A	PULLEY, FAN	1	X		
3	EA00005874A	SPACER	1	X		M6X12
4	26013-060452	BOLT	1	X		
5	EA00002552A	BELT,V	1	X		
No.	Part No.	Part Name	(Q'ty)	A1100N2	Remarks	
01	HA09250000A	SWITCH, OIL PRESSURE	1	X		
No.	Part No.	Part Name	(Q'ty)	A1100N2	Remarks	
1	EA00004125B	DATA PLATE	1	X		
2	22685-320601	RIVET	4	X		
No.	Part No.	Part Name	(Q'ty)	A1100N2	Remarks	
1	EA00000450C	WATER PIPE ASSY	1	X		
2	EA00000451B	WATER HOSE	1	X		
3	23000-041000	CLIP, HOSE	1	X		
4	23000-035000	CLIP, HOSE	1	X		
No.	Part No.	Part Name	(Q'ty)	A1100N2	Remarks	
1	HA00001425A	CONTROLLER	1	X		
2	HK13010000C	FILTER, FUEL	1	X		
03	HRA0801000A	BOLT, FLYWHEEL	6	X		HST only





|||

|||

|||||

|

||

|||

|||||

—

|||||

—

|||||

|||||

—

|||||

|||||

||

||

|||||
|||||
||

||

